



MADE IN U.S.A.
ENGINE MADE IN
REPEATEDLY CHANGING TO
DEALER

411 R *wheel tractor*

SERVICE MANUAL

SECOND EDITION

Service Department
Via Giudonini, 3 - Serravalle - Forlì (Italy)

Tel. +39 0544 51259 - Adm. 0544 51259 - S. Adm. 76739




Fig. 81. Transmission longitudinal section

TRANSMISSION ASSEMBLIES

CLUTCH

The master clutch assembly is composed of two dry, single-plate clutches, one for the tractor transmission drive and the other for the power-take-off drive.

The unit is controlled by one single pedal which, during the first part of its travel, disengages the main clutch (transmission) and in the following one, the power take-off, but only when this attachment is directly driven by the engine (independent power-take-off).

Figures 82 illustrate, respectively:

a) the clutch engaged; b) the main clutch disengaged; c) clutch completely disengaged.




Fig. 82. - Clutch functional diagram

a = engaged clutch. b = main clutch, disengaged. c = clutch, completely disengaged
P = Power take-off driven plate. G = Gearbox driver plate. F = Lever points

Removal and stripping of clutch.

Removing the clutch assembly from tractor:

Parts to be removed:

The batteries

The exhaust pipe

The engine, with the front axle (Fig. 83).

Operations and cautions.

Disconnect the following components:

— the hydraulic pump oil lines, the steering shaft over longitudinal tie rod, the board from the battery support and this support from the gearbox near the accelerator pedal (remove from the transmission shaft); the electric cables control connection;

— fit two wooden wedges on the front axle, attach the engine assembly to a lift and place the gearbox case on a stand;

remove the screws assembling the engine to the gearbox and facilitate the removal by actuating the clutch pedal.

Note. - To pull the flywheel inner pilot bearing use tool A 618027.




Fig. 83. - Removal of engine, with front axle.




Fig. 84. - Stripping of clutch on device A 711063/A.
1. Plastic pins
2. Lever arm
3. Lever
4. Force adjusting - hub




Fig. 85. - Front view of a tie-rod and orientation of elastic pins.
(See the last figure for reference)

Stripping of clutch:

Mount clutch on fixture A 711063 or on fixture A 711063/A, remove the elastic pins (1, Fig. 84) and push out the disengagement lever pivot pins (2). By slackening the stud bolts fastening the clutch to fixture, all parts become free.

If the clevises (3) must be removed unscrew them from the pressure plate after slackening the adjusting nuts (4).

Inspection of clutch dismantled parts:

Check the clutch components as follows, according to the data of tab 8 at page 57:

- check condition of 4 outer linings and of metal surfaces contacting them; if necessary smooth them. If the rings are coated with oil, replace them, as washing in gasoline and surface brushing are insufficient;
- check clearance between the clutch driven disk hub teeth and splined shaft;
- check the throw-out bearing, and the clutch shaft pilot bearing, located in the flywheel;




Fig. 86. - Clutch, exploded view.

- check clearance between bushes and disengagement lever pins;
- check plate spring characteristics;
- check the throw-out collar working sliding surfaces. If wear does not exceed the permissible limits, the shaft can be mounted again after rotating it 180°; if necessary replace the parts when grease drives due to excessive clearance.

Assembling and adjusting the clutch.

Lubrication:

Smear lightly the following components before assembling using quality chassis grease:

- the clutch disengagement lever pivots, the clevis ends contacting the disengagement levers (3, Fig. 84), the clutch-gearbox and the clutch power take-off shaft splines, the bell ends of push levers (P, Fig. 88), the clevis lever ends where contacting the disengagement collar; in addition service the bearing housing in engine flywheel




Fig. 87. - Clutch section.




Fig. 88. - Clutch plate centering with reference to points P.

Assembling the clutch components.

It is easily performed by following Figs. 86 and 87 and noting that the clutch-gearbox plate is centered with reference to the case and that the elastic pins are oriented as shown in Fig. 85.

Clutch assembly to be performed on fixture A 711083, using it on the side marked with the tractor number.

Clutch adjustment:

For clutch adjustment it is not necessary to place upon the fixture A 711083 the power take-off disc, which remains outside the assembly, and is substituted by a ring (Fig. 89) superposed to fixture A.




Fig. 86 - Clutch adjustment using fixture A 711063.
E, G, H - Discus components; D - Spacer bearing No. 4119.
Note: Use set of K 117063 if lever assembly is not available.

Clutch adjustments should be made as follows:

- adjustment of the clearances of the clutch disengagement lever ends. The adjustment to be made according the Fig. 89 i.e., by checking, using feeler gauge, that between the lever ends and the checking elements laid upon the spacer there is a max clearance of 0.1 mm (0.0039"); a different clearance requires to unscrew the fastening nut and adjusting the outer screw

Note: If clutch is installed on fixture A 711063 A the adjustment may be made after the assembly on the tractor, using fixture A 117063 provided with a suitable flange (Fig. 90).

- adjust the clearance (B Fig. 90) of the power take-off pressure plate claws. Check that clearance is 1.5 to 2 mm (0.0591" to 0.0787"), and if different, unscrew the locknut and screw on or unscrew the screw. The clearance adjustment may also be made when the clutch is mounted on the tractor through the gearbox side cover

The free travel of the clutch pedal is 25 to 28 mm (0.9843" to 1.3780"). Plate wear, however, determines the free travel. Unscrew the pedal to rod nuts as required as necessary to reestablish the previous dimensions.

Clutch control adjustments

Assembly of clutch on engine

The centering of the assembly on the engine flywheel is facilitated by using fixture A 117063 (Fig. 91). It is also used for the disengagement lever adjustment, when fitted with the cover plate (Fig. 90).




Fig. 90 - Clutch adjustment on engine, using tool A 117063, calliper etc.
B - Clearance 1.5-2 mm (0.0591-0.0787 in.)




Fig. 91 - Mounting clutch on engine using tool A 117063.

FLEXIBLE COUPLING BETWEEN CLUTCH SHAFT AND GEARBOX

Noisy transmission.




Fig. 92. - Diagram of flexible coupling for clutch-gearbox shafts.

Calls for the dismantling of the plastic coupling to check the rubber block efficiency; if blocks have excessive wear, replace them.

When reassembling ascertain the correct functioning by locating coupling and shaft splines correctly according the drawing of Fig. 92. In addition tighten the fastening bolts of the flanges to a torque of 2.5 kgm (18 ft-lb).

CLUTCH COMPONENTS: SPECIFICATIONS, ASSEMBLY CLEARANCES AND PERMISSIBLE WEAR

Assembly clearances	mm	in.	Wear limits mm	in.
Between wheel drive splined shaft and its disc	0.010 to 0.105	0.0004 to 0.0042	0.06	0.018
Between lower take-off clutch splined shaft and its disc	0.013 to 0.115	0.0006 to 0.0045	0.06	0.018
Between wheel drive shaft spline marks and flexible joint collar	-0.024 to -0.072	-0.0009 to -0.0028	0.09	0.0032
Between disengagement lever bushes and their pins	0.013 to 0.064	0.0005 to 0.0025	0.06	0.018
Between shaft and clutch throw-out collar	0.030 to 0.145	0.0012 to 0.0051	0.30	0.0118
Clutch driven disc thickness (wheel drive and lower take-off), complete with friction lining	8.2	0.3229	7	0.178
Tightening torque for flexible coupling flange nuts (Fig. 90)		2.5 kgm	18 ft-lb	
Clutch spring specifications				
Spring free length			66.1 mm (2.6024 in)	
Spring length under check load			49.2 mm (1.7795 in)	
Check load			119.0 lb (104.8 kg) (249.7 lb 274.7 lb)	

Each clutch mass 64-65 kg/m



GEARBOX AND EPICYCLIC REDUCTION GEAR

Dismantling - Stripping of components.

Remove the gearbox from tractor as follows:

Parts to be disassembled.

The engine, with its front axle.

The steering box

The two foot-boards, the rear engine cable and the clutch disengagement levers.

The stripping of gearbox components is facilitated by installing it on the rotary stand ARR 2204 (Fig. 93).

The central clutch shell and the shutoff cover.

The gearbox and the epicyclic reduction gear shifter rods.

Operations and cautions.

Follow the sequence described on page 53 for the main clutch removal.

If the tractor is provided with oil lines running from the hydraulic pump to the left, remove them.

Remove the two screws fastening the clutch flywheel cover support in the gearbox, and remove it together with the engine clutch shaft and the flexible coupling.

Remove the gearbox cover with the shift lever, remove the shifter forks, after pulling the fastening pins, beginning from the central rod (2, Fig. 95); slide out the reduction gear control sleeves with shifter forks and rods; take away the 3 springs (Section C-C, Pg. 100) and the detent balls.




Fig. 93. - Gearbox casing mounted on rotary stand ARR 2204.




Fig. 94. - Removal of gearbox casing from tractor.




Fig. 95 - Upper view of gearbox control gears and shift-forks

1. Shifter forks for 1st, 4th gears and reverse - 2. Epicyclic reduction gear control levers - 3. Shift fork controlling 2nd, 3rd and 5th gears




Fig. 96 - Disassembly of primary shaft
(Arrows show the wooden wedge and the pinion)

Primary shaft.

Note. - When disassembling the secondary shaft, engage two gears in order to unscrew the front end fastening nut.

Take away the primary shaft front cover and remove the nut by hammering on rear side.

Prevent the rear bearing from coming off together with the shaft by placing a wooden wedge as shown in Fig. 98.

If necessary pull out the bearing also using a punch A 960703.

Reverse gear and its shaft

Remove the stop and slide out the shaft together with the gear.

Should the shaft remain after some difficulty, apply a screw to the threaded hole in the axle.

Remove bush from gear using the punch A 928251.

Secondary shaft.

Remove the epicyclic reduction unit and the gear box well inner bearing disc.

Slide out the secondary shaft with a bronze punch hammering it at its front end.

Checking the stripped out components of the gearbox and epicyclic reduction gear.

Check gearbox and epicyclic reduction gear components against specifications of page 63.

Neither gear teeth nor chamfered surfaces should be damaged.

Check if the teeth of mating gears are working on the whole face length, and if the surfaces are smooth and free from signs of scoring or pitting.

The driving gear hub internal splines should be free from marks of wear or seizing, and all splines should have their corners without signs of flattening.

The stripped secondary shaft should be absolutely free from pitting or scoring, especially on gear sliding surfaces. Slide the gears on the shaft and check for clearance between the gear guide flanks and the corresponding shaft sliding flanks.




Fig. 87. - Gearbox and epicyclic reduction gear parts.

1. Clutch gearbox coupling - 2. Cover gasket - 3. Primary shaft front bearing - 4. 1st speed and 4th speed gear - 5. 2nd and 5th, 3rd and 6th speed gears - 6. Primary shaft rear bearing - 7. Reverse gear mounted on its shaft - 8. Secondary shaft bearing retaining ring - 9. Secondary shaft front bearing - 10. 1st and 4th speed driven gear - 11. 3rd and 5th speed and reverse driven gear - 12. 2nd and 6th speed driven gear - 13. Secondary shaft rear bearing - 14. Thrust ring - 15. Epicyclic reduction gear - 16. Control lever plate - 17. Epicyclic reduction driven gears - 18. Shims - 19. Reduction gear engagement sleeve - 20. Driven gear shims - 21. Step ring for pivots - 22. Driven gear side rollers.

Note: Shaking from sleeve No. 497830 before installation have been suppressed by right teeth.

The reverse shaft should be smooth and without scoring; if the permissible clearance between the bush fits on the gear and its shaft is in excess of the wear limits, replace both bush and shaft.

The oil bearings should be periodically checked in operation, without slates. The epicyclic reduction driven gear's roller bearings and those for the bevel pinion shaft should have an assembly clearance not exceeding the value listed at page 63 and the surfaces meeting such components should not be damaged in any way.

The gear controls should be checked for deformation and hardening characteristics of the working surfaces. They should slide freely with no塞tions in the box guide holes.

Replace gaskets whenever worn or damaged.

The epicyclic reduction gear thrust rings should be checked and if presenting signs of wear should be replaced.

At gearbox major overhaul, remove the control lever sector plate, located under the cover (Fig. 88), in order to check its components efficiency, especially the ratchet (3) and the control lever dowels (1), which are subject to wear.




Fig. 88. - Gear shift lever.

1. Control lever dowels - 2. Sector plate fastening screws - 3. Gear selector pivot ratchet.




Fig. 89. - Assembling of epicyclic reduction gear on gearbox secondary shaft.

6. Primary shaft rear bearing - 14. Shim - R - Reverse gear shaft - U - Shim sleeve - S.

Gearbox and epicyclic reduction gear reassembly.

To reassemble gearbox components proceed as follows:

Parts to be assembled.

Secondary shaft:

Operations and cautions.

Assemble on the shaft the rear ball bearing after heating it in an oil bath to a temperature of 80° C. approx.:

Install in the gearbox the front bearing after sliding in the shaft from the box rear end, and mount on it the gears according to Fig. 97.

Note. - The shaft nut tightening should be made after the installation of the primary shaft, as it could be facilitated by mounting two gears at the same time.

Reverse.

If the bush has been replaced, after reassembly it must be reamed using reamer M 0321, up to the dimension of page 63.

Fitten the reverse shaft (R) as shown in Fig. 98.




Fig. 100. - Gearbox section.

1-5th-1st-3rd and 2nd-4th-6th-5th speed, obtained by the disengagement of the epicyclic reduction gear sleeve according to the arrow direction indicated by r or speed to be used.

R = Taper roller bearing adjustment shims - Rb = Ring for centering the bearing on bevel ring gear - Section C-C through casing forward wall, and counter-according to the control rods - As. Rod = SI. Pl. 16 - Mo. Ball bearings - A. Reverse gear assembly.



Fig. 191. - Epicyclic reduction gear components.


(Note: Starting from chassis No. 421935 spherical teeth have been superseded by straight teeth).

Epicyclic reduction gear (Fig. 101).

Assemble the epicyclic reduction gear components according to Fig. 101.

Mount on the gearbox the primary shaft rear bearing (6) and fasten by its pin (V), the inner thrust disc (14), having its lubrication passages located as in Fig. 99.

Primary shaft.



Mount on shaft front end the bearing, the oil baffle and the elastic rings;

slide-in the shaft from the case front side and fit on it the first, second and third speed gears;

mount the primary and secondary shafts front covers and their gaskets.

When mounting the first cover, slide in on future A 137003 which avoids the oil seal gasket being damaged by the primary shaft salaries contact (Fig. 102).

Rods and forks for the gear control (Fig. 95).

Introduce through the gearbox wall holes the three idler springs and mount the ball and the first gear shifter rod with its spacer and fork;

introduce through the wall middle hole the two epicyclic reduction gear control rod check balls (see diagram G-C, Fig. 100) and complete the assembly by introducing the two balls from the relevant hole and mount the rod, the spacer and fork isolating the second and the third gears.




Fig. 103. - Orientation of the various spring pin cuts with reference to direction of force (F) and rotation.

Note. - The cuts of the pins fastening rods to rods should be oriented so that the strain expand the pins in their holes (Fig. 103).

Gearbox cover with control cover (Fig. 98).

Mount the lever and the two actuators in the cover and add the cap and snap ring;

Mount to the cover lower section the sector plate and fasten it with the two screws (2, Fig. 98); mount also the gear selector pivot (3).

Before mounting the cover shift in neutral all gears.

Gearbox selector control shaft.

Mount on gearbox clutch control shaft, the flexible joint, the support, the bearing, and its disengagement sleeve.

Before mounting all parts on the primary shaft, be sure that the seal ring is installed (Fig. 97).

NOTE: Shift the gear shift lever backwards, thus disengaging the reduction gear, in order to facilitate the operation of fastening the gearbox to the transmission casing.

GEARBOX AND EPICYCLICAL REDUCTION GEAR COMPONENTS: SPECIFICATIONS, ASSEMBLY CLEARANCES AND PERMISSIBLE WEAR

Date mm (in)	Assembly clearances	mm (in)	Wear limits mm (in)
	Between gears, sun pinions and their driving and driven gears	0.001 to 0.126 (0.004 to 0.00425)	0.25 (0.0500)
	Between gearbox driving and driven gear tooth flanks	0.15 to 0.21 (0.005 to 0.0075)	0.25 (0.0500)
	Between driven gear sun pinion tooth flanks and the flanks of epicyclical fixed reduction gear	0.5 to 0.13 (0.029 to 0.001)	0.25 (0.0500)
Epicyclic reduction driven gear needle gear diameter	20.31 to 20.73 (0.8000 to 0.8050)		
Epicyclic reduction driven gear needle clearance	2.95 to 3.00 (0.1170 to 0.1185)	Between needles and teeth of epicyclic reduction driven gear	0.01 to 0.08 (0.0004 to 0.0032)
Epicyclic reduction driven gears axis diameter	14.402 to 14.389 (0.5655 to 0.5665)		
Reverse shaft bush inner diameter (obtained by accurate tap reading)	25.958 to 25.968 (0.9800 to 0.9801)	Between bush inner diam. etc and its reverse shaft	0.009 to 0.109 (0.0004 to 0.0041)
Reverse shaft diameter	25.000 to 24.973 (0.9842 to 0.9804)		0.20 (0.0500)

Control body release spring

Gearbox selection release springs

Spring free length	38.5 mm (1.420 in)	Spring free length	31.8 mm (1.234 in)
Spring length under check load	31.5 mm (1.2402 in)	Spring length under check load	26.5 mm (1.0490 in)
Check load	11.7 to 15.3 kg (25.4 to 33.9 lb)	Check load	17.4 to 20.4 kg (38.0 to 45.0 lb)

DIFFERENTIAL AND LOCK

The rear half of the tractor body is a case housing the differential assembly and its lock; it is closed at the rear by a cover through which the power take-off shaft projects, the bell pulley unit may be attached thereto.

The case upper opening allows the fitting and removal of the power take-off drive and driven gears.




Fig. 104. - Removal of engine and gearbox from rear transmission casing.




Fig. 105. - Transmission casing rear cover removal.

Disassembly.

To remove the differential case from tractor and to dismantle it, proceed as follows:

Parts to be removed.

The hydraulic lift.

Grease lubrication oil.

The gearbox from the differential case (Fig. 104).

The final drives (Fig. 105).

The seal.

The transmission case rear cover (Fig. 105).

Operations and cautions.

Remove, if installed, the lift bolt, its oil base, and the implement hitch.

Remove the two plugs found under the tractor body.

Disconnect the rear light cable connection.

Place the differential casing on a stand and lift the gearbox with a winch, remove bolts connecting such two components and disconnect them by a lever.

Remove the rear wheels and their discs. To help the disassembly of the various units, remove the mudguards.

The seal should be removed to facilitate the operations which follow.

Remove the differential case upper cover and set the power take-off control levers at the position «MOTORE» (engaged).

Unscrew the rear cover fastening screws and remove the cover by pulling and lowering it very slowly, to allow the removal of the front bearing of the power take-off shaft from its housing.




Fig. 106. - Transmission casing mounted on rotary stand ARR 2204.

The differential lock control

At the same time, remove from the upper opening the gear which is thus free from the shaft end, to avoid damages from its falling in the box.

Note. - To easily disengage the rear cover from the transmission casing, set the power take-off engagement lever in the "MOTORE" (engine) position.

Differential gear casing supports.





Fig. 108. - Lock control spring mounting using tool A 207038.

(On top the spring is represented before assembly (A) and after assembly (B) on Fig. 109.)

To inspect or replace parts remove the rear cover, the pedal complete of attachment, the plug from the shaft left end, in order to make it possible removing it out from the right side.

Fasten the casing on support ARR 220f, mounted on rotary stand ARR 2204 (Fig. 106). Remove the gear casing supports and remove the bevel gear complete.

If the differential casing inner bearing races have to be removed, use puller A 937105.




Fig. 109. - Bevel ring gear assembly with differential 1. Differential lock




Fig. 109. - Rear transmission components.

1. Differential housing • 2. Power take-off driving gear • 3. Bevel pinion roller-bearing adjustment shims • 4. Ring for containing bevel pinion oil ring gear • 5. Ring gear adjustment shims

The bevel pinion:

Unscrew the bevel pinion shaft fastening nut using wrenches A 711109 and A 611100 and stoping the rotation with the brass hammer A 361322. Remove the shaft by applying a bronze punch upon its front end and hammer it out. The power take-off driven gear and the spacer are removed from the casing upper opening after setting the power take off engagement lever in the position marked "CAMBIO + (gearbox)".

Inspection of the stripped components of the differential casing and differential lock.

Accurately clean all stripped out components and check if the gear meshing surfaces are in good conditions.

- check the differential gear thrust rings, arc the pinion bushes and thrust bearings vs. the wear limits of page 69. When replacing bushes, after assembly, ream with expanding blade reamer U 611914 to achieve the prescribed clearance;
- check the copper lining of crown wheel hubs, and replace such parts if the coating is not sufficient;
- check the taper roller bearing and the differential axles oil seals;
- check the differential lock collar working surface and the pin fastening. Check the differential lock control seating (Fig. 107) by a comparison of its characteristics with the specifications on page 69.

Differential casing assembly.

See Figs. 109 and 110 and in addition bear in mind that:

- the planetary casing is secured to the bevel gear by bolts fastened in a torque of 4.5 to 5 kgm (36 to 38 ft.lb);
- the differential pinion axle is held in place by two special head bolts, the same which secure the casing to the bevel ring gear;




Fig. 110 - Rear transmission sectional view.

Ra = Ring gear shaft adjustment shims + a = Drive wheel shaft end spacer, up to free or max. height




Fig. 111 - Bevel pinion and gear correct tooth bearing.

– the assembly of the taper roller bearing inner race on the casing should be made after heating the bearings in the oil bath to a temperature of 204 to 219°C; the same procedure applies to two bearings and to the power take-off driving gear on the bevel pinion shaft (2, Fig. 109).

– the differential lock control spring is installed as shown by the Fig. 107, using tool A 280033.

To facilitate the reassembling of the differential case to the gearbox we suggest placing very near to the shaft front ends — by manoeuvring the relevant items — the power take-off driven gear and the reduction gear engagement sleeve.

Bevel pinion and ring gear adjustment.

When checking or replacing the bevel pinion and gear, the following adjustment sequence should be followed:

- bevel pinion shaft bearing adjustment;
- differential case bearing adjustment;
- tooth bearing adjustment;
- tooth backlash adjustment.

The sequence of operations is as follows:

- install the bevel pinion shaft and its bearing, the power take-off driving gear, the spacer and the adjustment shims Ra (Fig. 100). To calculate the shim thickness, subtract from 58.5 to 59.5 mm




Fig. 112. - Rear view of tool A 132010 for bevel pinion and gear adjustment.




Fig. 113. - Right view of tool A 132010 for bevel pinion and gear adjustment.

(3.302" to 3.342") the sum of the gear width and the spacer width. Finally, check the shaft for free rotation and mount in place of the foregoing shims others having their total thickness minus 0.05 mm (0.002"), which will set a 50 kg/cm (112 lbf) preload on the pinion bearings.

- Remove the bevel pinion and mount the bevel gear complete with differential pinions and supports; tighten one of the pinions with its screw and check with a feeler gauge, at the other support, the overhang thicknesses of the bevel roller bearing shim rings. Divide it by two placing each of the two halves Rb on the two supports and check if rotation is free but without end play.
- For a correct tooth bearing (Fig. 111) pay attention, at pinion assembly, to the number stamped upon the smaller base and marked by + or --; this is quite necessary to determine the thickness of ring Rb, which will be most fit to avoid noises during operation.
We suggest the following sequence:
 - mount the bevel pinion shaft fitted with all its parts and with a ring Rb of any thickness;
 - mount on the casing the tool A 1370t0, according to Figs. 112 and 113;
 - rotate the tool shaft clockwise so that the eccentric cone contacts the pinion base, and read on the quadrant graduated from 32 to 34 mm (3.622" to 3.700") the value at which rotation stops. If this value, indicated on the quadrant, exceeds the one calculated by adding or subtracting from the theoretical distance existing between the pinion smaller base and the bevel gear axis (93 mm - 3.501"), the number marked on the dial (not preceded by any letter mark), it will be necessary to replace ring Rb.
 - The ring to be mounted should have a thickness increased of an amount equal to the difference between the two values.
 - On the contrary, if the value read on quadrant results less than the one read on the pinion after adding or subtracting (according to the + or -- sign) from 93 mm (3.6514"), the thickness Rb should be decreased.

Example No. 1.

Reading on the tool quadrant 93.4 mm

Measure read on the pinion 93.2 mm

Distance between pinion and bevel gear:

$$93 + 0.2 = 93.2 \text{ mm} (3.6514 + 0.0078 = 3.6592")$$

The ring Rb should be 0.2 mm thicker than the one installed, calculated by subtracting $93.4 - 93.2 = 0.2 \text{ mm}$ in order to set the pinion at a distance of 93.2 mm according to the indication marked on it.

Example No. 2.

Reading on the tool quadrant 92.5 mm
Measure read on the pinion - 2.2 mm
Distance between pinion and bevel gear:

$97 - 6.3 = 92.7 \text{ mm}$,
The ring R_b should be 0.1 mm thinner than the one installed, calculated by subtracting $92.7 - 92.5 = 0.2 \text{ mm}$.

- d) Check with a dial gauge the tooth backlash which should be 0.20 mm (0.008"); the correct backlash can be obtained by shifting adjusting shims R_a from one support to the other, in order to set the bevel gear farther or nearer the pinion as required. The overall thickness, determined according to paragraph c) should not be altered.

SPECIFICATIONS, ASSEMBLY CLEARANCES AND PERMISSIBLE WEAR OF THE DIFFERENTIAL COMPONENTS

Assembly clearances	mm	(in)	Wear limits mm	Wear limits (in)
Between pinion and crown wheel teeth backlash	0.20	(0.008)	-	-
Between splines of differential case and the gears	0.050 to 0.100	(0.002 to 0.004)	0.4	0.0157
Differential plate pin and gear tooth backlash	0.15	(0.006)	0.5	0.0197
Between carrier and differential plate case	0.020 to 0.030	(0.0008 to 0.0012)	0.25	0.0098
Between casing and differential gears	0.080 to 0.150	(0.003 to 0.006)	0.25	0.0098
Between differential case collar and carrier	0.130 to 0.215	(0.005 to 0.008)	0.5	0.0197
Specifications	mm	(in)		
Crown wheel adjustment shim thickness (Fig. 111)	0.3-0.5-0.7 (toler. ± 0.02)	0.0118-0.0187-0.0275 (± 0.006)		
Bevel pinion shaft adjustment shim thickness (between carrier and rear hub bearing)	3.8-3.9-4.4-4.5-4.6-4.7-4.8 (toler. ± 0.20)	0.1496-0.1535-0.1573-0.1612-0.1754-0.1893-0.1932-0.1972-0.2011-0.2053-0.2190 (± 0.0098)		
Bevel pinion shaft bearing adjustment shim pack thickness	1.7-1.75-1.8-1.85-1.9-1.95-2.0 (toler. ± 0.01)	0.0662-0.0699-0.0705-0.0713-0.0721-0.0727-0.0733-0.0740-0.0746-0.0753-0.0760 (± 0.006)		
Differential gear thrust ring thickness (1)	1.425 to 1.525		0.058 to 0.068	
Differential option round thrust washer thickness	1.4 to 1.5		0.058 to 0.068	
Tightening torque of bolts assembling planetary gear assembly to crown wheel	4.8 to 5.5 kgm		32 to 39 lb.in	
Differential lock control fork spring				
Spring free length	133		7.406	
Spring length under check load	105.5		6.960	
Check load	28.5 to 31.5 N		69.3 to 66.1 N	

(1) Rings of oversized thickness of 0.1 mm (0.0039 in) are available. Wear limit of a shim: 1 mm (0.0394 in).

FINAL DRIVES

Each consists of a pair of gears having individual casings, mounted laterally to the differential and driven by it (Fig. 110).

Final drive overhaul.

The major overhauls thereof should be made as follows:

Removal from tractor (Fig. 114).

Remove the electrical cable energizing the rear lighting from connection, and take the mudguard away;

select the transmission casing on the stands and remove the wheel assembly, with disc and tire.

Remove the final drive casings from the tractor and pull outwards to slide out the differential case from bevel gear.

Stripping out of components.

Mount the assembly on the rotary stand ARR 2204 with support ARR 2221, and remove the brake drum (fastening nut).

Remove the drum using a universal puller (Fig. 115); remove both final drive casing cover and driven gears;

remove the axle inner bearing stop ring (see Fig. 110) and push it out the casing.

Note. - The final driven gear removal does not necessarily require removal of the casing from tractor.

To unscrew the driven shaft nut of the final drive, mount tool A 187014 to stop gear rotation (Fig. 116); then use a universal puller provided with 2 screws (diameter 16 MB, pitch 1.6 mm) (Fig. 117).




Fig. 114 - Removal of final drive casing from tractor.




Fig. 115 - Removal of brake pulley using the universal puller.




Fig. 116 - Final drive shaft nut removal.




Fig. 117 - Removal of final drive driven gear using universal puller (15 MM x 1,5 mm screw - 2 required).

Inspection of components.

Check the oil seal of the differential axle end of the driving wheel shaft, to prevent oil leakage on brake bands and from the driving wheel.
Check bearings for free running and tools (see also 'See specifications on page 73').

Assembling

When reassembling avoid damaging the seal located in the differential gear gear support.

B R A K E S

The pedal and hand actuated band brakes act on the pulley keyed on the differential axles. The tractor when used on roads requires Pedal and clutch braking and therefore the pedals can be connected by a lock which ensures simultaneous braking action. This fact must be born in mind when setting the pedal free travel which should be equal for both.




Fig. 118 - Brake assembly, pedal and hand controls.

A = Lock lock nuts - B = Gear - R = Brake band centering screws - S = Inner arm - T = Outer arm - U = Inner arm centering screw - Z = Brake band pivot pins.

Brake area. There are 7 segments per band. Two bands per wheel.

Area one segment 6 1/2" x 2" = 13 1/2" sq.in. X 6 = 81 sq.in.

Brake overhaul.

To be performed as follows:

Removal from trailer

To remove brake bands:

drain transmission casing oil and remove from the trailer the final drives, according to page 70 instructions;


- remove the differential casing lower covers and unscrew the screws (M, Fig. 119); remove the pedal springs, remove the adjustment rod ends B from outer arm and slide it out;

remove the braking band end pins from the inner control arm (Z, Fig. 118) and take them away

Inspection.

Check the brake pulley surface and if necessary turn it down, avoiding taking deep cuts which would impair its resistance; check the differential axle seals for oil leakages; correct any leakages smearing the ferodo linings; replace bands if soaked with oil using tool A 317007 for riveting; in addition check the shell and metal bushes for wear (Fig. 118 a and b).

Assembling.



Make sure that:

- the screws (M, Fig. 118) are fastened by wire to the internal levers (S, Fig. 118);
- screws are facing the tractor rear end; if not, the external levers T have been interchanged and no braking action would be possible;
- when mounting final drives, avoid damaging the differential bevel gear support seal with the differential axle end.

Fig. 118. - View of brake bands and controls.

A = Clevis locknuts - B = Caps - C = Brake band connecting screws - D = Outer arm - M = Inner arm screws.

Brake adjustment.

When mounting brakes on tractor:

- unscrew the two nuts and completely screw on the brake band centering screws (R, Fig. 119); then unscrew them through a complete turn, and retighten the nuts;

slacken nuts A and unscrew rods (B, Fig. 119); until the free travel of each pedal is taken up, then screw them again two turns so that the brake pedal travel is about 50 mm (1.96").

Before adjustment, the brake control lever should be set all the way down with respect to the tractor plate.

SPECIFICATIONS OF BRAKES AND FINAL DRIVES

	Data mm (in)	Wear limits mm (in)
Front drive pinion end-tooth gear tooth backlash	0.15 to 0.25 (0.0059 to 0.0098)	0.5 (0.0197)
Clearance between driven gear driver shaft housing and gear hub	-0.050 to 0.043 (-0.0020 to 0.0017)	0.20 (0.0079)
Brake cylinder diameter	1.6 (0.2375)	—
Brake fluid hoses thickness	6 10.2250 (0.237 to 0.0875)	4 5.4 (0.1975) 5.4 (0.2157)
Clearance between bushes and brake plate	2.060 to 2.144 (0.081 to 0.0847)	—

Brake fluid $\text{Mg} \text{Mg}_{\text{O}} \text{O}_2$, Max. (see page 7)

STEERING AND FRONT AXLE

STEERING BOX AND LINKAGE

Removal and disassembly.

The steering box removal and disassembly should be made as follows:

Parts to be removed.

Operations and cautions.

The battery.

Promote it with its frame from the battery box and the gearbox;
detach the rear lighting cable from central connection.

Steering and front drag link

The steering box.

Unscrew the 4 screws fastening the battery box to gearbox;
remove screws fastening the steering box to gearbox;
remove the steering box with the dashboard (lift the battery box first).

Clamp the steering box in a vice and remove the following components:

Steering arm.

Use puller A 735003

Shaft and collar.

Remove the adjusting screw locknut and the collar
shaft side cover (see Fig. 123).

Worm gear shaft

Remove the steering wheel and the braid; remove the screws fastening the steering column to the steering box and remove the steering shaft and its bearings.

Note. - When dismantling the roller bearing outer races from the steering box, do not alter the shim pack (S, Fig. 120).




Fig. 120 - Steering box perspective view.

R = Flat washers - S = Screw to roller tooth & gear shims - T = Taper roller bearing adjusting sleeve - Gq and Gp = Roller shaft seals - U = Adjusting screw - V = Locknut




Fig. 121 - Steering box mounted on track rod.

Inspection of stripped out components of steering box and steering unit.

Check mating surfaces of roller and worm gear for nicks or traces of seizing. Check alignment of roller and worm gear; this signifies that the roller and worm screw reciprocal position is correct; if otherwise the shims should be changed (S, Fig. 120).

Check for clearance between bushes and the roller shaft, according to specifications of page 76 and replace bushes when limits are exceeded, in order to maintain proper mesh between roller and worm gear.

Ream bushes after assembly, using reamer U 611916 to achieve the correct diameter.

If roller shows end play, due to wear of the two washers (R, Fig. 122), replace the shaft also, being the parts riveted together.

Check the taper roller bearing for free play and the roller shaft oil seal.

Check steering arm and drag links for straightness; if bent, straighten them and make sure that their strength is unimpaired.

Steering box assembly.

Parts to be assembled.

The roller shaft bushes.

Operations and cautions.

If bushes have been replaced, after reassembly turn them using reamer U 611916 up to the diameter specified in page 76.

The lower taper roller bearing outer races and shims (S, Fig. 122).




Fig. 122. - Roller tooth cross-section.

R = Roller washers - S = Shims covering screw to roller
T = Centering shim (lower bearing adjusting shims)

To avoid altering the setting of roller and worm gear, the shim pack S thickness should be $\frac{1}{16}$ in if the worm gear, the roller or the steering box have been replaced; the shims pack should then be adjusted as follows:

- Mount the worm gear Assembly, after greasing it with red lead compound, and adjust clearance of taper roller bearings;
- Mount the rotor, sleeve, cover and the steering arm;
- Adjust the roller and worm gear bearing according to indications following.

Note. - Each variation of shims S, calls for a new adjustment of bearings with shims T.




Fig. 123. - Longitudinal section of roller tooth shaft.
G1 and G2 = Seals - V1 ... Adjusting screw.

The worm gear will the taper roller bearing an adjusting shims (T, Fig. 122).

Mount the worm gear shaft with its bearing shims and check it for free rotation which must be as complicated without excessive effort.

The roller shaft, the cover and the steering arm.

Adjustment of roller and worm gear bearing.

The correct functioning of the mechanism requires that the distance between roller and worm gear be as small as possible and corresponding to the original specifications.

To this end, after mounting the unit and positioned the steering arm as in Fig. 122 (this corresponding to straight forward motion of the tractor), the adjusting screw (V2, Fig. 123) should be screwed on, in order to take up the play between roller and worm gear; in addition, check that this condition remains unvaried as the steering wheel is turned 30° left and right.

After adjustment, tighten the lock nut of screw V1.

To refit the guide box assembly to tractor reverse the dismantling procedure.

After assembly, service the guide box with SAE 90 oil and the drag link grease nipple with chassis grease.

Steering tests.

After adjustment check the steering wheel's alignment with the tractor axis; nevertheless a toe-in of about 6 mm (0.1968") and a camber of 2° are acceptable.

Check tightening of the steering lever bolts and the cross-ground clamps and check tie-rods and levers for straightness, to avoid early front tire wear.

SPECIFICATIONS, ASSEMBLY CLEARANCES AND PERMISSIBLE WEAR OF STEERING MECHANISM (STEERING BOX), TIE-RODS AND LEVERS

	Date mm (in)	Assembly clearances mm (in)	Wear limits mm (in)
Steering box tube inner diameter	34,965 to 34,980 (1.3725 to 1.3730)	Between steering roller shaft and its steering tube bush	0,025 to 0,028 (0,0010 to 0,0010)
Steering roller shaft diameter	34,800 to 34,875 (1.3460 to 1.3720)		0,15 (0,0050)
Gearbox inner diameter (after press fitting)	34,915 to 34,937 (1.3745 to 1.3750)	Between steering roller shaft and its bush on steering box cover	0,015 to 0,022 (0,0005 to 0,0008)
Steering control lever shaft diameter	34,975 to 34,980 (1.3730 to 1.3730)		0,15 (0,0050)
Upper bush inner diameter of elevating transmission lever	25,020 to 25,022 (1) (1.1420 to 1.1440)	Between upper bush inner diameter and the steering box cover lower lever pivot	0,020 to 0,105 (0,0000 to 0,0040)
Steering transmission lower pivot dia- meter (Section A-A, Fig. 125)	25,957 to 25,960 (1) (1.1404 to 1.1411)		0,15 (0,0050)
Inner diameter of lower bush of steer- ing arm	32,025 to 32,027 (1.4973 to 1.4995)	Between lower bush inner diameter and the steering arm lower pivot	0,025 to 0,125 (0,0000 to 0,0060)
Steering arm pivot diameter	37,961 to 38,000 (1.4945 to 1.4981)		0,15 (0,0050)
Drag-link inner diameter	19,000 to 19,043 (0,4324 to 0,4741)	Between drag-link end bush and its pivot	0,000 to 0,070 (0,0000 to 0,0020)
Drag-link pivot diameter	11,970 to 12,003 (0,4714 to 0,4740)		0,15 (0,0050)

Note: The steering arm upper and lower bushes shall be mounted into their seats on the support with an interference of 0,05 to 0,20 mm (0,0020 to 0,0081 in); bushes on steering box side cover shall be mounted with an interference of 0,013 to 0,063 mm (0,0005 to 0,0025 in). Assembling torque of steering transverse tie-rod clamp screws is of 2,5 kgm (0,777 Nm).

(*) The data are the pre-modification ones; the post-modification ones (from Tractor with frame No. 400261) have been increased by 1 mm (0,0394").

FRONT AXLE

Checking the front axle.

Removal (Fig. 124):

Place the engine sump on a stand or hydraulic jack; drain radiator water and slacken the rubber bushes band clamps;

disconnect the drag link from the steering arm and the radiator shudder control from its front end;

disconnect the head lamp cable connection; fasten the two ends of a rope in the radiator upper section and insert wooden box wedges to stop front axle oscillation; remove the four screws fastening its forward end to the radiator support and move the front axle assembly forward;

remove the radiator cowling and the radiator.

Dismantling:

Apply front axle to rotary stand (see Fig. 125). To strip it out refer to Fig. 126.

Checking components:

After mounting the axle check bearings which should rotate freely without any noticeable end play; check surfaces and plays of king pins and of the axle pivot pin with their bushes; check the bronze thrust rings thicknesses and replace them if in excess of wear limits (see table on page 79).




Fig. 124 - Removal of front axle and radiator from engine.




Fig. 125 - Front axle mounted on rotary stand for overhauling.




Fig. 126 - Front axle section.

Check the wheel hub cover rubber seals which must ensure protection against slush and moisture infiltration from outside into the bearing, set near to the wheel a surface gauge and rotate the wheel to check the disc and rim for deformation; this must concern both steering wheels.

Check the camber of the steering wheels by laying a square in the vertical plane along the wheel axis, and checking if for any two opposite points on the rim, the difference between measured distances is constant;

check front tires for wear and replace them if their central steering ribs are too worn.

Assembling.

Assemble axle according to Fig. 126; no difficulty should be experienced.

Note. - The lower bronze thrust bearing of the steering knuckle shall be installed with its lubrication passages facing the steel upper thrust bearing. End the assembly by greasing the hinge pivot, the steering knuckles, the front wheel hub cover and the front wheel hub with chassis grease.

**SPECIFICATIONS, ASSEMBLY CLEARANCES AND PERMISSIBLE WEAR
FRONT AXLE COMPONENTS**

	Data mm (in)	Assembly clearances	min (in)	Wear limits mm (in)
Axle hinge pivot bush inner diameter (dimension to be obtained after bush press-fitting) (1)	32,026 to 32,087 (1.2608 to 1.2633)	Between bush and front axle hinge pivot	0,008 to 0,112 (0,0008 to 0,0044)	0,05 (0,0138)
Axle hinge pivot diameter	31,973 to 32,033 (1.2599 to 1.2638)			
Axle support thrust ring thickness	3,10 to 3,21 (0,1220 to 0,1280)			Minimum thickness 2 (0,0787)
Steering knuckle bush outer diameter (dimension to be obtained after bush press-fitting) (2)	38,026 to 38,087 (1,4979 to 1,4935)	Between bush outer diam- eter and king pin	0,025 to 0,112 (0,0010 to 0,0044)	0,05 (0,0138)
Steering knuckle pivot diameter	37,973 to 38,030 (1,4951 to 1,4951)			
Axle thrust bearing end thickness	3,91 to 4,06 (0,0358 to 0,0423)			Minimum thickness 3,6 (0,1226)
Axle hinge thrust bearing thickness	3,925 to 4,000 (0,1545 to 0,1575)			Minimum thickness 3 (0,1181)

(1) Axle hinge pivot bushes and steering knuckle bushes shall be mounted into their seats with an interference of 0,06 to 0,20 mm (0,0024 to 0,0079 in).




Fig. 127. - Electrical diagram of tractors series 400.

G. Generator - M. Starting motor - G. Glow plugs - B. 12 V Battery - A. Horn, optional - PA. Horn buttons - FPG. Head fuse - P. Headlights, with a 50/55 W bulb - GR. Control box - PC. Fuse box - FPG. Control box fuse - LS. Battery charge warning light - FL. Ditchbank lamp - CLA. Lighting and starting key switch - CA. Starting lever switch - PR. Right side light - FPT. Combination number plate and left turn light - GP. Bipole socket - PR. Rear lamp (optional).

ELECTRICAL SYSTEM

DESCRIPTION

The tractors belonging to the 400 series are equipped with a 24 V system, including generating, starting and lighting units. The diagram of Fig. 127 includes:

- No. 1 Fiat generator (type R 115-140/24-1600 Mod. 2), 140 W, replaced by a generator type DC 115/24/7,3 C starting from engine No. 005043 up.
- No. 1 Fiat control box Mod. A/B-140/24, replaced by a Mod. GP 1/24,7 and.

CAUTION: The control box Mod. A/B-140/24 may be used with both generator types whilst the GP 1/24,7 unit must be used with generator Mod. DC 115/24/7,3 C only. See details in the respective chapters.

- No. 1 fuse (16 A) for the control box protection;
- No. 2 batteries (12 V), of 56 Ah capacity at 20 hrs. discharge, connected in series;
- No. 1 electric starter (3 Kw) equipped with a solenoid Mod. E 115-3/24;
- No. 1 five-position starting and lighting switch;
- No. 1 three-position lever type switch for starting and glow plugs;
- No. 4 glow plugs (140 W);
- No. 2 three-light headlamps, each with a 50-45 W bulb for driving and passing lights and a 10 W bulb for parking light;
- No. 1 dashboard lamp with 10 W bulb;
- No. 1 battery charge warning light (10 W) bulb;
- No. 1 fuse box with four 8 A fuses for equipment protection;
- No. 1 bulleight with 10 W bulb;
- No. 1 combination number plate and taillight with 10 W bulb;
- No. 1 two-pole rear socket;
- No. 1 rear floodlight (optional);
- No. 1 electric horn with push-button control and 8 A fuse (optional).



Lighting and starting switch.

Each position of the key on the switch corresponds to a circuit and operates:

position 0:	30	30/1	-- All circuits off;
- position 1:	30-51	30/1	-- Starting switch - battery charge warning light;
- position 2	30-51	30/1-58	Starting switch - battery charge warning light - front parking light - dashboard light - number plate and taillights - two pole socket - 100 mm dia. floodlight with built-in switch.

— position 3:	30-51	301-58-59b	→ Starting switch - battery charge warning light - front parking lights - dashboard light - number plate and taillights - two-pole socket - 100 mm dia. floodlight with built-in switch - passing lights.
position 4:	³⁰ 20-51-56a	301-58	→ Starting switch - battery charge warning light - front parking lights - dashboard light - number plate and taillights - two-pole socket - 100 mm dia. floodlight with built-in switch - driving lights.

The key can be removed when at position 0 only.

Starter switch.

The starting switch operation is dependent upon the position of the combination lighting and starting switch.

Even position of the lever on the switch corresponds to a circuit, and precisely:

— position 0:	15/54	— All equipment off.
— position 1:	15/54-19	— Glow plugs.
— position 2:	15/54-19-50a	— Glow plugs + starting.

The lever returns automatically to position 0 from levers 1 and 2.

Fuses.

The equipment belonging to the electrical system is protected by four 3 A fuses contained in a box placed near the dashboard and by two other fuses.

— Fuse 54/1 protector:	L. H. side front parking light + R. H. side taillight - 100 mm dia. floodlight with built-in switch.
— Fuse 30/2 protector:	Driving lights.
— Fuse 30/1 protector:	Passing lights.
— Fuse 54/2 protector:	R. H. side front parking light - dashboard light - L. H. taillight and number plate light - two-pole socket.
— Other fuses 18 A:	protects the control box;
8 A:	protects the electric horn (optional).

The generator with spy-light, the starter and the glow plug circuits are without fuse protection.

First the cause of fuse failure prior to replacing a fuse.

GENERATOR TYPE R 115-140/24-1600 Var. 2

Specifications.

PULLEY: $\text{D}_{\text{in}}^{\text{d}} 563.750 \text{ (C.D. 100 mm)}$

Fiat generator type R 115-140/24-1600 Var. 2 (see fig. 128) having the following specifications, has been mounted up to engine No. 005044; it has then been replaced by generator type RC 115/24/7.9 C.

Maximum continuous output (24 V)	140 W
Maximum continuous current output (Ampère-limitation at 28 V)	4,75-5,25 A
Speed at maximum continuous current output, at 24 V and 20°C (68°F)	1400-1600 R.P.M.
Maximum continuous speed	4000 R.P.M.
Excitation	shunt
Direction of rotation, as viewed from driving side	clockwise
Regulator group type	A/3 - 140-24




Fig. 128. - Sectional view of generator type R 115-140/24-1600 Var. 2.

1. Red alnico
2. Field coils
3. Pole shoe fastening screw
4. Pole shoe
5. Drive side support
6. Frame
7. Armature
8. Commutator
9. Lamination pack
10. Lubrication chamber
11. Field coil terminals

Bench testing the generator.

Test generator efficiency, according the checks listed hereafter.

Generator should always function coupled with regulator type A/3 - 140/24

Generator tested as a motor.




Fig. 129. - Wiring diagram for testing the generator as a motor.

G. Generator - V. Voltmeter 30 V, DC reading - A. Ammeter, 100 mA F.S. (Battery should supply slightly more than 24 V, +ve current is 7 A)

The arrangement consists in connecting terminals S1 and E7, short circuit, as shown in Fig. 129.

Generator shall be fed as an electrical motor at 24 V. Check that absorbed current, under such a voltage, is 3-5 A at 550-1100 R.P.M.

As test is finished, immediately disconnect terminals S1 and E7 (short circuited), to avoid damaging the field coils as generator speeds up.

Checking generator output (constant voltage).




Fig. 130. - Output curve of generator type R 115-140/24-160 Ver. 2 when warm.

Cutter speed = 1.42 V = 160/160 R.P.M.

The output curve shown in Fig. 130 has been obtained with generator heated after a period of operation.

Therefore, before plotting the characteristics, mount the generator on the test bench, according to diagram of Fig. 131; run it through a motor for about 30 minutes, at 2000 R.P.M.

The current output (5-5.5 A at 28 V) should be supplied by a rheostat.

Stop generator, and disconnect load-theostat. Rotate generator, gradually increasing its speed until the voltmeter reads 24 V, then measure the generator speed.

Such a speed represents the cut-in speed (hot conditions) and should be between 1250 and 1350 R.P.M. (points on abscissa - diagram of Fig. 130).

Stop the generator, insert the load-theostat, and maintaining constant the voltage, check against the various speeds the current values included in the cross-hatched area of diagram in Fig. 130.

Diagrams plotting should be made rapidly when generator performance is beyond its rated output and therefore overheat might damage it.




Fig. 131. - Wiring diagram for the output curve plotting (current versus R.P.M.) at a constant voltage of 24 V.

M. Generator exciting motor - G. Generator - V. Voltmeter, 24 V top reading - A. Ammeter, 20 A top reading.




Fig. 132. - Diagram of connections to check generator heating.

M. Generator exciting motor - G. Generator - V. Voltmeter, 24 V top reading - A. Ammeter, 10 A top reading.
(The regulator group to be connected to the generator should be of the R/2-140/24 type)

Temperature test.

If it should be necessary to determine the maximum temperature of the generator during operation, mount it on the test bench, with power and regulator group, according to diagram of Fig. 132.

Run generator during 45 minutes at 2000 R.P.M. and during 15 minutes at 4000 R.P.M. supplying to a resistor a current of 4.95 to 5.35 A at 28 V.

Overheating measured by pyrometer, should be:

- on generator frame: 45°C (113°F), or less;
- on commutator: 50°C (124°F), or less.

Checking: ohmic resistance.



Field-winding resistance at 20° C (68° F) should be 14.5 to 15.5 ohms, and may be measured between terminal C7 and ground, when generator is assembled.

Armature resistance at 20° C (68° F) is 0.520 to 0.545 ohm; it should be measured only exceptionally to avoid damaging the commutator bars, owing to the soldering of two pieces of wires spaced of 180°.

Fig. 133 - Field winding test.

(Connect the measuring instrument μ -ohm to terminal C7 and to ground)

Disassembly.

Proceed as follows:

- remove the commutator lead, at socket terminal 67, unscrew and remove the through-bolts;
- remove commutator end bracket and slide out the armature with the other bracket;
- clamp armature in a bad-jaw vice and remove the drive pulley and the remaining bracket.

Troubles - Repairs.

Battery charging trouble may be due to:

- faulty generator
- other trouble in the system.

Make sure to locate trouble first. The self-test lamp may furnish an indication with engine stopped or running at different speed rates.

If the generator is faulty, the cause may be sometimes found elsewhere, and particularly in the regulator group or in the circuits; therefore, the operator should take care of generator efficiency and also check the regulator group and the whole system in order to prevent repetition of the generator trouble after its reconditioning.

The battery charge lamp may be helpful to detect trouble. If when introducing the starting and lighting key, and setting it on position 1, the battery signal lamp remains lighted, the generator is normal; if engine is being started and accelerated to a given speed, the light should go out.

If, on the contrary, the lamp goes out only when engine has reached high speeds, the trouble may be due to faulty windings (grounded or short circuited), or to the armature.

Generally, the higher the R.M.P. rate at which the charging begins, the higher the potential damage if the lamp remains lighted; this indicates an insulation between the generator cables and the regulator group; or shows that the group contacts are oxidized, and internal connections dislodged; or that some generator coil is interrupted, or completely grounded.

If the above procedure leaves the light out and the trouble persists also after replacing the bulb this signifies that the trouble is to be found between bulb holder and switch, or between switch and the connections of the components branched upon it.

When the battery indicator light goes out to go on again the engine speed being steady the fault is probably due to the regulator group or free or to the electric connections (the jacks).

Generator repairs are to be carried out as follows:

a) *Brushes*.

If broken, chipped, or worn out, replace them with spare parts furnished by the FIAT Company - Sezione Ricambi. Be sure to avoid the installation of other brush boxes, as FIAT spares only can ensure a regular and long-lasting operation of both commutator and generator.

b) *Field-winding*.

Check field coils by circulating test bench current through them (Fig. 133) and measuring the voltage and the current with the bench instruments, then calculating the coils' resistance.

If connections alone are interrupted, repair them carefully; but if the winding is damaged replace the assembly with a new FIAT spare. We do not suggest making field coils, as a special procedure is required.

Pole-shoe screws should then be fully tightened to set the air gap at its previous value. Reboning of pole-shoes must never be resorted to. If the air gap (see table on page 87) is not maintained we advise warming up somewhat the coils, which are already shaped, to facilitate their installation.

c) *Armature*.

Commutator. — If commutator bar surface contacting the brushes is worn or out-of-round, turn down the commutator. Be careful when fixing the armature in a lathe and centering it, as the recentering of armature assembly between centers is not possible. Commutator centering should be most accurate, as commutator out-of-round, measured on brush ways should not exceed 0.01 mm (0.0004"). After commutator turning undercut the slots between bars using a saw blade to a depth of 1 mm (0.0394")

Armature winding. — If damage is in the armature winding, replace the whole assembly. It's not advisable to attempt making a new coil, as a special procedure would be required. Armature checks are to be made with the instruments illustrated in Figs. 134 and 135.




Fig. 134. - Checking the armature with twin-contact tool.
The interruption is located by the no indicator of the
ammeters.




Fig. 135. - Checking the armature on the testing
apparatus using a blade.
(Blade vibrates at short circuits).

Reassembly of generator.

After any repair or replacement and before reassembling the generator proceed as follows:

- a) Blow away all dust - chiefly carbon dust - from all components, using an air jet;
- b) clean brush holders and the commutator and bracket from grease and carbon dust deposits, using a dry cloth;
- c) clean commutator surface, removing carbon dust between bars. Avoid using abrasive paper or cloth soaked with gasoline or solvents;
- d) check brushes for play inside brush-holders, against the values listed below:
 - cross clearance 0.1 to 0.3 mm (0.0039" to 0.0118")
 - end clearance 0.2 to 0.5 mm (0.0078" to 0.0197")
- e) check brush spring pressure which should be 69 to 76 kg (1.62" to 1.675 lb.);
- f) service with high melting point grease the ball bearing, the commutator and bracket bush and the bracket.

The sequence shown in the chapter « Covering disassembly » should be reversed to reassemble the generator. Note that when reassembling the drive and bracket its lubrication may be facilitated by holding laterally both brushes and springs.

After reassembling, repeat the functional checks as shown in paragraph « Bench testing the generator ».

FIAT GENERATOR R 115-140,24 - 1800 Var. 2 - SPECIFICATIONS

Items	Values
Operational test at motor	Speed 1200 to 1500 r.p.m. Voltage 24 V Current 4-5 A
Running generator before plotting of the curve (not conditioned duration: 20 minutes; temp. versus revs)	Speed 1200 to 1500 r.p.m. Voltage 24 V Current 5.5-6 A Running 15-16 min. at 2000 r.p.m. Output current 1 A to min. at 4000 r.p.m. Voltage 5.05 ± 0.3 A Commutator temperature 73 V
Heating test	Increment not more than 20° C (19.4° F) Casing temperature not more than 45° C (113° F) Instrument not more than 45° C (113° F)
Resistance, at 20° C:	
— field-oils	14.8-15.5 ohm.
cylinders	0.020-0.040 ohm.
Commutator bar resistance maximum allowed out-of-round	0.3" mm (0.0032")
Brush duration	1500-2500 hours
Pressure by springs on brushes (new)	169 C.76 kg (1.581-1.675 lb.)
Brush cross clearance inside brush-holders	0.1-0.3 mm (0.0039"-0.0118")
Brush end clearance	1.5-0.5 mm (0.0118"-0.0235")
Diameter between pole shoes middle line	710-719 mm (27.75"-2.757")
Air gap	70-947 mm (0.0107"-0.0367")
Tightening torque of drive pulley nut	7 kg.m (50.53 ft-lb.)

GENERATOR TYPE DC 115/24/7/3 C

Specifications.

PULLEY: 1/8 in. dia. 745° (6.0 38 mm)

The generator type DC 115/24/7/3 C, illustrated in Fig. 136, has been mounted beginning from engine No. 005046; its specifications are:	
Voltage	24 V
Maximum continuous current (ampère - limited)	7 A
Maximum current	8.5 A
Maximum continuous power	196 W
Maximum power	238 W
Cool-air speed, 24 V, 20°C (68°F)	1550 to 1650 R.P.M.
Speed of maximum continuous current, 7 A, 20°C (68°F)	1725 to 1875 R.P.M.
Speed of maximum current, 8.5 A at 20°C (68°F)	1770 to 1930 R.P.M.
Maximum continuous speed	5800 R.P.M.
Rotation (from drive side)	clockwise
Excitation	shunt
Regulator group	A.S-140/24 type : GP 1/24/7

Main features of this generator compared with the preceding one are: completely enclosed, more power reaction-type brushes.

Reaction brushes are advantageous as vibrations against the brush-holders are reduced, compared to the radial type.

For equal brush sections they allow a larger contact surface on the commutator, thus reducing both sparking and temperature; the excitation current also is reduced, and the regulator group contacts, voltage and current regulators have longer life.

When the generator is coupled to regulator group GP 1/24/7, starting (cold), it may generate a current greater than the maximum one; but it is reduced when the internal continuous running temperature has reached appropriate levels (thermal equilibrium), without any damages to the components.

The feature is due to the current regulator, which, as explained when describing the regulator group, is thermostabilized.




Fig. 136. - Longitudinal and cross section of generator type DC 115/24/7/3 C.

Note: A bracket is fastened by screws (not represented in the figure) to the generator frame. Bracket must be fixed too securely.

Therefore it is required by the equipment inserted in the system. The generator may be overcharged without any damage to windings; in fact, they are at ambient temperature at the start of operation and therefore are not yet thermally stabilized.

When, after 20-30 minutes of functioning, due to ohmic resistance, the group and generator become stabilized, the current regulator reduces the current to a value continuously possible.

The temporary overcharged operation of the generator, allows a quicker battery recharge, especially if its charge level is low, due to repeated and cold startings.

The limiting current is a function of the surrounding temperature; and therefore during the summer the limiting current will be less than during the Winter, and the generator temperatures during the various seasons are more uniform.

Checking the generators troubles and remedies.

Consult diagrams of Figs. 129-131-132 for the generator checks, and for the coil check the Figs. 133-134-135.

Tests to be carried out as for generator type R 115-140/24-1600 Ver. 2. For specifications, see table on page 89.

Plotting the output curve (Fig. 137), requires the previous inspection of the brushes, that should be completely seated upon the commutator, which takes place after ten hours of operation, with a current output of 2 A at 2300 R.P.M.

See page 85 for the generator trouble-shooting and repairs.




Fig. 137. - Output curve of generator type DC 115/24/T3 C.
(Beginning of battery charging, at 24 V, 1600-1800 R.P.M.)

GENERATOR FIAT DC 115.24.T3 C - SPECIFICATIONS

Items	Values
Operational test at motor:	
Running generator before plotting of A-V-I curve (short circuit duration 30 minutes)	Speed 1150-1250 r.p.m. Voltage 24 V Current 4.5-6.5 A
Rating test:	Speed 2300 r.p.m. Voltage 24 V Current 6.75-7.25 A
Performance at 24°C (64°F) temp:	
Field-coils (between terminals 67 and ground)	15.5-15.9 Ohm
Armature	6.30-6.52 Ohm
Commutator bar maximum elevated position	6.0 mm (0.0009")
Brush end play w.r.t. holders	C.1-2.4 mm (0.0039"-0.0117")
Pressure by springs on brushes (new)	0.60-0.78 kg (1.32-1.72 lb.)
Diameter between pole pieces (middle line)	70.8-70.75 mm (2.771"-2.756")
A gap	0.3-0.4 mm (0.0118"-0.0157")
Tightening torque of drive pulley nut	1 N.m (0.05 lb.in.)

CONTROL BOX MOD. A/3 - 140/24

Description.

The Fiat A/3-140/24 regulator unit contains three elements: voltage regulator, current limiting regulator and circuit-breaker. These three elements (Fig. 138), fastened to the block, are enclosed in a sealing cover, equipped with gasket, which prevents shocks, dust and dampness.

Note. - A distinction will be made in the text between modifications made on regulator units with numbers up to 088917 and on those with numbers starting 088918 up; the numbers are marked on the cover.

Figs. 138 and 140 represent voltage regulator and circuit-breaker; the current limiting regulator looks quite similar to the voltage regulator.

Fig. 141 represents the wiring diagrams of the regulator units mounted on tractors series 400 and bearing the production number up to 088917 and from number 088918 up. The diagrams have thick lines to represent the coils in series on the generator recharge circuit, to differentiate them from the shunted ones on the same circuit.

All corrective steps are of the spring blade type, and adjust their load according to the calibration value, through the screw located at each regulator unit element size.

The temperature increment due to the shunted circuit currents and deriving thermal expansion, might influence the calibration values of the voltage regulator and of the circuit breaker. This is prevented by the contact hinges, which, being bimetallic, are thermally compensated.

The group bears the following terminal numbers:

- 51 - connected to positive generator terminal;
- 67 - connected to generator field coils;
- 31 - grounded;
- 30 - connected to the battery positive terminal and to electric system.

The wiring diagram of Fig. 127, points out the valve (FPG) protecting the regulator group.




Fig. 138. - Regulator unit (from no. 088918 up) as seen from the circuit breaker side.

1. Terminal 31 - 2. Terminal 67 - 3. Terminal 30 - 4. Voltage regulator or current regulator connection - 5. Current regulator series winding terminal soldered to circuit breaker - 6. Current regulator free contact connection with the regulating resistance.





Fig. 139. - Cross section of regulator unit (section shows voltage regulator).

1. Armature adjustment spring - 2. Calibration screw - 3. Voltage regulator body - 4. Armature - 5. Fixed contact bridge screw - 6. Fixed contact bridge - 7. Hinge dielectric spring (the bimetallic blade is coated on top).

Fig. 110. • Cross section of regulator group.
(Across circuit breaker)

1. Fixed contact bracket - 2. Pre-load spring - 3. Hinge spring (steel) bearing mobile contact - 4. Body - 5. Armature stop - 6. Calibration screw - 7. Adjustment spring - 8. Thermal compensation by-metallic blade - 1a. Up to No. 03897 - b. From No. 03898 up - 9. Armature rivet - 10. Contact gap: 0.7-0.85 mm (0.0275-0.0334") for armature, fitted with lever R for rivetless assembly; the clearance between contacts is 1.15-1.20 mm (0.0452-0.0472")



The wiring diagram of Fig. 127 shows the regulator group fuse.


The diagram of Fig. 142 represents the characteristics of the post-modification and the pre-modification groups. The junction zones between the two hatched strips, represents the functional limit between voltage regulator and current regulator.


Important:

1. The regulation group type A/3-140/24, should function only with generator type R 115-140 24-1600 and type DC 115/24/3/8 and derived.


The group shall never be used with a third brush generator even if of size corresponding to the generator prescribed above; the elimination of the third brush would not change things; even worse it would be to connect a third brush generator as if it were controlled by a regulation unit.

The reason is that both groups and generator circuits, namely the field coils of the generator, that are so reciprocally arranged as to get the best performance for the whole combination.





a) Characteristics obtained as generator runs at 2000 R.P.M., for regulation groups in No. 082918.



b) Characteristics obtained as generator runs at 2000 R.P.M., for regulation group from No. 082918 up.

Fig. 142. - Dunsur characteristics on battery, with group at 60 °C (122 °F).

- Avoid connecting group terminal 67 to generator terminal 61, even momentarily, because heavy sparking and group contact excitation would follow and contact welding would also eventually follow. It is thus indispensable to connect terminals having the same number; as even if wrong connections are eventually corrected and the group functions regularly, its usefulness would be nonetheless shortened.
- Shocks to regulator unit should be avoided, especially to its lower part containing the adjustment resistance (Fig. 146). During the bench testing the group shall be mounted with its terminals placed downwards, and an insulating sheet shall be interposed between the fastening support and the base.
- Connection between group terminal 31 and traction grounding shall be well secured, otherwise the regulation effect would fail as both the current and the shunt coils are lacking. This case allows the generator to increase its voltage as speed increases and windings are burned and voltage regulator and cut-out contacts are damaged, owing to excess of current excitation of the generator.

Regulator group bench testing.

To avoid miscalculations, the regulator group performance data must be measured by instruments periodically calibrated and according to the prescribed rules and methods.
No removal of group seals is allowed for taking such measurements.

Checks.

Operations and cautions.

Test efficiency of regulator group as follows:

- a test bench will be provided with a FIAT P.116-140/24-1500 Var. 2 or FIAT DC 115/24/7/2 C generator, coupled to a motor whose speed may be gradually stopped;
- the installation should have the measuring devices and instruments, concerning the testing of cut-out relay, current and voltage regulators according to instructions and rules hereinfor.

Cut-out relay.

i) Closing voltage.

Wiring should be as shown in Fig. 143:

— generator speed should be gradually increased;




Fig. 143. - Electrical diagram for testing the cut-out relay closing voltage.
M. Motor or test bench - G. Generator - V. Voltmeter.




Fig. 144. - Electrical diagram for testing the inversion current.
M. Motor of test bench - G. Generator - A. Ammeter - V. Voltmeter.
(Batteries are connected in series and must be fully charged, at a capacity of 60 Ah).

Voltage regulator.

Current regulator




Fig. 145. - Electrical connection diagram for the checking of the voltage regulator and of the current regulator.
M. Motor of the test bench - G. Generator - V. Voltmeter - A. Ammeter.

-- check the voltmeter value when cut-out relay closes; it must be read at the moment the temp of 24 V, 5 W, lights: insert lamp between terminal 30 and ground.

Closing value must be 25,1 to 26,9 V, for both pre-modification and post-modification groups. Checks should be made when cold, before coil temperature increases.

2) Back current at $25 \pm 10^\circ C$ ($77 \pm 56^\circ F$). Wiring should be made according to Fig. 144 and generator run to 2000 R.P.M. during about 5 minutes, making sure that voltmeter reads at least 20 V, then decrease the generator speed.

The ammeter pointer which was indicating a certain charging current will decrease and approach to zero and begin to show the inverted current value.

As the generator progressively slows down the ammeter dial will show increased values, up to a certain limit, after that a sudden fall to zero will be observed, due to the opening of the cut-out relay points. Such a current value will be not larger than 3 A for groups having production number up to 628917 and within 5 to 10 A for groups from number 628918 up.

Note. - Such a test should be carried out quickly to avoid battery discharge. When repeated start from a stopped generator.

Regulation voltage at half load on batteries, at $50^\circ \pm 3^\circ C$ ($122 \pm 37.4^\circ F$).

Close the cover and connect it according to the diagram of Fig. 145 and operate the group until the coil temperature reaches 47 to $53^\circ C$ (117 to $127^\circ F$).

Start the generator and slowly run it up to the same rate of 2000 R.P.M.; adjust rheostat so that generator delivers a current of 4 A (half-load current);

Check that at such current value, the voltage is about 26,7 to 29,7 V.

Limitation current on batteries.

Connect group according to wiring of Fig. 145, and check the limitation current on batteries immediately after the foregoing test, using the same instruments: proceed as follows:

-- rheostat should be set at its maximum resistance value;

-- resistance shall then be reduced until the current limitation value of 5 to 5,5 A has been reached, for groups up to No. 628917, and of 4,75 to 5,25 A for groups from No. 628918 up (corresponding voltage: 23 V);

-- said currents should not decrease when resistance is reduced, and on the contrary, voltage should go down nearly to 24 V (for groups up to No. 628917).

For those groups with numbers from 026916 up, the resistance being decreased, the current shall increase up to 6 A, approximately, and the voltage decrease down to 24 V.

Regulator group repairs.

In most cases when the unit does not perform correctly, it is advisable to substitute it instead of attempting to repair and calibrate it.

Exceptionally, if in need of repair, follow the bench checks already described; successively, according to the data, obtained replace the resistance, Fig. 146, and faulty elements. Always replace complete units.

Components elements as well as resistances should be kept into suitable containers, which prevent their being damaged deformed, smeared by grease or foreign matter, etc.




Fig. 146. - Regulator group bottom view.

1-2. Screw and nut, fastening the resistance - 3-4. Nut and cap fastening the cut-out relay - 5. Nut fastening the voltage regulator - 6-7. Nut and cap fastening the current regulator

Note. - Most failures, especially the important ones, such as:

- excessive wear, or cut-out relay contact sticking;
- oxidation of voltage and current regulator points;
- burnt or fused points;
- short-circuited coils;
- coil burning;

may be due to causes originating outside the regulator group and chiefly to generator misfunction, as, for example, to field winding resistance alteration, impaired circuits (cables, etc.). Therefore the operator should make the group operate correctly, but in addition extend the checking to the generator and to the charging system.




Fig. 147. - Regulator group (up to No. 026917) as seen from cut-out relay.

1. Terminal tube 31 for short winding end - 2. Terminal tube 51 - 3. Terminal tube 30




Fig. 148. - Regulator group (up to No. 026917) as seen from voltage regulator side.

1. Terminal tube 31 - 2. Terminal tube 51 - 3. Terminal tube 30 - 4. Connection from current regulator to voltage regulator - 5. Current regulator serial winding end - 6. Connection of regulator to the adjustment resistance

Dismantling and reassembling of group.

Remove lead seals, unscrew the nuts fastening the cover to base, remove both cover and gasket and dismantle according to needs.

Unweld the coil terminals connected to other elements, and unscrew the nut fastening it to the base. When checking or reassembling such elements, make sure that the setting screws are not being tampered with, as during manufacturing they have been sealed with varnish.

For coil terminal soldering use exclusively a neutral flux, avoiding acids.

Carefully watch the insulating washer assembling.

Before reinstalling the group cover, make sure that:

- the open contacts distance of the cut-out relay, when at rest, is 0,70 to 0,85 mm (0,0275" to 0,0334") for rivet-type groups (R, Fig. 14B), and 1,15 to 1,30 mm (0,0452" to 0,0512") for non-riveted groups;
- check the group insulation by applying 500 V at 50 cycles between the magnetic coils and the chassis as between terminals 30 and the base.

Mount cover when group is hot to avoid moisture condensation after closing.

CHECKING AND CALIBRATION VALUES OF REGULATOR GROUP A3-140/24

Group	Cut-out relay (when cold)		Voltage regulation (when heated to 50°C + 122°F or battery)		Cut-out relay (when cold on battery)	
	Closing voltage V	Inversor current A	Battery A/h	Regulation voltage at cold feed on battery		Dissipation current A
				V	A	
Up to No. 038817	25,1-25,9	not more than 5	60 (Nc. 2 batteries in series)	28,0-29,7 (with 4 A)	5-5,5	
From No. 038818 up	25,1-25,2	5 to 10 (with wiring of 2 g. 144)	50 (Nc. 2 batteries in series)	29,7-29,7 (with 4 A)	4,75-5,05	

Adjustment resistance of group (Fig. 14E) at 20°C (68°F) is 138-142 ohms.

CONTROL BOX MOD. GP 1/24/7 (Part No. 4055889)

Description.

The Control Box Mod. GP 1/24/7 is composed by three units: cut-out relay, current regulator and voltage regulator.

Both the voltage and the current regulators (Fig. 149) consist of a J-shaped body with a bend on the end of one arm and a tongue (5) on the other. An armature (2) supported by a tension spring (1) is fastened to the body (9). The spring is made of two blades lying flat on each other, one of steel and the other bi-metallic.




Fig. 149. - Exploded view of the voltage regulator.

c. Air gap between core extension and armature to be measured at the position indicated by the axis 0-0 (0.55 to 1.1 mm or 0.022 to 0.044").

1. Hinge spring (steel and bi-metallic); - 2. Armature; - 3. Adjusting spring; - 4. Fixed contact supporting sp.; - 5. Adjusting spring supporting sp.; - 6. Regulation resistance; - 7. Additional resistance in series with the shunt winding of the voltage regulator; - 8. Base; - 9. Body; - 10. Damping resistance; - 11. Additional resistance in series with the shunt windings of the current regulator and cut-out relay; - 12-13. Points clamping the turns of the windings to the sections (7) and regulation (8) resistances; - 14. Resistance terminals insulators.




Fig. 150. - Exploded view of the cut-out relay.

d. Air gap 0.54 to 0.75 mm = 0.021 to 0.030 in.

The contacts points of the elements are fixed to the armatures (2) and to a support applied to the elements. Point resetting is carried out by using a special tool on the tongues which carry the fixed contact points. The cut-out relay is similar to the other two elements and is also equipped with a hinge (1) made of one steel and one bi-metallic leaves.

The armatures of the three units are equipped with adjusting springs (9). Adjusting is done by loading the tongues (5) of the springs. The three units are fastened to the base by the threaded ends on their cores and sealed by a cover with a rubber gasket. The base is provided with three terminals, the numbers of which are marked on the cover connected to the cables as follows:

- 51, connected to the generator positive terminal;
- 62, connected to the generator field coils;
- 50, connected to the electric system.

The following resistances are riveted under the base (Fig. 150):

- the additional resistance for the shunt winding of the voltage regulator (7) and additional resistance for the shunt winding to the current regulator and cut-out (11);
- the regulator resistance (6) connected in series to the acceleration winding (8); damping resistance (10) shunted to the generator field-winding (between the current regulator body and ground).

Operation.

At low speeds the generator voltage is not sufficiently strong to induce in the shunted windings of the control box units a magnetic flux apt to attract the armature to the cores. All armatures are therefore at rest and the cut-out contacts are open, whilst the current and voltage regulators ones are closed.


As the generator speed increases the voltage and the current output increase creating a stronger magnetic flux; when the generator reaches predetermined values of speed and voltage the magnetic flux becomes sufficiently strong to win the resistance of the lens on springs and so attract the armature to the cut-out core to close the contacts. A current is then circulated from the generator positive terminal through the series windings of the units (Fig. 151) to the electric system equipped and positive terminal of the battery and returning to the negative brush of the generator.

The magnetic flux induced in the series windings is added to the one induced in the shunted windings to hold the cut-out contacts more securely closed. As a rule, after the cut-out is closed and the generator voltage keeps on raising, the contacts of the voltage reach the predetermined setting value. As the contacts open due to the magnetic flux induced by the shunt winding and acting on the armature, an acceleration winding (a) and the regulation resistance (B) are inserted in the field winding circuit of the generator. The regulation resistance lowers the current through the generator field winding and consequently the generator voltage until the voltage regulator contacts close again.

Fig. 151. - Electrical diagram of the control unit GF (25).

B. Regulator resistance - T. Additional resistance in series across the shunted winding of the voltage regulator - 10. Damping resistance - 11. Add. shunt resistance in series across the shunted windings of the current regulator and cut-out relay - a. Acceleration resistance in series with the regulation resistance (B) - B. 12 v batteries connected in series - G. Generator model DC 150/200/3 and its mod. and rev. no. - 20. Electrical equipment terminal - 31. Ground - 34. Generator positive terminal - 62. Generator field winding terminal

(Note. The windings of the three elements of the control are drawn with light lines and shunted across the generator circuit; those drawn with black lines are connected in series)



Then the field winding current and consequently the generator voltage increase resulting in the re-opening of the contacts. This cycle repeats itself and an oscillation of the armatures is maintained to keep the voltage within the setting limits.

The function of the acceleration resistance (a) is to increase the oscillation frequency of the voltage regulator when it reduces its pull on the armature (2). In fact, as the contacts open the field winding current going through the acceleration coil creates a magnetic field which is subtracted from the one created by the regulator shunt winding and therefore reduces the magnetic pull on the armature, favouring its release.

Should current consumption exceed a certain limit or the battery be discharged, a great current cutout will be required from the generator: this current induces a magnetic pull on the current regulator armature sufficient to close it against the action of the springs. The contacts open and insert through the generator field winding circuit the regulation resistance and the acceleration coil with the same results described above in the case of the voltage regulator. In this case it is the current which is contained within set limits. If the current cutout requirements remain above said limit, the current regulator armature keeps on oscillating substituting the voltage regulator one, which remains at rest.

To conclude, the current regulator limits the maximum current output of the generator, whilst the voltage regulator ensures through the system a voltage ranging within pre-determined limits (calibration limits) not harmful to the battery, for all the charging range which requires an output below the maximum values from the generator, equipment and battery.

The maximum power is reached at the operational limit between the two units (current and voltage regulators) and is also known as peak-power.

The shunt resistance coil (10) protects the voltage and current regulator contacts from the sparking deriving from the electromagnetic energy of the field coils during the opening cycles by grounding part of the energy.

When the generator slows down to a point where its voltage is lower than the battery voltage, a reverse current is produced from battery to generator. This reverse current will go through the series windings of the current regulator and cut-out in the opposite direction. No consequences will derive to the current regulator, as the current is not strong enough to pull the armature, but it will demagnetize somewhat the cut-out relay which has the contacts closed, so that as soon as the reverse current will reach a certain value the armature will be released causing the contacts to open and consequently discharging from battery to generator will be prevented.

Finally note the functional importance of the bi-metallic blades which together with the steel ones make up the fastening hinges of the armatures (1, Figs. 149 and 150).

The passage of current across the shunted windings of the control box unit causes a temperature rise, which produces an increment of the ohmic resistance, and consequently the quantity of current going through them is reduced. As for the armatures, the current reduction results in less magnetic pull, therefore a voltage higher than the set values would be needed in summertime to open the voltage regulator contacts and close the cut-out contacts.

To compensate the reduction of the magnetic pull on the armatures, the bimetallic blade which makes up the hinges is so disposed as to gradually reduce the tension in the spring as the temperature rises.

In the case of the voltage regulator the action of the bi-metallic blade is more than sufficient to maintain the set voltage against the variations of ambient temperature (thermal overcompensation) therefore the setting is slightly lower in the summer and slightly higher in the winter. This setting value of the voltage which varies slightly according to the temperature favours long life of the batteries the voltage of which, when current passes through, decreases as the electrolyte temperature increases, and on its part electrolyte also is sensitive to the surrounding temperature.

Therefore, should the voltage setting of the voltage regulator not follow the requirements of the battery temperature conditions, the following trouble would develop:

- when room temperature is high, the voltage would exceed the set limits and the battery would be compelled to absorb a very strong current resulting in excessive electrolysis and consequently wear of plates, insulators, etc.;
- when room temperature is low, the voltage would be scarce and could not ensure a correct recharging rate.

Also in the current regulator, the bimetallic blade (1, Fig. 152) which is part of the spring hinge of the armature is so disposed as to gradually reduce the tension as temperature rises.

But as explained above regarding the other two units (voltage regulator and cut-out), as the shunt winding temperature rises the current put across it decreases and consequently also decreases the magnetic pull on the armature. When the unit is cold this results in a higher regulated current and when it is hot a lower current because of the bi-metallic blade.

The bi-metallic spring of the current regulator works as thermal compensation of the current going through it and determines the following advantages:

- at the start or after an interval of about 2 hours from the last period of operation, the control box is at room temperature (that is, not thermally stabilized) and therefore, as explained before, the regulated current is higher than the maximum continuous permissible one for the generator, and should the system require it, the generator DC 118/24/33 E can be overloaded.

When the control box and generator temperatures rise, the bi-metallic blade reduces (in about 50 to 60 minutes) the regulated current to a value which the generator can tolerate, therefore the tem-

power output of the generator not only does not damage the windings but is good for the battery particularly when the charge is low, which may happen after difficult or repeated cold starting or after the kind of work which requires repeated startings for short hauls;

- the regulated current is dependent upon the temperature of the surroundings and will be higher or lower depending upon a low (Winter) or high (Summer) temperature, which for the generator means more uniformity of temperatures through the seasons.

The curve of a hot control box is plotted in Fig. 153 and as one can notice it starts with an almost horizontal line which shows that the current is maintained constant up to a certain voltage then drops quickly.

The junction area between the two strips shows the operating limit between the voltage and current regulators.




Fig. 152. - Front view of the control box.

1. Current regulator armature ring; 4. Fixed contact support
57 - 6. Adjusting screw support No. 81-07-10. Terminal 5.

This regulation system takes full advantage of the generator output and maintains the battery at a good level of charging even after difficult or often repeated starts. Should the battery be discharged, it will be recharged with the maximum output current up to a high charge (28 V); and when the latter is exceeded (29.5 V) the voltage regulator intervenes to reduce the generator charge fall (electrical equipment off). When the battery is charged, the delivery current is reduced to a few amperes to prevent excessive electrolysis, overheating, insulator damage.

IMPORTANT

1. - The control box mod. GP 124/7 must only operate together with the generator mod. DC 119/24-7.3; this limitation is necessary for two reasons:

a) only the generators specified above can be overloaded at cold starting;

b) the control box has been designed to suit these generators and the field windings have been designed to suit the control box. Should the latter be connected to a different generator, the operation would be incorrect, the settings would change, the useful life of the contacts would be practically shortened and the generator would soon be put out of use.

2. - An incorrect connection of the control box terminal No. 67 with the generator terminal No. 51 produces immediately a strong sparking effect which oxidizes the contacts of the elements of the control unit; if prolonged longer it causes a




Fig. 153. - Regulation characteristics (volt-amperes) of the control box model GP 124/7 on the battery (curve plotted with data obtained at an ambient temperature of 50°-53°C., 120°-130°F and generator speed of 3600 rpm).

cause spark welding of the contacts. It is therefore absolutely necessary to connect terminals bearing the same number, keeping in mind that even if the wrong connections are corrected and the operation becomes normal again, the useful life has been nonetheless shortened.

3. - The control box should never undergo shocks of any kind, particularly the lower side which houses the resistances (Fig. 159).

During bench testing the box must be positioned with the terminals downwards, and with an insulator lying between the bench mounting and the base.

4. - The grounding connection between the control box and the tractor must be secure, otherwise there will be no regulation there being no current going across the shunt windings. In this case the generator voltage output which increases with speed (as it is not regulated) will burn the winding ends and deteriorate the voltage and current regulator contacts due to the excess of current across the field winding of the generator.

Bench testing - Instructions.

To check the performance of the control box mod. GP 1/34/7 start with the following operations without exceeding the ... V:

- place on the bench a generator model DC 115/24/73 (regardless of modification A, B, etc.);
- connect the generator to an electric motor the speed of which can undergo fine variations over a wide range and provide a 30 V battery;
- make ready the instruments and gauges necessary to the elements of the control box keeping in mind that dependable results are dependent upon the observance of the rules and procedure which will be given below.

Caution: The test must absolutely be performed at the temperature specified for each control and after at least 30 minute operation i. e., when the temperature condition specified has been reached. This requires a special oven suitable for the thermal stabilization of the control boxes. Tests performed otherwise will not give dependable results.

Cut-out relay check.




Fig. 154. - Electrical diagram of the arrangement for testing the cut-out relay contact closing temperature.

M. - Test bench electric motor - G. Generator DC 115/24/73 and its mod. 240 versions - V. Voltmeter, 30 V inc. range.

a) Contact closing voltage at $25^\circ \pm 10^\circ C$ ($77^\circ \pm 50^\circ F$) ambient temperature.

In surroundings with the temperature specified above connect the control box according to the wiring diagram of Fig. 154 and run it idle at 30 V for 15 to 18 minutes.

This preliminary operation allows the unit to reach the thermal limit allowing the cut-out short winding and the bimetallic spring blade to reach thermal stability after an initial period during which the voltage oscillates considerably.

Immediately after obtaining thermal stability, starting from an inertia generator, gradually increase the speed to check the voltmeter for the value of the cut-out contact closing voltage, which should read 23.5 to 25.5 V when the light goes on.

b) Reverse current (in ambient temperature of $25^\circ \pm 10^\circ C$ = $77^\circ \pm 50^\circ F$).

This test should be performed immediately after the contact closing voltage test, in order to keep the thermal stability reached in the preceding test.




Fig. 155. Electrical diagram of the arrangement for testing the cut-out relay return current.

M. Test bench electric motor - G. Generator DC 115/24/72 A and its modified versions - A. Ammeter - V. Voltmeter, 30 V (cc reading).

Hook up according to the wiring diagram of Fig. 155 and run the generator up to 3800 R.P.M., holding it at this speed for 5 minutes.

See that the voltmeter reads at least 22 V, then gradually decrease the generator speed. The ammeter indicator which had shown at first a certain amount of charging current, will gradually go to zero, then will show the reverse current on the opposite scale. As the generator speed gradually decreases, the reverse current will increase up to a given limit at which it will drop to zero (cut-out contacts open). Said limit represents the minimum reverse current value which should be 5 to 14 A.

Note. - To repeat the test, if necessary, begin from a stopped generator to avoid incorrect readings due to residual magnetism in the magnetic material of the cut-out.

Voltage regulator check

Regulation voltage on half-charged battery (ambient temperature of $50^{\circ} \pm 3^{\circ}$ C or $122^{\circ} \pm 37.4^{\circ}$ F)

Connect the group according to the diagram of Fig. 156 and operate it at $50^{\circ} \pm 3^{\circ}$ C ambient temperature for about 30 minutes, with a half-charge current output corresponding to 5 A.

Immediately afterwards, maintaining the box at an ambient temperature of $50^{\circ} \pm 3^{\circ}$ C stop the generator and run it again, at a gradually increasing speed up to 3800 rpm; adjust the rheostat so to set the generator half charging with a current of 5 A at 29.7 V.

Current regulator check

Regulation current on battery. This check must immediately follow the preceding one.

Connect the unit according to the diagram of Fig. 156 and connect the rheostat maximum resistance, operate the unit at $50^{\circ} \pm 3^{\circ}$ C ambient temperature for 30 minutes, at regulation current speed (to this end decrease the resistance of rheostat until the current remains almost constant and the voltage drops) and at the specified 26 V. At the end check that the output current has become stable (i. e., thermal stability has been reached); stop the generator and connect the rheostat maximum resistance, start it again and run it up to 2600 R.P.M.;

decrease the resistance gradually until the voltmeter indicates 28 V and the ammeter a regulation current of 5.6 to 7.4 A.

As the resistance continues to decrease the current should slowly rise, and the voltage drop sharply almost to 24 V.

Fig. 156. + Electrical diagram of the arrangement for testing the voltage and current regulators.

M. Test bench electric motor - G. Generator DC 115/24/72 A and its modified versions - V. Voltmeter, 30 V (cc reading).

A. Ammeter, 10 A (cc reading).




Fig. 156. + Electrical diagram of the arrangement for testing the voltage and current regulators.

M. Test bench electric motor - G. Generator DC 115/24/72 A and its modified versions - V. Voltmeter, 30 V (cc reading) - A. Ammeter, 10 A (cc reading).

Trouble-shooting.

The various cases which may occur during the operation of the control box are the following:

A - Low charging rate with a fully charged battery

This is the condition of a generator-control box system working correctly.

B - High charging rate with a fully charged battery.

This condition indicates that the voltage regulator does not limit the output as it should because a high charging rate not only damages the already fully-charged batteries, but also the equipment of the system. The causes are the following:

- high voltage regulator settings;
 - defective voltage regulator windings or additional resistance (7, Fig. 150);
 - short circuit across the generator positive terminal and field winding which prevents the current from passing through the regulation resistance at voltage regulator contacts opening;
 - insufficient connection between control box and generator through mass;
 - high temperature which reduces the battery electromotive force reacting to the charge, so that the battery absorbs a high charging current even if the regulator set voltage is normal;
 - self-welding of the voltage and current regulator contacts;
- In all the above cases, excluding case e), one of the two following conditions will occur on disconnecting the cable 67 from generator to control box:
- Output remains high (trouble covered by point c);
 - The output stops completely (the trouble lies in the control box which should be checked as to points a), b), c) and f).

Note - If the generator output remains high even after a long period of charging but neither trouble nor high temperature show up in the control box, the battery is old or maintenance wrong. It does not absorb any more current, the voltage does not rise above a certain value and the generator current does not decrease.

C - Discharged battery and high charge.

Condition of correct operation of the generator and control box unit.

D - Discharged battery and low or no charging rate

This condition is due to the following:

- burnt control box fuse - b) interruption of the additional resistance of the cut-out relay short winding (11, Fig. 159) - c) loose connections, defective cables - d) defective battery - e) charging system high resistance - f) voltage or current regulator low voltage setting - g) voltage or current regulator oxidized contacts - h) generator failure.

Should the above condition be caused by the failure of the additional resistance (11, Fig. 159) see acc. to:

If, on the other hand, it is caused by fuse failure, search for the cause of fuse burning before replacing it. The reason may be found among the following:

- the cut-out relay contacts do not open as the engine stops;
- short circuit;
- reversed generator polarity.

Finally, if the trouble is not due to one of the causes described at paragraphs a), b) and c), look for it in the battery, control box, or generator. To find out whether the trouble is due to the battery replace the old one with a new one discharged so that if the output still goes to the maximum evidently the fault is in the battery. If not, look for the fault in the control box or generator by shorting momentarily the terminal 67 with the 51 and increasing the generator speed. Should the output, previously absent or very low, either reach a set value or increase, the trouble is due to one of the following:

- low current or voltage regulator setting;
- current or voltage regulator contacts oxidized;
- undue resistance, interruption of the generator field winding or inside the unit.

Otherwise, look for trouble in the generator.

REPAIR INSTRUCTIONS

As a rule it is preferable to replace the control box rather than repairing or adjusting it, therefore only exceptional cases may justify handling it. The repairs which can be done, provided that it has been found for sure that it is the cause of trouble, are: replacing the cover, the additional resistances (7, 11, Fig. 159), the damping resistance (10), and the regulation resistance (6).

The spacers are furnished in special containers to avoid contacts with foreign material.

Most of the faults of the trouble, particularly the more serious ones such as excessive consumption or welded cut-out relay contacts, oxidized or pitted voltage or current regulator contacts, coil shorts and winding overheating, are due to faults outside the unit and particularly to the same faults of generator components (field winding resistance altered, wrong brushes, faulty cables, etc.).

Therefore, the repair man should not content himself by replacing the control box, which has anyhow a high factor of safety in operation, but rather check the generator and the whole charging system.

Cover replacement.

Should the replacement be due to bruises or warping we suggest to check the control box prior to replacement, according to the testing procedure of page 100 and following.

When replacing the cover check the seal gasket and place spring washers under the screw heads of the base, then tighten the screws until the two ends of the washers come in contact. Finally, apply a sealant on the head of one screw.

Replacing the regulation and damping resistances (6, 10, Fig. 159).

Here follow the causes and their respective consequences in case of wire interruption or shorts of the resistances (6, 10, Fig. 159):

- | | |
|---|--|
| a) control voltage low or very low; | e) oxidized voltage and current regulator contacts; |
| b) control voltage rising because out of control; | f) voltage regulator contacts stuck because of self-welding; |
| c) control current rising because out of control; | g) current regulator contacts stuck because of self-welding; |
| d) control voltage very unstable particularly at high generator speeds; | h) temporary sticking of the voltage regulator contacts. |

Paragraphs a), b), c) concern the control resistance, paragraph d) the damping resistance.

If still in doubt, replace these resistances which are fixed to the base by rivets. Drill the rivet head first then drive the rivets out with a punch paying attention not to damage the wires soldered to the plates (12 and 13, Fig. 149). To prevent the current regulator core from rotating while removing and replacing the resistances use tool A 127050 as shown in Fig. 157. The new resistances shall be fastened down with the screws, spring washers, and nuts specified for the replacement.

The value of the control resistance (R_1) is 135 to 144 ohm, that of the damping resistance (16) is 6 ohm. Check that the air gap between the armature and the expansion edge of the current regulator core (at position C-C of Fig. 149) is 0.99 to 1.11 mm (0.039 to 0.044"). To correct the air gap use tool A 127051 or the fixed contact support (4, Fig. 152) and check with a magnifying lens if the contacts are aligned correctly. The gap between contacts of the cut-out relay should be 0.54 to 0.75 mm (0.0216 to 0.030") and the air gap measured on the expansion edge of the core facing the contacts (Axis A-A, Fig. 150) and with contacts closed should be 0.25 mm (0.010").

Then follow test bench checks, reported on page 100, to ensure that the trouble has been completely eliminated and reassembly has not altered in any way the operation of the various parts.




Fig. 157. - Control box GP 1/24/7 with tool A 127050 installed to replace resistances 8 and 10. Fig. 158.

5. Spring setting, support tang




Fig. 158. - Rear view of the control box.
1. Cut-out relay armature hinge - 2. Setting spring - 3. Fixed contact support tang - 4. Setting spring, support tang
5. Ground.

Replacing the resistance on the voltage regulator shunt winding and the resistance of the current regulator and cut-out relay shunt windings (7, 11, Fig. 159).

If the voltage setting of the regulator has changed, that is:


- regulating voltage is low;
- regulating voltage rises to high values because out of control;

the cause can be attributed to the resistance of the voltage regulator shunt winding (7, Fig. 159) which can be altered (short) or interrupted.

A coil short increases the absorption on the part of the voltage regulator shunt winding (because the resistance is connected in series to said winding) and increases the pull on the armature resulting in a lower regulating voltage. Should the resistance be interrupted, the voltage regulator shunt winding does no longer get access to the generator but remains insulated.

Therefore, as the flow of current is interrupted the core cannot pull the armature, contacts do not close and the voltage, out of control, rises.

The resistance value is 73 to 77 ohms at 20° C (68° F). If the cut-out contact closing voltage is found to be low, or the contacts remain open even at high generator speeds, check the resistance (Fig. 158) to ascertain whether the cause must be attributed to altered value or to an interruption of the wire.






Fig. 160. - Electrical diagram of the arrangement for setting the output relay.

B₁, 24 V battery - B₂, 40 V battery - A, Ammeter, 20 A top reading (0.5% accuracy) - V, Voltmeter, 30 V top reading (0.5% accuracy, class 2) connected across terminals 51 and 51' - P, Potentiometer, voltage of 25 V; capacity must be such that the output relay shunt winding current consumption does not exceed double relays one of the no-load voltage measured by the voltmeter - S, Warning light indicating opening and closing of contacts (2 V-3 W bulb) - R, Rheostat 4 ohm - 20 A - R₁, Drop resistance sufficient to allow heating up of the warning lights - S by switch T₁ with the switch T₂ contacts open.

Voltage regulator setting.




Fig. 161. - Electrical diagram for setting the voltage and current regulators.

G, Generator DC 115/24/7.5 and 116 versions - V, Voltmeter, 30 V top reading (0.5% accuracy class) - A, Ammeter, 10 A top reading - R, Rheostat, 3 ohm-20 A - B, 12 V - 100 Ah batteries - connected in series, fully charged - T, Switch.

Current regulator setting.

Once thermally stabilized, bring the voltage to 26.1 to 25.9 V through potentiometer P; adjust the load on the calibration spring (3, Fig. 158) by bending its metal tongue (5) until the light S goes out;

bring potentiometer P setting back to the minimum; increase the voltage again acting once more on the potentiometer and check that the light S goes out at the specified setting.

The contact points entire closing stroke should occur at a voltage variation lower than 0.2 %

2) Reverse current (at a temperature of 20° ± 10° C = 77° ± 50° F).

This test must immediately follow the preceding one in order to take advantage of the thermal stability achieved by the unit.

With switch T closed, bring the voltage to 27.7 V by acting on the potentiometer P (the cut out relay contact points are closed and light S off); close switch T₁; increase the reverse current through the rheostat R, and check that the light S goes on when the contact points open. The opening may result in an unstable evidence only by a ringing noise;

check the ammeter reading of the reverse current which starts the contacts opening (5 to 12 A). Should the reading be uncertain or should the light go on the tolerance limit, bring the reverse current back to minimum and increase it again working on the rheostat R, as instructed before; open switches T and T₁ and bring the sliders of the potentiometer P and rheostat R back to minimum.

Provide the conditions suitable to maintain the unit at a temperature of 50° ± 3° C (122° ± 37° F).

After wiring the unit according to the diagram of Fig. 161, wind the adjusting spring of the current regulator by shaping the adjusting tongue (5, Fig. 152); close switch I, start the generator and stabilize the temperature of the unit, for 30 minutes, at 20° ± 10° C, by varying the generator speed;

open the switch I and bring the generator set to 3500 R.P.M.; adjust the load of the adjusting spring of the voltage regulator by bending the tongue and the rheostat R, so to obtain a regulating voltage and a medium charge current of 29.7 to 29.9 V and 5 A, respectively,

check stability and accuracy of the regulation voltage by stopping the generator and running it again up to the speed of 3500 R.P.M.

This test must immediately follow the preceding one, holding the test temperature at 50° ± 3° C (122° ± 37° F), and using the same instruments and the same wiring diagram (Fig. 161);

close the switch I, start the generator, adjust its speed and rheostat R to obtain a voltage and a current of 26 V and 6.5 to 7.4 A, respectively;

after 30 minutes of operation at the above conditions stop the generator and open the switch 1. Bring the generator back to a speed of 2500 R.P.M., adjust the load of the adjusting spring by acting on the tongue (5, Fig. 152), and the threaded R to obtain a regulating current and voltage of 6.5 to 7.4 A and 26 V, check the stability and the accuracy of the regulating current by stopping the generator and running it again up to a speed of 3000 R.P.M.

Performance check and sealing of the unit.

Once set, close the hot control unit with cover and gasket before it undergoes the bench test as from instructions of page 100 and following. Then put the paint seal or one of the cover fastening screw heads before returning it to the owner.

Overhauling or repairs must be entrusted to FIAT Service Shops only.

Whenever a control box is opened for overhaul or repair, operate it for a certain length of time without the cover on so that it will warm up and eliminate any residue dampness on its elements. Very

CONTROL BOX GP 124/T SPECIFICATIONS (*)

Description	Data	
Cut-out relay:		
- fixed current for thermal stabilization	> 30	A
- switch voltage	25.1 to 25.9 V	
- voltage variation for contact closing process	> 0.2	V
- reverse current	6 to 14	A
- air gap contacts closed (ex. A-A, Fig. 150)	0.26	mm
- gap between contacts (d, Fig. 150)	0.04 to 0.16 mm	0.005 to 0.030 in
Voltage regulator:		
- batteries capacity at 26 V	100	Ah
- average load current	5	A
- range of load after thermal stabilization at a room temperature of $20^{\circ} \pm 2^{\circ}$ C $(102 \pm 37^{\circ}$ F) for 30 minutes	26.7 to 26.9 V	
- rated voltage for thermal stabilization	> 30	V
- air gap (C, Fig. 149)	0.09 to 1.11 mm (0.002 to 0.044 in)	
Current regulator:		
- rated current on battery at $50^{\circ} \pm 3^{\circ}$ C ($122 \pm 37^{\circ}$ F) room temperature after thermal stabilization	5.6 to 14	A
- rated current check voltage	29	V
- air gap (D, Fig. 149)	0.09 to 0.11 mm (0.002 to 0.044 in)	
Resistors, Fig. 159		
- regulation resistance (S)	100 to 144	ohm
- damping resistance (D)	60	ohm
- additional resistance for voltage regulator (7)	13.5 to 17	ohm ²
- additional resistance for cut-out relay and current regulator (11)	15 to 27	ohm ²

Note: The generator check and adjustment speed is 3000 r.p.m.

(*) See data for modified groups under the following heading.

CONTROL BOX TYPE GP 124/T, MODIFIED (Dwg.no. 4085433).

The modified control box 4085433 differs from the previous type (4055383) as follows:

- the series and parallel windings of the cut-out relay are mounted in succession instead of being superimposed;
- the values of supplementary resistances for the voltage regulator (7, Fig. 151), cut-out relay and current regulator (11, Fig. 151) have been lowered from 73-77 ohms to 55.5 to 66.6 ohms. These resistances together with those placed under the case of the control box are not furnished as spare parts.

BATTERIES

Specifications and dimensions.

Tractors are equipped with two 12V batteries, capacity 56 Ah (measured at 20 hours discharge) connected in series, to reach the generator voltage of 24 V. The main battery characteristics are:

1. Connections, covered with mastic insulating material to prevent current dissipations and protect against corrosion the connections and the pole terminals.
2. Separators, for protection of battery lead plates from vibrations, made of extremely thin porous rubber, or of polyvinyl plastics.
3. Self-leveling and splash-proof plugs, allowing electrolyte self-leveling, and preventing its splashing from the vent holes, when tractor jobs in operation.

Sizes:

length . . . 368 to 372 mm (14.4902" to 14.6456")
width . . . 173 to 177 mm (6.8110" to 6.9685")
— height . . . 197 to 200 mm (7.7559" to 7.8739")

Battery makers:

- Marelli S.T.F. 5;
- Tiamo S.C.R. 4 F.

Weight (with electrolyte) approx. 24 kg (52.912 lb).

Cleaning.

Keep batteries clean and dry, particularly the upper parts, thus avoiding, especially after the recharge, the corrosion of the element sealing compound. Wipe terminals with pure vaseline, avoiding the use of lubricating greases as it reacts with sulphuric acid of the electrolyte (reduces or liquid).

Electrolyte level checking and top up.

Electrolyte should completely cover the element plates, and top-up them of about 3 mm (0.1189"). Distilled water only should be used for topping-up then make sure the plugs (A, Fig. 162) are fully tightened.

For longer battery life, avoid any contact between water and metallic containers.

Battery charge check.

Unscrew the plug, and introduce the hydrometer in each element; the specific gravity represents the battery charge conditions, as follows:

Electrolyte gravity	Condition of battery charge
1.25	100%
1.21	75%
1.18	50%
1.15	25%
1.13	nearly discharged
1.11	completely discharged



Fig. 162 - Batteries mounted on tractor.

A. Fuses of even control plug for water filling - C. Cover for level control plug.

Therefore a battery may be considered charged if the electrolyte gravity reads between 1.23-1.24 at 25° C (77° F). Avoid letting the battery to discharge completely; recharging should be made when gravity is not less than 1.15 (20° Br.). The recharging current rate should never exceed 5 A.

In order to maintain the battery charging within actual conditions the checks should not be made when:

1. the electrolyte is different from the prescribed one.
If distilled water is being poured in, take time to set a uniform distribution.
2. battery is hot, or immediately after repeated startings, or when electrolyte is cold. The most suitable temperature is between 15° and 25° C (59-77 F).

If the batteries cells have a specific gravity with differences exceeding 0.02 or high or low gravities, accompanied by excess of heat (more than 50° C - 60° F, above the ambient temperature), see the Service Organization of the battery supplier.

Discharge of battery during operation.

During operation, the batteries are not to be periodically recharged, as the tractor charging plant can maintain their efficiency.

When discharged (excluding after long tractor stops which cause battery self-discharge), the batteries indicate abnormal functional conditions. These may be traced to:

1. Faulty recharging system (generator, regulator group); see service instructions.
2. Current dispersion, due to insulation defects in the electric system. This may take place after heavy current draw due to the insertion of extra accessories. A rapid check is made by inserting a ammeter between battery positive terminal and its disconnected clamp, after having stopped the engine and excluded all equipment. The current rate should not exceed 1 millampere.
3. Extra accessories in addition to the standard ones installed by the manufacturer are dependent upon the electric system capacity.
4. Tractor short hauls, using high gears at low speeds and with frequent stops.
To maintain the generator at the normal recharging speed rate, use low gears when running at low speeds.
5. Sulphated battery; short circuited elements or interrupted.

Relitting and removing from tractor.

No difficulty should be met in installing or removing the battery from tractor; to avoid heavy discharges, be sure to disconnect the grounding cable, before working. In addition, use proper techniques, and never use tools to renew or to measure the terminals.

STARTING MOTOR

Specifications.

Type	FIAT E 115-324 Var. 2
Rated voltage	24 V
Rated output	3 KW
Excitation	compacted
Direction of rotation (station side)	clockwise

The starting motor mounted on tractors of series 400 is a direct current 4-pole motor with solenoid and free-wheel engagement pinion drive (Fig. 103).




Fig. 103 - Starting motor.

- 1. Remove-centre switch terminal - 2. Terminal for motor field coil - 3. Remote control switch - 4. Pole piece fastening screw - 5. Starter pinion - 6. Bolt for brush protection - 7. Thrust ball nuts.

Test bench checks.

As voltage, during tests, should be approximately constant, the starting motor shall be energized by large capacity batteries.

The specified voltages, applied to the motor terminals, shall determine the prescribed current drains through the setting of a rheostat. No result would be reliable if such conditions were disregarded, with the exception of the torque reading, and only approximately.

To verify the motor performance check the electrical and mechanical specifications as follows.




Fig. 104. - Electric diagram for bench test of starting motor.

- M. Starting motor - V. Voltmeter, 30 V (0-30); reading - A. Ammeter, 300 A, 100 reading - B. Batteries, 12 V, 100 Ah, connected in series, fully charged - R. Rheostat, carbon plate type, 1000 A, 100 reading - S. Switch.
- (a) Starting motor electrical diagram.

Checks.

Operational test (under load).

Checking motor torque when stopped

Idling test of motor.

Electromagnet run.

Motor internal total resistance.

Field coil resistance

Electromagnet coil resistance

Mechanical characteristics.

Guide for finding starting motor troubles.

Faults in the charging system may be localized either in the electric motor or somewhere else in the system. It is therefore necessary to localize trouble first in order to avoid a waste of time by looking for faults in the electric motor not being there or due to outside causes, as that road would be useless as trouble would repeat itself.

Therefore, if cranking is very slow or absent, the defect must be localized. To this end, as engine is stopped, the headlights can be used.

Comparatively scarce illumination can be traced to low battery charge, damaged cables, or terminals not tightened. Naturally, the check is made taking for granted that the headlight circuit and its components are efficient and without tension losses for poor contacts at the switches, halo-sockets, etc. It happens less often that the recharger plant is defective, and this may be ascertained through the regulator check. Anyway, the battery recharge, without having found out the causes, will not eliminate the trouble that will repeat.

Operations.

Wire up according to Fig. 164.

Use a test bench fitted with a ring-gear having a ratio between pinion and gear of about 1 to 10; make some startings of short duration, and check, by breaking the motor until a current of 255 A is reached that its torque is about 1.86 to 2.15 kgm (13.4 to 15.7 N.m) at 1510 to 1610 R.P.M., the voltage being 19 V.

Sync the test bench ring gear; switch on, and adjust voltage to motor terminals, so that it will absorb a current of 62.5 A at 12.7-13 V. The starting motor should then deliver a torque of 4.62 to 4.75 kgm (33.4 to 34.3 N.m).

Clear away the ring-gear, to prevent its meshing with the pinion.

Shut the starting switch and adjust the terminal voltage at 24 V.

Motor should then absorb a current not exceeding 39 A at 4000 to 5000 R.P.M.

The mobile contact of electromagnet should perform a run of 5.4 to 6.65 mm (0.252" to 0.335"); the stroke being of 3.5 to 19.1 mm (0.324" to 0.397").

The rest data of the motor when stopped allow calculating the motor total resistance, by the ratio between the voltage applied and the current. At 40°C (104°F) the resistance should be of 0.0025 to 0.0028 Ohm.

1) The main field coil resistance (in series), at 20°C (68°F) should be of 0.0055 to 0.0070 Ohm.

2) The secondary field coil resistance (shunted), at 20°C (68°F) should be of 1 to 1.14 Ohm.

The electromagnet coil resistance, at 20°C (68°F) should be of 1.36 to 1.45 Ohm.

See data on page 115

The battery being normally charged, and the starting motor operated, causes the following headlight behaviour:

- 1) No light: traced to poor connections between battery and motor, or corroded battery terminal nuts.
- 2) Considerable dimming as engine is started, and the latter runs slowly or stops:
 - a) excess of oil crankcase density;
 - b) armature shaft bearing bushes and support worn, and bearing shoe screws loose;
 - c) commutator damaged, series field coil or armature coils grounded or short-circuited.
- 3) Bright headlights, and starting motor cranking slowly or stopping:
 - a) loose terminals of the motor solenoid contacts oxidized or insulated by foreign matter intrusion, or damage of the excitation circuit and commutator currents;
 - b) poor or faulty brush contact on commutator.

Trouble-shooting instructions.

Item 1) of the preceding chapter increases the ohmic resistance between batteries and motor and may be measured by a voltmeter when motor is running.

The voltage drop measurements to be taken are as follows: between tractor body and battery negative pole; between tractor body and the electric motor frame; between battery positive pole and the solenoid terminal, where the battery feeding cable ends.

Such measurement should not give more than 0.1 V, when the starting motor is running.

However, if the voltage drop is excessive, disconnect the cables, clean the battery terminals and smear them with vaseline, to prevent corrosion.

Items 2) and 3) of the preceding chapter call for a commutator check for efficiency and the removal of the starting motor to perform its test with no load and when stopped (torque test).

The following causes may occur when such tests are being performed.

I - Force current and speed up to specifications.

I' - Low speed and torques with no load; high current drain: trouble to be traced to armature winding partly short-circuited or grounded; or to mechanical defects, such as worn out bushes, armature shaft bent, loose polar shoe screws.

A simple inspection may indicate that some armature turns are grounded, as the corresponding commutator blocks would be deteriorated by heavy current passage that would take place through the brushes.

III - Motor does not start and high current drain: might be caused by the armature or the field coil completely grounded.


IV - Motor does not start and no current drain or less than 24 A: no current drain requires checking the solenoid contacts on the commutator, and of the brush spring performance.

Very low current drain signifies that the field series winding is interrupted.


The solenoid winding insulation may be checked with a test lamp.

V - Low speed, with no load low current and torque, the fault may be traced to the internal resistance of the motor, or to commutator extended bars due to centrifugal force.


The first trouble is readily detected when the motor is dismantled, the second one may be caused by the free-wheel too hard to turn or by field coil connections unisolated from the commutator bars.



Sect. C-C - Longitudinal section.



Sect. A-A - Cross section on fork lever.



Sect. B-B - Cross section on commutator.

Fig. 155. - Sectional views on starting motor type E 115-1/24-VAR. 2

1. Start-up drive piston - 2. Fork lever - 3. Solenoid core - 4. Solenoid coil - 5. Solenoid terminal - 6. Fixed contact - 7. Commutator - 8. Armature - 9. Brushes - 10. Field coil - 11. Brush - 12. Overrunning clutch hub - 13. Overrunning clutch sleeve - 14. Solenoid core play ($0.5-1.0 \text{ mm} = 0.0197-0.0394 \text{ in}$) - 15. Solenoid mobile contact travel ($0.4-0.65 \text{ mm} = 0.0157-0.0256 \text{ in}$) - 16. Armature shaft end play ($0.35-0.75 \text{ mm} = 0.0138-0.0295 \text{ in}$) - 17. Solenoid terminals.

Motor disassembly.

The starting motor can be dismantled into the following assemblies: solenoid unit, commutator and bracket assembly, armature assembly, clutch assembly, pinion end bracket assembly, motor frame assembly.

Parts to be removed.

The solenoid.

Operations and cautions.

Remove the screws fastening it to the support, also the field coil end from terminal (2, Fig. 163), lift the solenoid assembly and take it away.

To dismantle it remove the upper cover (in order to disengage the coil end) and make free the neutral part of the solenoid body (3) from the screws fastening it to the support, and from the terminal rings.

To remove the solenoid coil core, remove the split pin and the mobile contact nut.

Commutator end head.

Remove the nuts and the screws fastening the head to the frame (7) and the protection strip (6), free the field coil leads connected to the brushes, and remove the complete head.

Pinion end bracket.

Slide it out from the frame with the armature; remove the pinion engagement control fork pivot and pull upwards the fork to disengage the pinion.

Free-wheel.

Remove split pin, unscrew the nut, remove the pinion stop ring, and slide the free-wheel hub. To strip the free-wheel, remove the spring cup stop ring, and slide out components; remove the ring fastening the wheel to the bell and carefully slide out the spindle, to prevent rollers and springs from falling out.

Starting motor trouble-shooting and component checks.

Brush replacement in the commutator is comparatively simple: use the springs and slide out broken or worn brushes. Use only original brushes supplied by FIAT - Sezione Ricambi, which ensure a long service.

Check the solenoid contact which, if oxidized or burnt, should be cleaned using emery cloth, then remove all metal and emery dust before reassembly.

If necessary, replace the solenoid and the starting motor field coils using original spares, without attempting to repair them or to wind a new coil, as good performance cannot be obtained by such means. After having tightened the coils under the polar shots, check that the air gap corresponds to specifications to facilitate the assembly worm so the windings to about 50°C (122°F).

Check commutator for out-of-round which should not exceed 0.02 mm (0.00078"); if necessary, and if the commutator bars have not been thrown out-of-round by centrifugal force, turn them down, then undercut the mica of 1 mm (0.030") using a saw blade.

Check armature conditions with the same device used for the generator and if grounded renew it.




Fig. 106. - Parts of starting motor clutch.

1. Clutch retainer - 2. Clutch rollers - 3. Push rod for clutch rollers - 4. Clutch hub

Reassembly instructions.

To reassemble the starting motor reverse the sequence used for dismantling.

Before assembling, clean armature and brackets with a strong air jet, and clean the commutator using a dry cloth.

Refit the free-wheel, and the starting plunger fork guides with high melting point grease; when assembled, before the test-bench checks, see that end clearance (C, Fig. 165) is 0.35 to 0.75 mm (0.0138" to 0.0295").

STARTING MOTOR PERFORMANCE DATA

	Specifications	Values
Operational test (under load)	current torque speed rate voltage	265 A 1.52 to 2.15 kgm (13.3 to 19.5 lb ft) 1510 to 1610 rpm 19 V
Checking motor torque when stopped	current voltage torque	620 A 12.7 to 18 V 1.62 to 4.75 kgm (13.4 to 34.3 lb ft)
Idling test of motor (under no load)	current voltage speed rate	30 A 14 V 4000 to 5000 rpm
Commutator oil-film thickness		0.09 mm (0.0035")
Pole shoe armature diameter		75.03 to 76 mm (2.984 to 3.000")
Armature outer diameter		94.96 to 95 mm (3.750 to 3.780")
Armenite total resistance at 60°C when supplied (at 40°C + 0.004 ohm)		0.0006 to 0.0016 ohm
Resistance of main field coil (in series), at 20°C (68°F)		0.0020 to 0.0070 ohm
Resistance of secondary field coil (shunted), at 20°C (68°F)		1 to 1.14 ohm
Solenoid energizing current at 24 V, (20°C + 20°F)		0.7 A
Solenoid solenoid internal coil resistance when heated		1.35 to 1.46 ohm
Lift force, with a current of 6 A and an air gap of 3 mm (0.118")		not less than 11 kg (24.2 lb)
Solenoid mobile contact travel		4.5 to 5.5 mm (0.177 to 0.221")
Solenoid case travel		5.5 to 10.5 mm (0.216 to 0.339")
Brush spring pressure (new brushes)		1.15 to 1.50 kg (2.52 to 3.38 lb)
Armature axial play (C, Fig. 165)		0.35 to 0.75 mm (0.0138 to 0.0295")

GLOW PLUGS

The glow plug consists of a thin wire helix, contained in an insulator and surrounded by a metallic shell, which is heated by the incandescent coil to 850°C (1562°F) through the regulator when energized by a 24 V current.

The glow plugs are short-circuited (nominal voltage 24 V, 140 W each).

Removal and cleaning.

Before unscrewing the plugs, free their terminals. Clean them with a metallic brush, wash in gasoline and blow them dry.

Checks on the test bench.

- Check the plug current absorption at 24 V (5.82 ± 0.2 A);
- Sealing. The plug is screwed in a seat similar to the one existing on the engine in a vessel the pressure of which can be raised to 30 kg/cm² (+20.70 psi.). Air tests, against the atmospheric pressure of 760 mm (29.9213") of mercury, shall not exceed 2 cm³ (0.1200 cu.in.) of air.

ATTACHMENTS


POWER TAKE-OFF

The power take-off assembly is located inside the transmission casing rear cover and may be actuated by a lever directly from the crankshaft or from the gearbox (through a gear installed on the bevel drive shaft, Fig. 81).

In the first case, the power take-off shaft runs at a speed proportional to the engine (575 r.p.m., engine running at 2300 r.p.m.), and in the other case the speed is proportional to the tractor forward travel (3.75 revolutions per meter of forward travel).

Major overhaul.

Removal.



Drain differential and gearbox oil.

Set the control lever for engine drive and remove the screws fastening the rear cover to the transmission casing (Fig. 168).

Note. If tractor is fitted with hydraulic lift, there is no need to remove it, we suggest, instead, to remove the half-pulleys transmission cover, if mounted, to simplify the assembly.

Mount the assembly on rotary stand ARR 2204 (key Fig. 167).

Fig. 167. - Cover-rear transmission, with power take-off, mounted on rotary stand ARR 2204.




Fig. 168. - Power take-off assembly, stripped.

- A. Driving shaft components.
- B. Driver shaft components.

Dismantling.

See A, B, Fig. 108 representing the disassembling sequence of the various components from their seats.

Inspection of components.

Check gear teeth and shaft and hub splines conditions.

The power take-off driving shaft sliding gear can be checked and also disassembled by removing the transmission casing upper cover.

Check the bearings for smooth running and the power take-off driven shaft oil seal conditions.

See page 118 for main assembling clearances and permissible wear limits.

Assembly.

Reverse the dismantling sequence.

Note. - To fit the power take-off driving shaft into the sliding gear hub, turn the power take-off driven gear by hand

BELT PULLEY

The belt pulley assembly is mounted in place of the power take-off cover (Fig. 81) and may be set with the pulley either on the right or left side according to the required direction of rotation. In both cases the vent should be mounted on top and the drain plug at bottom (Fig. 109). If necessary, interchange the position of the parts.

The unit is controlled by the power take-off lever shifted into «MOTORE» (engine).

Major overhaul.

Dismantling.

Drain lubrication oil, remove the pulley from drive shaft end, and take away the capastic end cover, remove the snap ring from the driving shaft support, and hammering on a bronze punch from the inside, remove the shaft and all its parts.

The roller bearing outer race, if necessary, is removed from its seat after taking away the snap rings; from the pulley driven shaft remove the nut and its split pin and, using a bronze punch, push out the driven shaft.

The roller bearing outer race and the ball bearing remain in their seats, and may be removed after taking away the snap rings.




Fig. 109. - Belt pulley unit

Checking all components.

Check bevel gears and shaft splines according to table of page 118.
Check bearings for correct functioning and shaft seal for oil leaks.

Reassembling and adjusting the pulley assembly.

Refer to Fig. 170 and reverse the sequence followed for dismantling.

Bevel pinion and wheel adjustment made by varying the shim ring P of driving pinion and shim ring L of bevel crown gear.

The suggested clearance for bevel pinion and wheel is of 0.15 mm (0.0059"), and should be obtained by varying the L and P shim ring thicknesses.

Service with SAE 140 oil the belt pulley assembly until level reaches the plug located on the cover opposite to the source.




Fig. 170. - Belt pulley unit section.

L. Bevel gear adjustment shim.

P. Bevel pinion adjustment shim.

SPECIFICATIONS, ASSEMBLY CLEARANCES AND PERMISSIBLE WEAR OF POWER TAKE-OFF AND BELT PULLEY COMPONENTS

Assembly clearances	Data		Wear limits	
	in.	mm	in.	mm
Take-off gear backlash	0.10 to 0.20	0.0009 to 0.0025	0.4	0.0797
Between driving gear splines and power take-off control shaft	0.010 to 0.015	0.0254 to 0.0381	0.05	0.0026
Between gear splines and power take-off driven shaft	0.020 to 0.022	0.0050 to 0.0055	—	—
Belt pulley overall backlash	0.12	0.0039	0.4	0.0157
Between driver gear splines and pulley shaft	0.024 to 0.029	0.0061 to 0.0074	—	—
Belt pulley gear adjustment shims	18-18-0-0709-0-0787 0-CR55-0-0545	—	—	—

HYDRAULIC LIFT




Fig. 171 - Hydraulic pump mounted on tractor.




Fig. 172 - Hydraulic lift mounted on tractor.
A. Lift control lever • B. Selection lever (position control requires the lever to be shifted down) • M. Spring for selector shaft.

Hereafter are the main components of the lift mounted on 411 R tractors:

- A gear hydraulic pump, driven by engine timing gears (Fig. 171);
- a lift, with integral oil tank composed of a ram (simple effect) acting through a ball-headed link on a lever keyed on the lifting arm shaft;
- a three point implement hitch, adjustable with a screw controlled by a hand wheel on the right side, allowing the cross adjustment of the implement position (Fig. 187);
- a control valve, optional, to be applied in place of the control valve cover for supplementary attachment control (Fig. 188).

HYDRAULIC PUMP

$P_{\text{out}}/P_{\text{in}} = 0.8X \quad \eta_{\text{hyd}}$

The hydraulic pump needs no maintenance, checking or adjustment even after long operation. This is due to the fact that clearance between the gears and bushes is taken up automatically by the oil pressure.

The bushes have their side facing the delivery fitted with a skirt (f. Fig. 173), which the oil crosses through to act upon a surface recessed on the two covers and defined by two rubber gaskets shaped as a heart, and laid eccentrically (2).

Pump general overhaul.

See Fig. 173 for the disassembling and assembling sequence of the hydraulic pump components. The explanations of the preceding paragraph should facilitate a correct assembly and disassembling; sense of rotation of the drive shaft is indicated on the pump cover.

In addition, notice that assembly and disassembly require no special tooling as the high finish of machined surfaces would be damaged by a careless assembly.

Never disassemble a hydraulic pump if original spare parts are not available; if repairs are necessary entrust them to FIAT Service Organization.

We give below the specifications of the hydraulic pump, to check its performance:

— ratio between engine and pump R.P.M.	1,162
— pump speed (with engine at rated speed, 2300 R.P.M.)	2,000 R.P.M.
- pump rotation, as viewed from driving shaft end	clockwise
— suction head	± 300 mm (± 11.8110")
— deliveries (oil at temperature \leq at 0 kg/sec.cm (0 p.s.i.)	12 liters/min (3.75 Imp.gal.)
of 60° C (140° F)	at 150 kg/sq.cm (2163.5 p.s.i.)
	16.5 liters/min (3.65 Imp.gal.)
— pressure valve opening pressure (marked C or E)	145-155 kg/sq.cm (2082-2205 p.s.i.)

To secure a good performance of the lift hydraulic pump, use exclusively SAE 20 hydraulic oil avoiding all mixtures.

The customer shall be warned that periodical checks and cleaning of the hydraulic lift oil filter is absolutely necessary. After the first 20 hours from any oil change clean accurately to remove dirt from the filter.




Fig. 178. - Hydraulic lift pump components.
1. Shaft bushes - 2. Pump cover - 3. Delivery port.

HYDRAULIC POWER LIFT OPERATION

The power lift consists performing two different operations, position control and draft control. To choose either one just move lever B (Fig. 172) downwards in the former case and upwards in the latter.

The lever can be activated only when the lift arms are raised.

The lift arm raising or lowering control is performed by lever A. In the position control operation, at every position of lever A corresponds a different height of the lift arms, and consequently of the implement. In the draft control operation most of the excursion in the quadrant is used to determine the draft of the implement during work.

Whenever lever A is moved, the control valve spool rotates and according to its sense of rotation lets oil pass in different conditions through the valves of the hydraulic circuit which control the raising or the lowering of the arms. In the position control operation, the height of the arms can be controlled through lever A only, while in draft control also intervenes the reaction force which the implement passes on to the spring M, Fig. 176. The deformation of the latter transmits the rotation of the control valve spool, (the strain of the spring being transformed by a lever mechanism) and consequently a movement of the arms which brings the resistance encountered by the implement in the ground back within the limits established by the position of the lever A in its sector.

In position control operation the selector lever B, acting on the relative position of levers and rockers of the linkage cuts off the control valve spool from the effects of the strain set by the implement on spring M.

Fig. 176 illustrates the hydraulic diagram of the system. For further details on the power lift operation see the Technical Information Bulletin, Form No. 324 '92.




Fig. 174 - Axial control shaft section.
1. Cylinder discharge valve - 2. Left arms bearing shaft - 3. Shaft bushings - 4. Through part in the control shaft - 5. Control screw - 6. Tensioning screw - 7. Left arms - 8. Control screw adjustment screw - 9. Linkage control lever.








Fig. 175 - Sectional view of the hydraulic lift unit.
1. Cylinder pressure safety valve - 2. Piston - 3. Left arm piston - 4. Arms main lift releasing screw - 5. Spring adjusting screws - 6. Lever - 7. E. P. F. g. n. Ref. Fig. 176
(The arrow indicates the leather washer placed between the piston and the cylinder or lift arm is up to No. 6588).
a) Sectional view of the cylinder pressure valve.
2. Lift control valve - 3. Cylinder safety valve - 4. Groove machined along the control valve sole to discharge the air, the pressure of which is on valve (2) caused by acting on the rod of 1 - E. Centre screw.




b) Detail of section through top control shaft:
- 1. Control shaft - 2. c) Sectional view of the piston of the hydraulic lift No. 6588 and up - d) Bearing from 140-02100 us (Aug 1962) the number of the unit bearing has been removed from 6 to 4.






S. Active lifting.

The control valve P is rotated so to let oil pass from the pump onto the top of the left side of valve cylinder 2, causing its closure. The pump suction oil can flow down in the cylinder through valve 5 and directly into piston 3, lifting it up.



F. Active lowering.

At each of the piston moves, the control valve P rotates again returning to the lower position through levers F, E, D. The rod connections are unchanged except the cylinder pressure which kept the valve 2 closed by valve 5 on the top in discharge. The oil moves through the piston valve 3 to open and the oil flow is conveyed into the suction instead of the cylinder.



A. Active lowering.

To lower the piston, the valve pump opens by connection the discharge valve (5), which allows the oil to follow towards the tank under the pressure of the filter.

Fig. 576. - Working diagrams of the hydraulic system for different arm positions

(Note: The oil flow pattern in the circuit is identical both for position and draft control direction) - 1. Pressure relief valve - 2. Control valve - 3. Cylinder safety valve - 4. Cylinder discharge valve - 5. Cylinder intake valve - 6. Link - 7. Rocker - 8. Valve link - control lever - U.V.Z. Top link mounting holes. Starting from 1970/2000 on the number of holes has been increased from 3 to 4, see Fig. 170.




Fig. 177. - Removing the arms lifting shaft (the arrow shows the direction of extraction).
21. Screws which fasten the levers on the index arm - 2. Linkage control lever.




Fig. 178. - Removing the valve block.

11. Valve block - 12. Linkage control lever - 13. Control pins connecting the lever to the control valve lever - Q. Set screw connecting the control lever to the control valve - R. Access cover for removing screw R (see Fig. 182) - S. Control valve adjustment plate

Dismantling the power lift.

To remove the unit from the tractor separate the arms from the implement hitch. First, then disconnect the two oil lines and remove the screws which fasten the unit to the transmission housing. To dismantle the power lift proceed according to the following sequence:

Components to be removed.

Fitter (11, Fig. 183).

Outside Intake (12).

Cover (13).



Operations and captions.

Pull the parts out the lift box.

Remove the complete assembly from it from the lift box and setting support.

Can be removed together with the spring support.




Fig. 184. - Undoing the auxiliary equipment control lever screws.

Fig. 179. - Cylinder discharge valve parts.
1. Pump.




Fig. 185. - Testing apparatus for safety and pressure relief valves, using valve holder A 197032/A/B.

Arms control shaft.

Remove the left outer arms, the screws which fasten the levers to the inner arm (21, Fig. 177) and slide the shaft in the direction shown by the arrow.

Note. - To prevent damaging the seal ring located on the left end of the arms control shaft move the shaft about 2 cm (85/90°) in the sense opposite to the arrow and remove the ring (Fig. 177).

The inner arm with its piston striking strut remains inside the power lift.

Control valve (Fig. 178).




Fig. 178. - Left outside and inside control linkage

The illustration shows on top, the outer linkage removed from the lift below, the inside linkage placed according to:
A. Lift control lever • B. Selector arm • C. Lever arm • D. Control spool • E. Screw securing the control lever to the screw • F. Screw securing the lever L to the rocker

Remove pin (9) which fixes the valve spool control lever to its link prior to sliding the whole unit off the studs.

Note. - The following components remain fixed inside the power lift:

- the lever mechanism which is removed by unscrewing the screw (R) first and sliding off the outer lever (L) in a second time;
- the piston and barrel. The latter can be slid out the front by applying a slight force.

The valves can all be disassembled easily enough as they all are accessible from the outside, with the exception of the oil inlet into the power cylinder valve (8) which requires removing the control valve group. To disassemble the control valve slacken the screw which fixes the control lever (Q), remove the adjusting plug (t) and the side cover of the control valve for auxiliary equipment (Fig. 180).

Fig. 183 shows the power lift subassemblies in the dismantling sequence and Fig. 182 the outside lever mechanism (above), and the inside lever mechanism connected as they are during operation (below).

Inspection of components disassembled from the hydraulic lift.

After dismantling the power lift unit check the following:

- check conditions of the gasket between barrel and housing and between piston and barrel;
- check the play between the arms control shaft journals and the bushings; if found exceeding the values specified on the table of page 130 replace the bushings;
- check that the play between the control valve spool and its bore lies within the specified limits.
Note that the valve spool is not furnished with a stop as a spare, but always together with the valve block being fitted to the bore;
- ~~wash~~ replace the oil filter cartridge, if found defective, and make sure that the filter outlet plug is well seated to the plate for cartridge protection to prevent extraction on the part of the hydraulic pump;
- replace the oil seals for the lift arms shaft and the gaskets of covers,堵头 and valve seats if they are not deformable;
- check sealing characteristics of the discharge valve and of the lift control valve (4, 2, Fig. 180), grind the seats if necessary and check spring performance;
- check the setting of the pressure limiting and safety valves by means of a hand pump equipped with valve carrier A 197032/A/B, Fig. 10f. If data do not correspond, replace the valves, as component parts are not furnished separately as spares.




Fig. 183. Exploded view of the barrel assembly.

2) Exploded view of the auxiliary control valve. Pressure relief valve is shown open.

Power lift assembly.

Reverses the effect of dismantling and takes away

- when placing the inside and outside arms on the control shaft make their respective stamped marks to register (see Fig. 184);
 - the installation of the seal rings on the arms requires using the protection A 197003/A first, in order to prevent contact with the teeth of the shaft end, and then the use of the punch A 197003/B (Fig. 185);
 - the screw which fastens the control lever in the control valve assembly (Q, Fig. 192) should be mounted on the piston side.

Power lift adjustment

The adjustment of the power (4) should be carried out by placing the unit on the tractor or on the bench # 495005 which is equipped with the necessary weights.

- a) Control valve speed adjustment** -- Run the engine to high idle speed, then raise the lift arms, and place the selector lever on position control (downwards). Remove the cotter pin and slowly screw in the adjustment plug (t. fig. 196) until the load starts oscillating (vertical oscillation); or screw the plug half a turn and fit the cotter pin.




Fig. 184. - Register marks for filling the inside and outside arms onto the control shaft.




Fig. 185. - Lift arms control shaft seals fitting.
A = A 153003 A, P, rev. - B = A 157003, B, Prod. rev.

b) Arms stroke adjustment. — Start the engine and check that the stroke of arm ends of the implement hitching device (with the links connected in the holes as shown in Fig. 187) is from 530 to 630 mm (22-7/16" to 25-5/16"). If the stroke length does not lie within the above tolerance, act on screw 10, (Fig. 189) by means of spacers.

Note that when the implement hitching device arms are at their highest position there must be a margin left, which is controlled by raising by hand the lift arms.

c) Adjustment of the distance between the oil cover and strut support. — Whatever parts have been replaced (spring, strut support or oil cover) or after a major overhaul check the following:

- 1) Remove the strut and check that distance E (Fig. 190a) is 15 ± 0.5 mm (0.590" \pm 0.02"). If otherwise change one or two spacers H between spring end and support. Note that it would not be equivalent to use a large number of spacers H to decrease the clearance E because that would vary the load and conditions of the spring M.




Fig. 186. - Valve block.

1. Pressure relief valve - 2. Lift control valve - 3. Cylinder pressure safety valve - 4. Discharge valve - 10. Lift arms stroke adjusting screw - 11. Control spot adjustment plug.




Fig. 187. - Hydraulic lift linkage installed on the tractor.

1. Left link, adjustable - 2. Removable pin - 3. Fixed pin - 4. Left lifting rod - 5. Check chain - 6. Left lever bar - 7. Snap pins - 8. Right lever link - 9. Levelling lever - 10. Top link mounting pin.

(See also, mounted drawbar assembly on page 129)




Fig. 188. - Adjusting the top link supporting spring tension using tool A 197016.




Fig. 189. - Hydraulic system pressure reading using a pressure gauge with fitting A 197035 mounted in place of the safety valve.

- 3) Install the lever A 197016 in the mounting holes (Fig. 188) and by pressing downwards take up completely the clearance existing between cover and support at the lower stop shown with an arrow (2 Fig. 190 a). In these conditions, the distance I should measure 28.5 ± 0.5 mm (0.885 ± 0.02). A greater distance means that the surfaces of the lower slot are worn and need added material. The distance (in cases 1) and 2) of Fig. 190 a can be checked using the two ends of the "Go-No-Go" gauge C 197015.
- 4) Adjusting the play between roller and sector (Fig. 190 b). - Move the lift control lever to the highest position in the sector slot to get full raising of the arms, and place the selector lever in drain control (upwards); apply the lever A 197016 to the mounting holes of the slot to its supports so as to completely take up the play existing between cover and support at the lower stop; in these conditions the distance between cam and follower should measure 1.5 to 2 mm ($1/16$ to $5/64$). If necessary, the distance can be corrected by rotating the eccentric on which the follower is mounted.

Note. - Should the working pressure of the lift hydraulic system need checking, place a pressure gauge with fitting A 197035 in place of the safety valve as shown in Fig. 189.




Fig. 190 a. - Setting the clearance between lift cover and top link mounting bracket.

- 1) Setting the clearance 14.5 to 15.8 mm (0.57 to 0.62 in) between cover and top link support bracket, using fit tool A 197016.
- 2) Setting the clearance 1 (25 to 28 mm = 0.985 to 0.905 in) between cover and top link support bracket, using fit tool C 197015 being tested.
- 3) Adjusting arms + M. Top link support bracket being. Clearance indicated in sketches 1 and 2 of Fig. 190 must be considered as a practical working dimension, for height units the clearance is 14.8 to 15.1 mm (0.580 to 0.594 in) and 29.2 to 29.5 mm (0.073 to 0.096 in) respectively.




Fig. 190 b. - Adjusting the clearance between cam and roller.

- A. Lift control lever - B. Selector lever - C. Reaction roller - D. Lift arms - E. Lock to apply to the support bracket to take up the play existing between the cam indicated by the arrow.

Important

To be sure to make the best use of the power lift in every circumstance, read the following instructions.

Position control operation.

Move lever B (Fig. 190 b) downwards and insert the strut support wedge as shown in Fig. 192. In these conditions the holes of the support shown in Fig. 176 can be used to mount the top link.

Draft control operation.

Move lever B upwards (Fig. 190 b) and take the wedge away from the strut support (Fig. 192). For a more sensitive operation use the intermediate holes but not for implements which bear heavy loads on the strut (rippers, disc claws etc.) which require the use of the lower holes. Exceptionally, and only for very light work requiring high sensitivity, use the top holes. Never mount the top link in the top hole for all other cases in order to avoid excessive stresses on the setting.




Fig. 191. - Sectional view of the hydraulic lift linkage rods
B, Right lifting rod. C, Left lifting rod.

AUXILIARY COCK

The hydraulic power lift can be equipped with a control cock unit in place of the control valve cover in order to actuate attachments controlled by hydraulic power cylinders, both single and double acting. This attachment is not controlled by the lever which determines the raising and lowering of the arms, but rather by a lever which is part of the control cock lever. This makes the two operations independent.




Fig. 192. - Top fair support bracket wedge.
1. In - 2. Oil.





Fig. 193. - Auxiliary oil reservoir installed on the left fender and supplying a single-acting cylinder.
1. Breather - 2. Filter plug - 3. Bypass - 4. Control valve.


from each cylinder and allows using the same oil contained in the lift unit. The two different types of operation cannot function at the same time. Should the application require more than 2 to 2.5 liters (1-3/4 to 2-1/4 imp. quarts) of oil, an auxiliary oil reservoir must be added. Fig. 193 shows the installation of an auxiliary oil reservoir with a capacity of 9 liters (5 imp. quarts) for actuating a power cylinder with a max. capacity of 11 liters (3.6 imp. quarts).

The auxiliary oil reservoir is connected to the hydraulic power lift unit through a tube fixed to the breather plug by means of a fitting. The plug is then installed on the auxiliary reservoir. Check all the seals before installing the reservoir to prevent leakage due to the higher pressure head. The control valve block shown on Fig. 190 and 193 is installed on the power lift unit in place of the control valve block cover. From the latter it is possible to recover the gasket and the complete pressure valve which can be installed in the new unit.

The operational diagrams for single and double acting cylinders are shown on Fig. 194.



Hydraulic diagrams showing the control of oil for double acting cylinder.



Hydraulic diagrams showing the operation of single lifting or haul.

Fig. 194. - Diagrams showing the operation of the control valve connected to single and double-acting cylinders.
4. Pressure relief valve - 5. Control valve pin - 6. Double-acting cylinder (not filling) - 7. Plug (16 AISI + 1.5 to be used after one stop stroke valve cylinder) - A. Stop position - B. Lifting position - C. Lowering position.

HYDRAULIC LIFT ASSEMBLY DATA

Description	Dia. mm (in)	Assembly clearances mm (in)	Wear limits mm (in)
Inside diameter of cylinder sleeve	25,085 to 26,017 (3,3474 to 3,3493)		
Diameter of piston	34,955 to 35,006 (3,3451 to 3,3463)	Inside diameter of cylinder sleeve and piston	0,055 to 0,115 (0,0014 to 0,0044) 0,25 (0,010)
Inside diameter of bushings on arm control shaft (1):	55,000 to 55,170 Right end : (2,1592 to 2,1721) Left end : (1,9545 to 1,9671)	Arm shaft and bushings:	
	47,000 to 47,170 (1,8642 to 1,8769)	Right end : 0,130 to 0,209 (0,0099 to 0,0072) Left end : 0,100 to 0,145 (0,0039 to 0,0056) 0,25 (0,010)	
Diameter of arm control shaft and bushings:	54,270 to 55,000 Right end : (2,1642 to 2,1656) 46,975 to 47,000 Left end : (1,8495 to 1,8501)		
Inside diameter of bushings to power support lever (press-fit in bushing bo.)	12,045 to 12,055 (0,4730 to 0,4740)	Inside diameter of bushings and the diameter of the lever pin	0,015 to 0,108 (0,0005 to 0,0034) 0,15 (0,005)
Diameter of draft control lever pin	11,845 to 11,860 (0,4614 to 0,4624)		
Inside diameter of oiler and oil control lever bushings (press-fit bo.)	10,030 to 10,035 (0,4007 to 0,4050)	Inside diameter of power lever bushing and their pins	0,002 to 0,122 (0,003 to 0,0240) 0,05 (0,002)
Diameter of roller (1, Fig. 150) & oil control lever (1, Fig. 152) pins	11,905 to 12,000 (0,4714 to 0,4724)		
Thickness of lever discs for oil control lever	3 (0,076)		
Thickness of spacer for lever disc adjusting screw (1, Fig. 155)	0,45 to 0,55 (0,018 to 0,022)		
Inside diameter of bushings press- fit into the upper link bracket (2)	26,070 to 26,080 (3,3337 to 3,3351)	Bushings and upper link bracket hinge axis	0,000 to 0,180 (0,000 to 0,005) 0,5 (0,020)
Diameter of upper link bracket hinge axis	26,000 to 26,042 (3,2845 to 3,2883)		
Valve spring specifications		Safety (cylinder)	Control (lift)
Free angle	10° (6°)	35 (1,40)	45 (1,67)
Compressed length	100 mm (in)	37 (1,45)	50 (1,96)
Test load	4 kg (lb)	25 to 28 (55 to 64)	1 to 10 kg (2 to 22)
			1 to 4 kg (2 to 8)
Opening pressure of oil relief valve (1, Fig. 150) (marked with letter C or E)	155 to 165 kg/cm ² (2,229 to 2,295 lb/in ²)		
Opening pressure of cylinder safety valve (3, Fig. 150)	155 to 165 kg/cm ² (2,229 to 2,295 lb/in ²)		
Discharge valve (4, Fig. 150) to control valve body wrench torque	9 to 10 kgm (25 to 72 ft-lb)		
Cylinder safety valve (7, Fig. 150) wrench torque	4 to 5 kgm (28 to 35 lb-in)		

(1) Bushings are fitted into their housings in the lift casting with an interference of 0,000 to 0,120 mm (0,000 to 0,005 in).

(2) Bushings are fitted into their housing with an interference of 0,05 to 0,23 mm (0,0020 to 0,0091 in).

100 Tightening torque on valve bodies

Relief valve cylinder (3 Fig. 150) 4 1/8 to 5 kgm (29 to 36 ft-lb)

Relief valve (1 Fig. 150) 9 to 10 kgm (65 to 72 ft-lb)

HYDRAULIC LIFT SYSTEM FAULT TABLE

FAULT	POSSIBLE FAULTS	ACTIONS REQUIRED
Lift fails to operate.	1) No oil. 2) Control valve sticking. 3) Hydraulic pump does not work.	Top up. Dismantle and clean it. Overhaul the pump.
Lift jolts.	1) Oil level very low 2) Oil filter clogged up. 3) Air bubbles in suction ducts.	Top up. Clean it. Check fittings and seals.
Lift does not hold the load in raised position (when the engine is running, the load keeps on oscillating up and down; when the engine is stopped, the load drops).	1) Faulty adjustment of valve screw. 2) Faulty sealing or sticking of discharge valve. 3) Oil inlet valve of hydraulic cylinder leaks. 4) Oil leaks past lift piston seal or cylinder seal. 5) Cylinder pressure relief valve leaks. 6) Discharge valve seals damaged.	Readjust the valve screw as specified on page 128. Dismantle and check the parts involved; assemble the valve tightening the plug with a torque wrench set at 9 to 10 kgm (65 to 72 lbf ft) in order to avoid possible distortions. Dismantle and check the parts involved. Replace them. Replace it.
<i>Not sufficient pressure to raise lift arms.</i> <i>See Sec. lifting arms.</i>	1) Pressure relief valve cut-of-adjustment. 2) Cylinder drainage relief valve cut-of-adjustment. 3) Low pump efficiency (*).	Check settings. Replace it. <i>(Force loading 24% self weight)</i> Test pump performance and overhaul it, if necessary.
Pressure relief valve cuts in when lift arms are all raised e.g. fully.	1) Lift arm stroke adjustment screw cut-of-adjustment.	Take a few turns from underneath the screw head (see paragraph <i>c b</i> of lift adjustment on page 128).
Traces of engine oil in the hydraulic fluid	1) Oil leaking through between hydraulic piston and seal.	Check the parts involved and replace the damaged ones.

(*): Usually accompanied by a considerable increment of the force required to raise the load.

TOOL LIST

Tool No.	Description	Page No.	Fig. No.
A 001932	Hammer, brass	56	
A 5717	Screw stand, pump assembly	39	
A 11401	Grinder, engine valves	13	
A 12231	Hose pump	38	
A 12703	Adaptor	36	
A 18177	Dial gauge	40	
A 117019	Wrench, injection pump timing	43	
A 117052	Wrench, engine timing	46	
A 117063	Pivot tool	46	
A 115066	Bushing	56	
A 127050	Gauge, control box setting	47	
A 227551	Gauge, control box setting	101	
A 137003	Adapter, gearbox primary shaft	704	
A 137012	Ramps, bevel pinion setting	67	
A 581614	Lock, final drive gear	68	
A 197002-A/B	Driver and protector	70	
A 197013	Lever	125	
A 197022-A/B	Valve holder, valves in oil	127	
A 197035	Piston	124	
A 217028	Valve spring compressor	127	
A 217030-A/D/C/O/G/F/G	Cutters etc., suitable set, for valve seat grinding	12	
A 217072/A/B	Driver cylinder liner removed and installing	11	
A 287004	Puller, injection pump case	36	
A 287013	Adapter set, differential lower bracket	36	
A 313030	Driver, valve guide removal and installing	27	
A 323009	Pulser, injection pump plungers	24-38	
A 323010	Wrench set, injection pump adjustment	40	
A 325023	Support, injectors	40	
A 328025	Puller, injection pump shaft bearing	44	
A 328028	Pulser, pump bearing outer race	25	
A 328037	Caliper force, injection pump retainer	37	
A 329033	Tool, injection pump keeper removal and installing	25-36 39	
A 329044	Screw driver	36-38	
A 429572	Measuring set for control rack lever	34	
A 513007	Wrench set	51	
A 561031	Wire brush	12	
A 587002	Compressor, injection pump plunger stroke check	12	
A 587005	P.let., injection pump delivery valves	49	
A 587015	Connection set with pressure gauge, injectors and pump element check	36	
A 527103	Pulser	30	
A 711195	Wrench	34	
A 819008	Clamp piston rings	28	
A 819022	Piston piston rings	16-20-45	
A 619027	Pulser, pilot bearing in flywheel	18	
A 711033-A	Fixtures, main clutch disassembling and reassembling	54-55-56	
A 711109	Wrench	66	
A 711120	Spring tester	66	
A 735208	Puller, steering arm	14	
A 823251	Driver, gearbox	13	
A 830763	Driver, gearbox	59	
ARR 2201	Rotary stand, medium size	58	
ARR 2216	Rotary stand, large size	59-65-70-119	
ARR 2221	Sliding set for rotary stand ARR 2204	65	
ARR 177004	Sliding set for engine installation	65-70	
ARR 117005	Engine lifting hook	645	
C 680	Dial gauge, with stand	46	
C 687	Dial gauge set	29	
C 731	Gauge blocks	11	
C 192219	o.D.-o.gauge gauge	29	
C 537023	Fixture, connecting rod alignment check	122	
C 879012	Ring gauge, for setting dial gauge C 687	46	
C 295005	Bench, hydraulic lift	116	
C 0321	Piston, reverse shaft bush	41	
C 0381/A/B	Reinforcement, engine	61	
C 217017	Expansion reamer	14	
C 350039	Reamer, valve guides	17-19	
C 223034	Hammer, pump rack bushing	14	
C 616914	Expansion former	57	
C 616915	Expans. oil reamer	66	
		74	

E




Fig. 135 - Front and side view of tractor 415 R.




Fig. 136 - Rear and side view of tractor 411 R.

SPECIFICATIONS

ENGINE

Type	6D 250 (7)
Diesel 4 stroke with turbulence chambers	
Number of cylinders	
Bore and stroke	85 x 100 mm (3.346" x 3.937")
Piston displacement	2270 cm ³ (138.5 cu.in.)
Compression ratio approx.	21.5 : 1
Maximum rated horse power (with air cleaner, without fan and exhaust muffler)	40 H.P. (30)
Maximum R.P. developed at	2900 R.P.M.
Maximum torque	14.3 N.m (101 lb ft)
Maximum torque developed at	1600 R.P.M.
Engine weight (w/ air cleaner, without lubricating oil)	275 kg (600 lbs)
Lubricating oil quantity (in pump and pipes)	7 kg (15.4 lbs)

Timing

Valve clearance	Valve clearance	Valve clearance	Valve clearance
Exhaust	0.060 mm (0.0024 in)	0.060 mm (0.0024 in)	0.060 mm (0.0024 in)
Intake	0.060 mm (0.0024 in)	0.060 mm (0.0024 in)	0.060 mm (0.0024 in)
Clearances between valve stem and rocker arm for check of timing engine cold Normal running clearance between valve stem and rocker arm engine cold (valve and rocker arm) .	0.060 mm (0.0024 in)	0.060 mm (0.0024 in)	0.060 mm (0.0024 in)

۱۷۹

Proportionate fuel pump	without segment bowl type	FIAT FP-KE 22A-L4/1
Operating pressure	with segment bowl type	FIAT FP-KE 22A-L4/0
Injection pump (Bosch) inserted with 4 plungers	for fuel pump without segment bowl type	1.2 tof (5 kg/cm ²) (17 to 21 psi)
	for fuel pump with segment bowl type	PES 4A 60B 410-L4/1
Direction of rotation of pump shaft (looking on drive side)		PES 4A 30B 410-L4/16
Injection order		clockwise
Setting of injection assembly on engine	The pump assembly with plunger No. 1 at the beginning of delivery, is mounted on engine fixing plates No. 1 in the con- nection stroke.	1-3-4-2
Nozzle nozzles type		20° ± 1° before T.D.C.
Nozzles type		KC 46 S & F
Injectors calibrated at		ON 12 SD 12
		120 ± 5 kg/cm ² (1700 - 1500 psi)

Governor

Vacuum governor (united with the injection pump) type:
Max. engine speed (no load), not less than: EP-V 83 A:LC 5
Min. engine speed (no load) from: 2600 R.P.M.
420 to 480 R.P.M.

LITERATURE

Lubrication at pressure (automatically adjusted by a valve) with hot engine oil or gasoline.

$\Delta \text{Kg} = 0$ (43 p-500)

(2) For disputes arising from agreements

Engines 417-29, 1650, 1651, 1652, 1653

Starting

Electric motor with engagement controlled by electro-magnet type FIAT E 115-3/24
Gear clutches for cold starting

1 Kvar
140 W

TRANSMISSION

	Gear ratios	Overall reduction ratios
1st gear	19.668 : 1	213.449 : 1
2nd gear	5.904 : 1	130.276 : 1
3rd gear	3.749 : 1	92.758 : 1
4th gear	2.938 : 1	54.847 : 1
5th gear	1.625 : 1	36.873 : 1
6th gear	1.032 : 1	22.788 : 1
1st reverse	7.253 : 1	160.349 : 1
2nd reverse	2 : 1	44.731 : 1

Rear reduction train

Bevel gears ratio	3.917 : 1
Final drives ratio	5.638 : 1
Total reduction ratio (bevel gears and final drives)	22.076 : 1

TIRES

Tractor type	613.100 (411 R)	815.103 (421 R)
Size of front tires		
Max. inflating pressure of front tires	6.00-16 2.5 kg/cm ² (36 p.s.i.)	6.50-16 2.5 kg/cm ² (36 p.s.i.)
Size of rear tires		
Max. inflating pressure of rear tires	Field work 0.0 kg/cm ² (11 p.s.i.)	0.0 kg/cm ² (11 p.s.i.)
	road work 1.2 to 1.5 kg/cm ² (17 to 21 p.s.i.)	1.2 to 1.5 kg/cm ² (17 to 21 p.s.i.)

STEERING SYSTEM

Turning radius	3 m (9 ft. 10 1/2 in.)	2.8 m (9 ft. 2 in.)
----------------	------------------------	---------------------

BRAKES

Outer diameter of drums	2100 mm (82 1/2")	2100 mm (82 1/2")
Width of brake lining	50 mm (2")	50 mm (2")

DRAWBAR (D)

Horizontal swing of drawbar clevis	650 mm (26")	650 mm (26")
Height of drawbar clevis above ground	270 mm (10 1/2") maximum	200 mm (7 1/2") 550 mm (21 1/2")

DIMENSIONS AND WEIGHTS

Wheelbase	1225 mm (31 1/2") 1280-1380-1480- 1580-1680-1780- 1880-1900 mm 50 1/2-54 1/2-58 1/2- 62 1/2-68 1/2-70 1/2- 74"-78"	1310 mm (37 1/2") 1260-1360-1460- 1560-1660-1760- 1860-1880 mm 48 1/2-53 1/2-57 1/2- 61 1/2-65 1/2-69 1/2- 70 1/2-77 1/2"
Front wheel		

(*) See 981 drawing specifications on page 109 for tractors with engines over 400 bhp up.

Tractor type	615.00	615.100
Rear track	1200-1300-1400- 1300-1600-1700- 1800-1900 mm $47\frac{1}{2}$ - $51\frac{1}{2}$ - $45\frac{1}{2}$ - $59\frac{1}{2}$ - $62\frac{1}{2}$ - $70\frac{1}{2}$ - $74\frac{1}{2}$	The same as for type 615.00
Overall length of tractor	2800 mm (114")	2860 mm (113 $\frac{1}{2}$)
with drawbar	2820 mm (111")	2755 mm (108 $\frac{1}{2}$)
without drawbar	1500 mm (59")	1450 mm (58 $\frac{1}{2}$)
Overall width	2200 mm (86 $\frac{1}{2}$)	2150 mm (83 $\frac{1}{2}$)
with min. tread	1410 mm (55 $\frac{1}{2}$)	1335 mm (52 $\frac{1}{2}$)
with max. tread	1370 mm (54")	1300 mm (51 $\frac{1}{2}$)
Max. height	400 mm (15 $\frac{1}{2}$)	400 mm (15 $\frac{1}{2}$)
to the top of steering wheel		
to the top of barrett		
Ground clearance under front axle		
Ground clearance under rear axle		
Operating weight of tractor	1420 kg (3133 lb)	1460 kg (3200 lb)
Weight of the two front wheel weights, approx.	70 kg (154 lb)	70 kg (154 lb)
Weight of the four rear wheel weights, approx.	220 kg (480 lb)	220 kg (480 lb)

PERFORMANCE AND FUEL CONSUMPTION

Speeds with engine at rated speed for concrete course:

	k.p.h.	m.p.h.	k.p.h.	m.p.h.
1st gear	2.2	1.4	2.1	1.3
2nd gear	4.9	3.0	3.0	1.9
3rd gear	6.3	3.9	6.1	3.8
4th gear	8.0	5.0	7.7	4.8
5th gear	14.5	9.0	14.0	8.7
6th gear	22.0	14.2	22.1	13.7
1st reverse	3.3	2.0	3.2	2.0
2nd reverse	11.9	7.3	11.4	7.1
Diesel fuel consumption	3.5-4 kg (7.7-8.8 lb)	3.5-4 kg (7.7-8.8 lb)		

Maximum drawbar pull on concrete course, with tractor fully ballasted (iron discs and 15 $\frac{1}{2}$ water ballast-ec tires):

1st gear	1500 kg (3,300 lb) $\frac{1}{2}$	
2nd gear	7500 kg (16,500 lb) $\frac{1}{2}$	
3rd gear	1500 kg (3,300 lb) $\frac{1}{2}$	The same as for
4th gear	1350 kg (3,000 lb)	type 615.00
5th gear	750 kg (1,650 lb)	
6th gear	450 kg (1,000 lb)	

($\frac{1}{2}$ Wheels in lifting position).

ELECTRIC SYSTEM

Running at 24 V.

See page 81 for instructions on its components.

ACCESSORIES

The performances of the accessories (power take-off, belt outlet, hydraulic lift) are the same for the several types of tractors.

Power take-off

Diameter of shaft
Speed of the power take-off (at rated engine speed)
Revolutions in ground speed

11/2

575 R.P.M.

Revolution for approx. 10% of forward travel (2 cm)

Belt pulley

Belt speed at rated engine speed	1195 R.P.M.
Belt speed	15.6 revs (3,070 R.p.m.)
Diameter of pulley	250 mm (9 1/2")
Width of band	150 mm (6")
Weight of pulley (without lubricating oil)	26.5 kg (58 lb)

Hydraulic lift

Hydraulic gear pump, type	Plessey C 10 X
Reduction ratio between engine shaft and hydraulic pump drive shaft speed	1,162 : 1
Pump speed (with engine at rated speed)	2000 R.P.M.
Delivery (litres/min) at approx. 20°C (68°F) at 180 kg/square cm (265 p.s.i.)	17 litres (2.75 Imp.gal.)
Relief valve opening pressure (Marked with letters C or E)	18.5 litres (3.65 Imp.gal.)
Bore of hydraulic lift cylinder	150 kg/square cm (2100 p.s.i.)
Displacement	85 mm (3.34")
Maximum travel of lift lower links	503 cu.cm. (31.5 cu.in.)
Maximum weight raised at the end of the lower links	580 to 600 mm (1' 10" to 23 1/2")
Indicated lifting capacity	900 to 1200 kg (2000 to 2645 lbs)
Lifting time (with engine at 2000 R.P.M.)	approx. 780 kgm (1725 ft.lb)
Weight of draft-and-position-control hydraulic lift, including pipes and pump (without oil)	3 sec. 62 kg (136 lb)

(*) Starting from chassis No. 624274 up, specifications are as follows:

Max. travel of lift lower link	950 and 980 mm (3' 1 1/2" and 3' 2 1/2")
Max. weight raised on lower link ends	900 and 1200 kg (1985 and 2645 lbs)

CAPACITIES

Part to be filled	Quantity	Material
Cooling system	12 l. 2 1/2 Imp.gal.	Water
Fuel tank	39 l. 8 1/2 Imp.gal.	Gasoline
Engine crankcase (filters and plugs included)	2 kg 7 3/4 Qts.	SAE 30 HD oil for temperatures from 0°C (32°F)
Injection pump and governor	—	SAE 10 W oil for temperature below 0°C (32°F)
Air cleaner	0.6 l. 1 1/2 Imp.gal.	SAE 5W-40 oil for temperatures above 20°C (68°F)
Transmission	12 l. 11 1/2 Imp.gal.	Semisynthetic oil as used for the engine pump
Final drives (each)	2 l. 1 1/2 Imp.gal.	SAE 30 HD oil
Steering system	—	SAE 10W oil for temperatures above -10°C (14°F)
Front wheels	—	SAE 90 oil for temperatures below -10°C (14°F)
Grease tanks	—	SAE 50 oil
Belt pulley	0.4 l. 1/2 Imp.gal.	Chassis grease
Hydraulic lift	3 l. 0.75 Imp.gal.	SAE 140 oil for temperature above -40°C (-40°F)
Generator supports	—	SAE 90 oil for temperature below -10°C (14°F)
Generator wires	—	SAE 20 hydraulic oil
Starting motor overrunning clutch	—	High melting point grease
		SAE 50 HD oil
		High melting point grease

MODIFICATIONS

Starting from the tractor with engine No. 070425 and chassis No. 411700 up, the fuel filter and feed pump have been modified as follows.

DOUBLE FUEL FILTER

In addition to the single paper element a cloth element has been added.
After each 300 hours the filtering elements to check their efficiency and to wash with kerosene the cloth one and replace, if necessary, the paper element which must not be washed.



Fig. 194 - Two element fuel filter.

1. Filtered steel screws - a. Filtering cloth & element - b. Paper filtering element.




Fig. 195 - Injection pump type PES 4 A 60 B 410:L4/16.

1. Cover protecting the pump central sleeve - 2. Reference marks - 3. Pump fastening nuts - 4. Feed pump fuel filter.

After the filter elements assembly, bleed air as follows:

- screw back of two turns the screws (1, fig. 195);
- unscrew the cap of the priming pump of the feed pump and pump till the fuel that flows from the holes located under said screws is free from air bubbles. Relighten said screws.

FEED PUMP WITH BOWL-TYPE FILTER

The injection pump type PES 4 A 60 B 410:L4/16 features a feed pump with bowl filter mounted on top the pump body (Figs 196 and 199).




Fig. 196 - Feed pump components.

19. Fuel filter.

The calculation with respect to previous pump type PES 4 A 60 B 4tc(L4R) is the same and the sole difference concerns the fuel feeding.

Fuel filter cleaning should be done with petro. every 120 working hours and before reassembling it, it is advisable to check and to replace it if necessary.

After assembly, bleed air bubbles from the system by slackening the relevant screw located on the injection pump body and by actuating the priming hand pump.

U-FLEX TYPE OIL RING

A U-Flex type oil-ring has been installed on engines No. 018735 and above. This type ring is higher than standard ones, therefore the piston groove has been modified accordingly.

Said changes have also been made on engines from No. 018268 to 015513.

Modified dimensions are shown in Fig. 200.




Fig. 200. - Dimensions of piston ring and its groove
5.530-5.532 mm; 2.118-2.120 in.; 72.6-72.4 mm;
0.2177-0.2178 in.; 0.2157-0.2159 in.; 2.858-2.856 in.

NEW DRAWBAR AND HITCH

Starting from chassis No. 420401 up the drawbar and hitch device of the series 400 tractors (except mod. 431(R)) have been modified in order to bring location of the various parts within the requirements of international standards. Changes are as follows:

- stronger and sturdier frame;
- more adjustment possibilities, in fact:
 - the drawbar plate can be fixed to the tractor at two different heights, and for each one it is furthermore possible to adjust the height by turning the drawbar plate toward or downward. More vertical settings are possible by turning over the drawbar;
 - the drawbar can be set in 3 longitudinal and in 3 traverse positions;
- Besides, the lower links are made 4 cm longer and the PTO shaft 4 cm longer.




Fig. 201 - New drawbar and hitch assembly.

Specifications.

Vertical distance from ground line to top of drawbar at hitch point, adjustable as follows	318 - 378 - 438 mm (12 1/8" - 14 1/2" - 17 1/8")
Horizontal swing distance at hitch point	519 mm (20")
Horizontal distance between hitch point and rearmost point of 12.4-28 tyres, adjustable as follows	10 - 55 - 100 mm (3 1/8" - 21 1/2" - 4")
Horizontal distance between hitch point and end of PTO shaft, adjustable	354 - 399 - 444 mm (14" - 15 1/2" - 17 1/2")
Vertical distance between top of drawbar at hitch point and centerline of PTO shaft, adjustable as follows	220 - 160 - 100 - 40 mm (8 1/2" - 6 1/4" - 4" - 1 1/2")
Vertical distance from ground line to centerline of PTO shaft .	580 mm (21 1/2")
Diameter of hitch hole (plus one 17.5 mm = 31/16" hole or 102 mm = 4" spread of hitch hole)	29 mm (1 1/8")

TABLE OF CONTENTS

	Page		Page
<i>Foreword and Service Notes</i>	3	<i>Gearbox and auxiliary reduction gear</i>	58
Engine	4	<i>Specifications</i>	63
General	4	<i>Differential and lock</i>	64
Operation	4	<i>Specifications</i>	65
Removal	5	<i>Final drives</i>	69
Disassembly	6	<i>Brakes</i>	71
<i>Overhaul and Checks</i>	17	<i> Specifications</i>	72
Cylinder block and气门	11	<i>Steering and front axle</i>	73
Cylinder head	12	<i>Steering box and linkage</i>	73
<i>Timing gear</i>	13	<i>Specifications</i>	74
Valves, guides and springs	13	Front axle	75
Valve levers and rocker arms	14	<i>Specifications</i>	76
Camshaft	15	<i>Electrical system</i>	80
Specifications	16	<i>Wiring diagram</i>	80
<i>Piston chain</i>	17	<i>Description</i>	82
Pistons	17	<i>Generator Type R 115 100/24-1572 Ver. P</i>	83
Connecting rods	19	<i>Specifications</i>	87
Crankshaft	20	<i>Generator Type DC 115/24/7;2 C</i>	88
Main and connecting rod bearings	21	<i>Specifications</i>	89
Specifications	22	<i>Control Box Mod. A 3-141/24</i>	91
<i>Lubrication</i>	25	<i>Specifications</i>	95
Oil pump	26	<i>Control Box Mod. GR 1.24/7</i>	96
Oil filters	26	<i>Specifications</i>	97
Specifications	27	<i>Batteries</i>	102
<i>Cooling</i>	28	<i>Starting motor</i>	103
Water pump	29	<i>Glow plugs</i>	105
Thermostat	29	<i>Attachments</i>	115
Radiators	29	<i>Power take-off</i>	116
Fan	30	<i>Bell pulley</i>	117
<i>Air feeding</i>	32	<i>Specifications</i>	118
Air cleaner	33	<i>Hydraulic lift</i>	119
<i>Fuel feeding</i>	30	<i>Pump</i>	119
Fuel tank	31	<i>Operation</i>	120
Feed pump	31	<i>Control Cock</i>	122
Injection pump and governor	32	<i>Specifications</i>	122
Calibration data	32	<i>Toot lifter</i>	131
Injectors	41	<i>Specifications</i>	131
Specifications	43	<i>Modifications</i>	137
<i>Reassembly of engine</i>	45		
Timing	49		
<i>Brake test</i>	50		
Performance data	51		
<i>Transmission</i>	53		
<i>Clutch</i>	53		
Flexible coupling	57		
Specifications	57		