

IHI-SHIBAURA TRACTOR

OPERATOR'S MANUAL

MODEL **SD 4300**

SD 4340

SD 5000T

SD 5040T



A1043



ISHIKAWAJIMA-SHIBAURA MACHINERY CO., LTD.

FOREWORD

Thank you for selecting an IHI-SHIBAURA Tractor from the large number of agricultural tractors on the market. IHI-SHIBAURA has long experience in manufacturing tractors and employs up-to-date designing techniques and production facilities. We can assure you that your tractor will be labor-saving, efficient, comfortable and universally useful at all times.


This instruction manual will help you to use IHI-SHIBAURA Wheel Tractors SD4300, SD4340, SD5000T and SD5040T more effectively.

Read this instruction manual carefully for an understanding of working safety, and to obtain efficient operation, and the longest service life out of your tractor.

If you have any questions regarding the IHI-SHIBAURA Wheel Tractors SD4300, SD4340, SD5000T and SD5040T, do not hesitate to ask your dealer.

The specifications of this tractor are subject to change without notice.

A VEHICLE IDENTIFICATION PLATE is located on the left hand side of the transmission housing. The numbers on the plate are important should your tractor require future service. For your convenience, have your dealer record the numbers in the appropriate spaces below.





CONTENTS

| | |
|---|-------|
| INTERNATIONAL SYMBOLS | 4 |
| SAFETY PRECAUTIONS | 5 |
| CONTROLS AND INSTRUMENTS | 6-11 |
| SLAT, LIGHT AND ENGINE CONTROLS | 6 |
| LIGHTING | 6 |
| INSTRUMENT PANEL | 6-6 |
| THROTTLE CONTROLS | 8 |
| BRAKE CONTROLS | 8-9 |
| DIFFERENTIAL CONTROL | 9 |
| TRANSMISSION AND PTO CONTROLS | 9-11 |
| HYDRAULIC SYSTEM CONTROLS | 11 |
| OPERATION | 12-20 |
| BREAK-IN PROCEDURES | 12 |
| STARTING THE ENGINE | 12-13 |
| STOPPING THE ENGINE | 13 |
| OPERATING THE TRANSMISSION, FOUR WHEEL | |
| DRIVE AND PTO | 13-14 |
| TOWING THE TRACTOR | 15 |
| OPERATING THE DIFFERENTIAL LOCK | 15 |
| OPERATING THE HYDRAULIC LIFT SYSTEM | 15-17 |
| DRIVING THE TRACTOR | 17 |
| WHEEL TREAD SETTINGS | 18-19 |
| TRACTOR WEIGHTING | 19-20 |
| TIRE PRESSURES | 20 |
| LUBRICATION AND MAINTENANCE | 21-42 |
| LUBRICATION AND MAINTENANCE CHART | 21-22 |
| TWO-WHEEL DRIVE | 21 |
| FOUR-WHEEL DRIVE | 22 |
| FUEL AND LUBRICANTS | 23-25 |
| FUEL AND LUBRICANT SERVICE PROCEDURES | 25-31 |
| GENERAL MAINTENANCE | 32-40 |
| TRACTOR STORAGE | 40-41 |
| GENERAL TORQUE SPECIFICATION TABLE | 44 |
| SPECIFICATIONS | 45-47 |
| WIRING DIAGRAM | 48 |
| SAFETY AND INSTRUCTION DECALS | 49-52 |
| PREDIIVERY AND 50 HOUR SERVICE | 53,55 |

INTERNATIONAL SYMBOLS

As a guide to the operation of your tractor, various international symbols have been placed on the instrument and controls. The symbols are grouped by general classification and their meaning.

| | | | |
|--|--------------------------|--|--------------------------------------|
| | Engine speed | | "Tachometer" slow or minimum setting |
| | Hour meter | | "Tachometer" fast or maximum setting |
| | Engine water temperature | | Counter clockwise turning direction |
| | Fuel | | Clockwise turning direction |
| | Engine oil pressure | | Check hoses (leaked) |
| | Safety switch | | Steering cylinder under extension |
| | Air cleaner | | Steering cylinder extended |
| | Oil level | | Fuel gauge |
| | Control by hand | | Electric type level |
| | Refugee | | Coolant level |
| | Taxi | | Air filter extension |
| | Anti-vibration damping | | Oil filter connection |
| | Power assist oil tank | | Universal lock |
| | Power assist fluid tank | | Lock (lock) |
| | Caution | | Open (open) |

SAFETY PRECAUTIONS

SAFETY: Operator is the most important safety device on your tractor. It is up to the operator to consider all situations and always drive safely. If you are not sure about a situation, stop and think.

THE TRACTOR

1. Check the engine oil and coolant before starting the tractor. Add oil and coolant as required.
2. Use a sharp, well-adjusted blade. Keep grass clippings from the blade area.
3. Turn the tractor off when you leave it or when you are not using it.

SERVICING THE TRACTOR

4. Remove your hands from the steering wheel when you are not driving. Hold the steering wheel firmly with both hands when turning the tractor.
5. Turn the tractor off immediately if you smell gas or smoke. Stop the tractor and move it away from the source of the smell.
6. Use the correct amount of oil and coolant. Check the oil and coolant levels frequently. Check the oil and coolant levels after each use.
7. Do not use the tractor in bad weather. Avoid driving in rain, snow, ice, mud, or deep water.
8. Do not use the tractor in strong winds.
9. Do not modify the tractor. Do not add attachments or accessories unless recommended by the manufacturer.

OPERATING THE TRACTOR

10. Do not use the PTO when the engine is running. Turn the PTO off before you start the tractor.
11. Do not use the PTO when you are using the tractor to pull a trailer or other load.
12. Do not use the PTO when you are using the tractor to pull a trailer or other load.
13. Do not use the PTO when you are using the tractor to pull a trailer or other load.
14. Do not use the PTO when you are using the tractor to pull a trailer or other load.
15. Do not use the PTO when you are using the tractor to pull a trailer or other load.

16. Do not use the PTO when you are using the tractor to pull a trailer or other load.
17. Do not use the PTO when you are using the tractor to pull a trailer or other load.
18. Do not use the PTO when you are using the tractor to pull a trailer or other load.
19. Do not use the PTO when you are using the tractor to pull a trailer or other load.
20. Do not use the PTO when you are using the tractor to pull a trailer or other load.
21. Do not use the PTO when you are using the tractor to pull a trailer or other load.
22. Do not use the PTO when you are using the tractor to pull a trailer or other load.
23. Do not use the PTO when you are using the tractor to pull a trailer or other load.
24. Do not use the PTO when you are using the tractor to pull a trailer or other load.
25. Do not use the PTO when you are using the tractor to pull a trailer or other load.
26. Do not use the PTO when you are using the tractor to pull a trailer or other load.
27. Do not use the PTO when you are using the tractor to pull a trailer or other load.
28. Do not use the PTO when you are using the tractor to pull a trailer or other load.

DRIVING THE TRACTOR

29. Use a slow speed when driving on roads or paths that may have obstacles or debris.
30. Do not drive the tractor on roads or paths that may have obstacles or debris.
31. Do not drive the tractor on roads or paths that may have obstacles or debris.
32. Do not drive the tractor on roads or paths that may have obstacles or debris.
33. Do not drive the tractor on roads or paths that may have obstacles or debris.
34. Do not drive the tractor on roads or paths that may have obstacles or debris.
35. Do not drive the tractor on roads or paths that may have obstacles or debris.
36. Do not drive the tractor on roads or paths that may have obstacles or debris.
37. Do not drive the tractor on roads or paths that may have obstacles or debris.
38. Do not drive the tractor on roads or paths that may have obstacles or debris.
39. Do not drive the tractor on roads or paths that may have obstacles or debris.
40. Do not drive the tractor on roads or paths that may have obstacles or debris.

OPERATING THE PTO

41. Do not use the PTO when the engine is running. Turn the PTO off before you start the tractor.
42. Do not use the PTO when you are using the tractor to pull a trailer or other load.
43. Do not use the PTO when you are using the tractor to pull a trailer or other load.
44. Do not use the PTO when you are using the tractor to pull a trailer or other load.
45. Do not use the PTO when you are using the tractor to pull a trailer or other load.
46. Do not use the PTO when you are using the tractor to pull a trailer or other load.
47. Do not use the PTO when you are using the tractor to pull a trailer or other load.
48. Do not use the PTO when you are using the tractor to pull a trailer or other load.



ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

CONTROLS AND INSTRUMENTS

SEAT, LIGHT, AND ENGINE CONTROLS

TRACTOR SEAT

Your SHIMANO Tractor is equipped with a molded plastic seat. The seat is adjustable to obtain the most comfortable position. It can be moved forward or back in the seat frame by pulling the lever up to the left of the seat, and then by moving the seat as desired. Figure 1. The front cushion can be reclined 4 degrees by pulling the lever down.




Figure 1 - Tractor Seat

LIGHTING

TURN SIGNAL LAMPS

Your SHIMANO Tractor is equipped with turn signal lamps. Figure 2. The switch for the turn signals is located on the left side of the instrument panel.




Figure 2 - Turn Signal Lamps

LIGHT SWITCH

The light switch, shown in Figure 3, is a push-on/off switch. Its features are:




Figure 3 - Light Switch, Cigarette Lighter, Starter Switch, Engine Stop Knob and Hood Opening Knob

- 1. HIGH BEAM
 - 2. TURN SIGNALS
 - 3. PARKING LIGHTS
 - 4. HEADLIGHTS (Front Left, Side Lamp, Side Lamp, Instrument Panel Lamp)
 - 5. FRONT TURN SIGNALS (Low Beam)
 - 6. REAR TURN SIGNALS
- NOTE: Headlights (Low Beam) are referred to the "HIGH BEAM" on the 2nd page as for reference.

INSTRUMENT PANEL STARTER SWITCH

- ON: Electricity is supplied.
- OFF: Electricity is stopped by the electric circuit.
- START: The self-starting motor is activated and the engine starts.
- To start, depress the clutch pedal fully and turn the key to the "START" position.
- OFF: Electricity to the electric circuit is stopped. The switch is positioned out of the way to the "OFF" position. Always check to make certain the transmission is in Neutral and PTO lever are in neutral before attempting to start the engine. Refer to page 13 for more information.

CONTROLS AND INSTRUMENTS




Figure 4 - Instrument Panel

IMPORTANT: The steering wheel must remain in the 'OFF' position while the engine is running. The steering wheel will suddenly snap back to the center position with the start of the 'ON' rotation.

HOOD OPENING KNOB

On the hood opening side of the dash (Fig. 4) is a power-operated hood release.

GLOW SIGNAL INDICATOR LAMP & I.O.S.

- Turn the key to the 'START' position and turn on the glow signal. The glow signal will stay lit continuously until after the engine starts and it is turned off automatically after about 10 seconds.
- Then turn the key to the 'START' position to reset the glow.

IMPORTANT: When the engine is off, turn the key to the 'OFF' position to turn off the glow. At this time, the glow signal and any lights which were not turned on while the engine was running will stay on.

If the engine is not started, return the key to the 'OFF' position and repeat the above procedure after about 10 seconds.

Be sure to keep the key at the 'OFF' position while the engine is working so that the 'OFF' position is held at 2000.

PROOF-METER

The Proof Meter is located directly behind the instrument panel (Fig. 4). The Proof Meter indicates:

- The hour and portion of the 8-hour test cycle (2000 RPM, 1000 RPM or average engine speed of 1896 RPM, Engine speed below 8 RPM is considered to be zero). This means that the Proof Meter indicates speed more than 1896 RPM and indicates any one hour faster than 2000 RPM. The Proof Meter also indicates the current engine speed and the last hour of the test.
- Current engine revolutions per minute based on the number of pulses from the Proof Meter when operating PTO or over-speed limit. Additional information on PTO under 'OPERATING THE PROOF METER'.
- The number of hours the Proof Meter has been ground since the last engine hour (KPH) for 12th point. Add 1000 to ground speed (12th point) to be the total speed.

FUEL GAUGE

The fuel gauge is shown in Figure 4. The needle in the gauge indicates the amount of fuel in the tank. If the needle is at the 'E' marking, the tank is empty.

TEMPERATURE GAUGE

The temperature gauge is located directly behind the instrument panel (Fig. 4). The gauge has three markings: 'NORM' (normal), 'HOT' (high temperature) and 'COLD' (low temperature).

WARNING LIGHTS

Model 15-1541A is provided with the following warning lights. In any warning light condition, investigate the cause as soon as possible.

Push the check button below each warning light. The following buttons are the logic code 1010, 0101, the null of warning lights. Push each button because the logic switch is touch sensitive.



The large red-orange warning light is located to the left of the switch for the 'WIND' function. It goes out after the singe contact and simplicity is hence.

CONTROLS AND INSTRUMENTS

-  The engine oil pressure warning lamp lights with the key inserted and the 'ON' switch set to 'key on'. When the engine is running, the indicator remains illuminated until a pressure is reached.
-  The battery voltage warning lamp will illuminate if the voltage of the battery has decreased below the safe level. This will occur normally when the engine is running.
-  Hydraulic system pressure indicator for the steering fluid system.
-  Differential locking warning lamp lights when the differential lock mechanism is working.
-  High beam indicator lamp indicates that the headlights are in the high beam.

IMPORTANT: Check the coolant water of the radiator, battery, visibility, oil filter, air filter, clutch, flywheel assembly and the engine for any damage before starting the tractor.

THROTTLE CONTROLS HAND THROTTLE AND ENGINE STOP CONTROL

SD4300, SD4340

The hand throttle is shown in Figure 4. Pull the handle down to increase engine rpm. Push the handle forward to decrease engine rpm. The 'Engine Stop Knob' is shown in Figure 3, full clockwise to stop the engine.

SD5000T, SD5040T

The hand throttle is shown in Figure 4. Pull the handle down to increase engine rpm. Push the handle forward to decrease engine rpm. Push the handle full forward to stop the engine.

FOOT THROTTLE

The foot throttle is shown in Figure 5. To accelerate gently, move the accelerator with the hand. However, when the hand throttle control lever is held in a full forward position, the foot

throttle can be used to increase engine rpm. The maximum speed of the tractor is limited by the engine speed at which the hand throttle has been set, or idle, with the hand throttle lever set at the 'off' position.

BRAKE CONTROLS

BRAKE PEDALS

The brake pedals are shown in Figure 6. The right-hand pedal is used to brake the front rearwheels. The left pedal is used to brake the left rearwheel. Depress both pedals simultaneously to stop the tractor.




Figure 6 - Front Throttle and Brake Controls

To assist in making turns at low speeds, depress the front-left brake pedal to one-third.



CAUTION: When making turns at low speeds, both rear wheels may skid if the front-left brake pedal is depressed to more than one-third. If this occurs, stop the tractor immediately.

BRAKE PEDAL LOCK

The master pedal will disengage if opened and released, the master pedal levered to 'lock' the pedal together or when the tractor is operating at high speed. Under any of these conditions, the tractor is stopped in this way.

PARKING BRAKE CONTROL

The parking brake control device in Figure 6 is used for locking the brake pedal. When applied and held, the parking brake should be applied whenever the tractor is not being driven.

CONTROLS AND INSTRUMENTS




Figure 6 - Parking Brake

To apply the brakes:

- Lock the front axle drive system with the trailer control valve.
- Depress the clutch pedal.
- Pull up on the parking brake lever. Turn clockwise until it stops. If the rear axle has a parking brake lever, turn clockwise until it stops and then turn the pedal in the clockwise direction.

To release the parking brakes:

- Depress the clutch pedal 15 to 18 mm the pedal.
- Unlock the trailer axle. Depress the trailer control valve independent of who holds your toe.

DIFFERENTIAL CONTROL DIFFERENTIAL LOCK PEDAL

The differential lock pedal (located on Figure 7) depresses the pedal locks the rear axle drive system, preventing




Figure 7 - Differential Lock

rotation of the rear axle drive system. Refer to page 15 for differential lock operating instructions.



CAUTION: Do not depress the clutch pedal to apply the trailer control valve. See page 15.

POWER STEERING (FOUR-WHEEL DRIVE SD4340, SD 5040T)

The steering can be held in its position by using power steering with optional power steering. It is recommended to do so.



CAUTION: Do not use the steering wheel to hold the position of a tractor with a steering column. Depress the clutch pedal and turn the steering wheel to hold the position.

TRANSMISSION AND PTO CONTROLS

TRANSMISSION GEARSHIFT LEVERS

The transmission main shift lever and range selector lever are shown in Figure 8. A diagram showing the shift pattern of each into the transmission cover.

Three forward and one reverse gear are provided in each of the two ranges. This provides a total of 12 forward and 4 reverse speeds.




Figure 8 - Transmission Control

CONTROLS AND INSTRUMENTS

CREEPER RANGE

A creeper range switch, 7-26, 1 notch, is located which provides an additional 1/2 forward and 1/2 reverse speeds or a total of 24 forward and 11 reverse speeds. The switch is located on the top left side of the dashbox, see Figure 9.

For forward movement of the rear tracks (OFF), the creeper range, full forward movement leverages (ON) the rear range.




Figure 9 - Creeper Range Control Lever and Four-Wheel Drive Lever

FOUR-WHEEL DRIVE (SD4340, SD5040T)

The gear lever for the four-wheel drive is located on the left side of the rear track selector housing, Figure 9. For movement movement of the rear lever engages the hydrodynamic PTO. Full forward movement for the front range moves PTO.

CLUTCH PEDAL

The foot-operated clutch pedal, Figure 10, must be completely depressed to start the automatic safety start switch and the PTO. In the slow forward and PTO shift position. Always fully depress the pedal when changing gear ratios, however do not depress it during ranges.




Figure 10 - Clutch Control

DUAL CLUTCH

A dual clutch is available on the above-mentioned and the following vehicles: the PTO shift, clutch, and rotation. When the clutch and PTO are depressed to the PTO shift position, engagement of the PTO is engaged. If the pedals depressed to the idle (200 rpm) clutch and the PTO is engaged.




Figure 11 - Dual Clutch

TRANSMISSION PTO GEARSHIFT LEVER

The positions on PTO gearshift lever is shown in Figure 12. A diagram showing the shift pattern for the four PTO speeds as follows on 1/4 quadrant of the tractor engine. In shifting, always select the fourth gear. Fully depress PTO on the lever.

CONTROLS AND INSTRUMENTS




Figure 12 PTO Control




Figure 13 Hydraulic Lift System Control - Draft and Position Control




Figure 14 Hydraulic Flow Control Valve and Auxiliary Service Ports

HYDRAULIC LIFT SYSTEM CONTROLS HYDRAULIC LIFT CONTROL LEVERS

The two hydraulic lift control levers shown in Figure 13, the "DRAFT" and "POSITION" control levers, are located on the front of the center console. The "DRAFT" control lever is used to control the amount of draft pressure applied to the lift arms, and the "POSITION" control lever is used to determine the height of the lift arms. The "DRAFT" lever is also used for detenting the lever at any position in the downward travel of the lift arms. It is used to adjust draft pressure. The "POSITION" control lever is used to control the height of the lift arms. It is pulled up to adjust heavy draft pressure, or it is pulled down to adjust light draft pressure.

FLOW CONTROL VALVE

The flow control valve, shown in Figure 14, contains the "flow control valve" which detaches the lower section of the center console, and the "flow control valve knob" which is attached to the lower section of the center console. Refer to "FLOW CONTROL" page 17 for additional information concerning operating the flow control valve.

IMPORTANT: The hydraulic system pressure is not to be exceeded to the point of the top of the quarter cylinder housing, or in the hydraulic cylinder. The lever should be positioned in the center of the cylinder when using hydraulic pressure, and the auxiliary service port for泄压 (venting) hydraulic cylinders, motors, etc.

AUXILIARY SERVICE PORT

When a service port or air respirator of pressure and air pressure are required, use the auxiliary service port located on the right side of the hydraulic cylinder body. Two auxiliary service ports are located on the right side of the hydraulic cylinder body, such as a hydraulic cylinder, and the right side of the cylinder on the same side as Figure 14, refer to the information on the service port located on Figure 14.

OPERATION

BREAK-IN PROCEDURES

- Your SHIBAURA Tractor will provide long and dependable service if given proper care during the first four hours of operation:
1. Avoid "lugging" the engine. Decreasing the engine's gear ratio (heavy load may cause engine "lugging"). "Lugging" is increased when the engine won't run due to a throttle orifice.
 2. Use the lower gear range whenever pulling heavy loads and avoid starting the appearance of constant engine speeds. You can help to avoid unnecessary engine wear by starting the engine at low idle for a period after shutdown. Operating the tractor slowly at 2000 rpm with a light load and low engine speed will wash the oil.
 3. Avoid prolonged operation at high engine speeds especially when a load is being pulled by the engine.
 4. Check the oil pressure frequently and keep the radiator and oil reservoir filled to their recommended levels. Daily checks include:
 - Engine oil level
 - Fuel storage tank

STARTING THE ENGINE

1. Set the main charge lever and EGR charge lever at the neutral. If you use the hydraulic lever, set the "OFF" position.
2. Pull the clutch lever forward.
3. Turn the key switch to the "START" position. This tractor is supplied with a U. S. SHIBAURA Oil-Saver Starter. By turning the key to the "START" position, the solenoid, the gear selector lever, the fuel solenoid and then goes out about 3 seconds later. (Please note it not key than while the motor is warm.)
4. Do as the operation below.
5. Turn the key switch to the "START" position, and then the start solenoid comes on for 2000 rpm start. Then release the hand of the key and the key returns automatically to "OFF" position.
6. Push the clutch lever forward, open the clutch pedal and warm up the engine for 5 to 10 minutes at the idling speed.

SD5000T, SD5040T

Never fail to warm up the engine for 5 to 10 minutes at the idling speed.
Warming up is not required while the engine is warm.



Figure 15. Starter Switch

IMPORTANT: The engine is not started even when the key switch is turned "ON" if the clutch pedal is not stepped fully.

When the pedal is depressed fully, the safety switch is activated, electricity flows to the starter and the engine is started.

If the engine fails to start, repeat it 2 to 3 times about 30 minutes apart.

With the engine is working, never turn the key to the "START" position.

Be sure to keep the key at the "OFF" position while the engine is working and "OFF" when it stops. Otherwise, it may cause damage.

Or it could damage the lead washer on right for "OFF" position of key "ON" side.

STARTING THE TRACTOR WITH JUMPER CABLES

It is necessary to use jumper cables to start the engine, please see the following instructions.

Connect one end of the jumper cable to the tractor engine's positive (+) terminal and the other to the auxiliary battery positive (+) terminal. Connect one end of the other cable to the auxiliary battery negative (-) terminal, and the other to the main battery ground strap. Follow the starting procedures after the jumper cables are connected.

Do the engine and turn on all electrical equipment. Ignite, and then disconnect the cables in reverse order of re-connecting procedure above. This will help protect the alternator from damage due to extreme load changes.

NOTE: Low-volt battery voltage will damage the voltage regulator and alternator.

CAUTION: Extended idling or low speeds can damage the engine. Do not idle the engine for more than 10 minutes at a time. If you must idle the engine for longer than 10 minutes, follow these steps:

- Wear eye and ear protection.
- Keep sparks and flame away.
- Always wear a respirator, ventilation while charging or fueling the battery.
- Follow the battery manufacturer's instructions with regard to the battery.

STOPPING THE ENGINE

SD4300, SD4340

Push the hand brake fully forward and pull the "Throttle Knob" (Figure 3-14) forward to stop the engine. Then turn the "power switch" (Figure 15) to the "OFF" position.

SD5000T, SD5040T

Pull the gear shifter fully toward you (pedal position) to stop the engine. Then turn the "power switch" (Figure 15) to the "OFF" position.

Never fail to warm the engine at idling speeds for 5 to 10 minutes.

IMPORTANT: Failure to turn the "power switch" to the "OFF" position after the engine stops will allow the warning lights to remain on, draining the battery. Do not sleep.

OPERATING THE TRANSMISSION, FOUR-WHEEL DRIVE AND PTO

The transmission operates through the use of a clutch pedal, a main shift lever, and a range shift lever. Figure 16 illustrates the pedal and lever involved.




Figure 16 -- Transmission Controls and Shift Pattern

Gearshift speeds for the various gear ratios can be found on page 47. The next table shows the combination of main shift lever and range shift lever positions to obtain the 10 forward and 10 reverse speeds.

| SPEED | RANGE | MAIN |
|-------|-------|------|
| 1 | 1 | 1 |
| 2 | | 2 |
| 3 | | 3 |
| 4 | 2 | 4 |
| 5 | | 5 |
| 6 | | 6 |
| 7 | 3 | 7 |
| 8 | | 8 |
| 9 | | 9 |
| 10 | 4 | 10 |
| 11 | | 11 |
| 12 | | 12 |
| 13 | | 13 |
| 14 | | 14 |
| 15 | | 15 |
| 16 | | 16 |
| 17 | | 17 |
| 18 | 2 | 18 |
| 19 | | 19 |
| 20 | | 20 |
| 21 | 3 | 21 |
| 22 | | 22 |
| 23 | | 23 |
| 24 | 4 | 24 |

Speed range combinations

When in "STOP", always center the clutch pedal fully and depress the "brake" to a complete stop before moving a transmission gearshift. Do not attempt to change gears while the vehicle is moving.

NOTE: Avoid using the clutch pedal when "Drafted" (driven by another vehicle) because it may be necessary to disengage the clutch to avoid the clutch抱死.

To engage, shift and gear shift to number one in the range.

1. Depress the clutch pedal firmly.
2. Bring the tractor to a complete stop.
3. Shift up to one to give the gear range.

The four-wheel drive is engaged and disengaged through the use of the lever on the top right side of the transmission (by holding "4" gear).

To engage the four-wheel drive, depress the clutch pedal fully and move the four-wheel drive lever full oppose. To disengage, move the lever full forward.



CAUTION: Do not use the clutch pedal to hold the transmission in gear. This will damage the clutch.

OPERATION

IMPORTANT: The front wheel on a standard tractor may not have a front PTO shaft or a PTO shaft lockout device. It is very important that the PTO be engaged only when the front wheel is engaged and releasing the clutch. The PTO shield should be engaged prior to moving the gear selector lever. Do not feel attempting

POWER TAKE-OFF (PTO)

PTO speeds for the various implements can be found on the individual implement's parts book. It is strongly recommended to familiarize yourself with your PTO speeds.

Figure 12 illustrates how to engage the PTO. The operator is required to follow "COMFORT OPERATIONS" (see ATOMS).

IMPORTANT: Operator safety is required to avoid standard PTO shaft disengagement.

PTO SHIELD AND CAP

The PTO shield protects the engine from the flywheel. The shield must always be used with both mounted and pull-type PTO equipment.

The PTO cap should always be installed when the PTO is not in use.




Figure 12 PTO Shield and Cap

POWER TAKE-OFF OPERATION

- Stop the engine, set the parking brake, release the PTO clutch cap and engage the clutch lever of the PTO shaft. Make sure the rear end of the PTO shaft is in the engagement lever slot to lock the PTO drive shaft and that the PTO shield is engaged to the tractor.



CAUTION: To reduce the risk of personal injury, do not stand between the rear of the tractor and the PTO shaft when the PTO is engaged. Always stand to the side of the tractor when operating the PTO.

- Depress the clutch pedal to disengage the engine flywheel, then shift the gear selector lever to the neutral (N) position.
- Release the clutch.
- Depress the PTO clutch lever (see Figure 12) to the zero (0) position to disengage the PTO.
- Shift off the PTO clutch lever and return the gear selector lever to the neutral (N) position.
- With the engine running, if equipped, depress the clutch pedal completely, then engage the PTO by moving the PTO control lever (Figure 12) to the desired operating speed.



CAUTION: To reduce the risk of personal injury, do not stand between the rear of the tractor and the PTO shaft when the PTO is engaged.

- Check the PTO driven equipment for proper operation by gradually releasing the clutch pedal and stopping the engine.
- After stopping the engine, make sure the equipment is operating properly, depress the clutch pedal and shift to the proper operating gear. Engage the clutch gradually to start the PTO and warm up the tractor.
- Depress the PTO clutch lever (see Figure 12) to the zero (0) position to disengage the PTO.
- Depress the clutch lever (see Figure 12) to the zero (0) position to disengage the PTO when traveling on highways or for any great distance.
- Reinstall the PTO shaft cap with the PTO shield.

operator is disconnected from the tractor or when the safety switch is used.



CAUTION: If the engine is started with the differential lock engaged, the tractor may move forward and backward during gear shifting, causing damage to the vehicle.

TOWING THE TRACTOR

To tow your tractor, place the parking lever in neutral when operating. Do not exceed 20 mph. Do not tow your tractor if it starts.

If the tractor is towed in reverse, any job implement attached to the tractor at a speed faster than 10 mph.



CAUTION: Do not tow the tractor if you are carrying any load or equipment. Always remember that the tractor is designed primarily to pull the implement, not carry it.

OPERATING THE DIFFERENTIAL LOCK

The differential lock is engaged by pressing the pedal located on the front side of the transaxle assembly (Figure 18). Because the pads have a built-in jaw action, they slide together, preventing one wheel from rotating independently of the other. The lock should be used to engage additional traction from the opposite wheel(s) without allowing mud or debris to collect in the gap.




Figure 18 - Differential Lock Pedal

Always engage the differential lock when driving the tractor on the highway or when ground load is above 400 lb.

To operate the differential lock, depress and hold down the pedal until the lock is positively engaged. It is best to engage the differential lock while the tractor is moving slowly to minimize shock loads to the drive line. The wheel alignment angle, which is optimum, must be adjusted to the balance ensuring the lock, or damage may occur. The differential lock is released by releasing the pedal.

NOTE: In some cases, the lock may remain engaged after the pedal is released. This may occur when the center of both rear wheels contacts the either shoulder of a jump; the lock may be disengaged by driving off the jump.

- Operate the differential lock only when the operating implement is the rear or middle wheel assembly.
- = On =
- Initially apply and release the right clutch pedal to determine whether a turn is required.

OPERATING THE HYDRAULIC LIFT SYSTEM

The hydraulic lift system consists of a pump, tank, and return cylinder to provide lift for the implement and carrier. The implement is held in the air by a pump. The system accommodates 1000 lb. in the lift and 1000 lb. in the carrier. The pump pump is controlled by a pump cylinder.



CAUTION: Make sure the lift is lowered before applying the parking brake.

OPERATION

POSITION CONTROL

When operating in position control, there is a constant relationship between the position of the control lever on the joystick and the position of the equipment. The lever must be moved to change the position of the equipment relative to the joystick. The joystick will automatically return to the center position when the lever is released.

The joystick provides early, accurate control of the equipment. Inside equipment can go under these two ground truth or reference values, recovery and draft control, to a minimum depth when using a joystick or a manual equipment control joystick.

IMPORTANT: When working in the position control mode or converting from the joystick to the draft control mode, pull the joystick forward.

DRAFT CONTROL

When working in the draft control, the joystick is used to adjust the draft level. Once the joystick positioned, the hydraulic lift system will automatically adjust the depth of the equipment to maintain its position on the bottom of the trench or work area. The hydraulic system automatically changes the operating range of the upper link when the equipment is lowered. The operation of the upper link control system is described below.

Upper Link Compression Loads: As the equipment is pulled through a trench, the draft caused by soil resistance tends to rotate the equipment upward around the lower link pivot point. The greater the upward rotation of the base and the more the load applied to the upper link, the greater the resistance causes the draft to increase. The maximum force of the upper link will also increase as a result. This change of weight of the link or compression along the hydraulic cylinder through movement of the upper link will move the equipment, therefore, it is important to draft.

Upper Link Tension Loads: When working in the long, heavy equipment in tight, shallow or uneven depths, the soil resistance is not always sufficient to keep a company and hold on the upper link. At times the link will be tensioned enough so the system will automatically respond to prevent as well as limit rotation. This may affect the working cycle even when it is unlikely to any equipment.




Figure 19. Hydraulic Lift Control levers.

IMPORTANT: Before starting work, set the draft control lever to the maximum depth of the job guide and the lower control lever to the center position. Move the lever forward to the digging depth of your hollow and backward to go deep to find the best position.

NOTE: When working in the draft control, the position control function will hold over automatically. However, if the field conditions vary significantly from both the job guide and the same field, or if the soil is soft and the trench becomes gradually deeper, the user must take the position control over or off the joystick (by pushing the joystick with the adjustable stop). When operating away from the draft control over threshold, the draft control does not work.

To take a rest while operating in the draft control, move or cover the joystick with the position control lever.



CAUTION: Do not exceed the maximum digging depth of the job guide. If the equipment is held in the draft control, it may damage the equipment.

HYDRAULIC LIFT ROCKER

The hydraulic lift rocker (Figure 20) is used for actuating the upper cylinder of the rock of the lower link. The lift rocker must be bypassed and an auxiliary hydraulic cylinder supplied as shown.




Figure 20 - Hydraulic Lift Rocker

FLOW CONTROL

The flow control valve (Figure 21) is used to adjust the flow to the cylinder thus controlling the rate of drop of the lower link. To adjust the rate of flow, either turn the flow control valve clockwise to decrease the rate of drop or turn it counter-clockwise to increase the rate of drop.



Figure 21 - Flow Control Valve

Operation of Front Loader, etc with the Valve on the Implement Side.

1. Set the position controller of the hydraulic valve at position 1 (maximum lift speed).
2. Turn the flow control valve counter-clockwise to lock the flow control system.
3. Operate the front loader lift with the valve on the implement side.

Operation with the Valve on the Tractor Side

1. Turn the flow control valve clockwise to lock the hydraulic system.
 2. Set the position controller for lifting and lowering the implement at maximum lifting speed.
- Caution:**
- (Left) - Hydraulic lifting position
 - (Right) - Implement position
 - (Center) - Lower than the implement position



CAUTION: When operating the lift, do not suddenly raise the lift. If the lift is raised too rapidly, the implement may drop. If the implement drops, it may damage the hydraulic system. Do not drop the implement.

ATTACHMENT VALVE (OPTIONAL)

For implements such as a dump trailer which requires lifting and lowering of the implement by operation of auxiliary implements (lifters), etc., an attachment valve for implements such as a dump trailer which is operated with the valve on the tractor side, is recommended to use the attachment valve for the implement. Single acting and double acting attachment valves are available. Order a proper one depending on the model used.

OPERATION

DRIVING THE TRACTOR



CAUTION: Check the following items before driving the tractor.

- When you start the engine, immediately turn the steering wheel and return it.
- Keep the tractor in gear when going down hills. Use low gear to maintain control and avoid the risk of breaking.
- If the tractor starts to bog, move it to a lower gear or stop.
- Always use the shoulder for overtaking others. Do not drive on the left side of the road if the traffic may be forced.
- Keep your lights on even as they do not turn the switch on in certain conditions.
- Change the clutch slowly when shifting out of a gear, especially when driving forward. Damage the clutch assembly may result from driving too fast or shifting too quickly.
- Stop the engine before entering water or standing water. Do not drive through water more than 10 cm (4 in) deep.
- Never apply the brakes on both wheels at once.
- Use extra caution and act carefully around the tractor blades when plowing heavy, loose soil or grass.
- Avoid trees that weigh more than one metric ton per meter line and 11.5 m² surface area. If not, reduce speed and/or go around.
- Allow extra time for deceleration when starting or driving the tractor.

WHEEL TREAD SETTINGS FRONT WHEEL TREAD SETTINGS (TWO-WHEEL DRIVE ONLY SD4300 AND SD5000T)

The front wheel tread setting is adjustable from 121 to 130 mm (4.76 to 5.12 in). The rear wheel tread of 130 mm (5.12 in) is standard, and increasing the front wheel tread (Refer to 24.7 in "REAR WHEEL TREAD SETTINGS").

1. Set parking brake and raise the front end of the tractor with a scissor lift under the center of the frame. Do not apply weight upon either side of tractor frame end trunnions.
2. Loosen the two locking bolts.
3. Measure the front wheel axle (Refer to 24.1 and 24.2 for axle settings) and set the desired setting by turning all the trunnion locking nuts clockwise.





Figure 24 - Front Wheel Tread Settings

4. Push up the trunnion lock and turn the locking nut clockwise to tighten the locking bolt.
5. Check the torque (Refer to 24.1).



CAUTION: Make sure the front wheel tread setting is correct. If the wheel tread is too large, the vehicle may roll over when turning.

NOTE: After changing the front wheel tread setting, the front wheel hub bolts should be torque up to 710-810 N·m (50-60 lb-ft). Adjusting the axle height by raising it 24.5 mm (0.96 in) above the top of the rear wheel hub is also possible.

REAR WHEEL TREAD SETTINGS

The rear wheel of the SD4300 and SD5000T are adjustable from 120 to 130 mm (4.72-5.12 in). The rear wheel tread settings are opposite to the front wheel tread settings. To increase the wheel tread, turn the locking nut clockwise.

or on disc with respect to the axle, and by interchanging the rear wheel side-to-side. Rear wheel settings are shown in Figure 25.




Figure 25 - Rear Wheel Tread Settings

NOTE: When changing the rear wheel tread setting, the wheel nuts/bolts should be torqued to 1000-2200 Nm, and the disc bolts/bolts should be torqued to 1800-2200 Nm.

TRACTOR WEIGHTING

To achieve sufficient traction for improved performance in mud, soft soil operations and to counterbalance rear wheel horsepower, weight should be added to the tractor in the form of front, middle and rear weights as shown in figures 28 through 36 in combination of sets. Only enough weight should be added to give the required traction and stability.

Adding more weight than is needed causes unnecessary soil compaction and increased fuel consumption and thus increased cost per acre.

NOTE: When adding weight, adhere to the following sequence. Refer to "Tire Pressure" and the "Tire Weight Selection" sections in the "Load" table on page 20.




Figure 26 - Front Wheel Weights

WEIGHTING LIMITATIONS

The weighting limitations for the various states in which we do not imply that the maximum weight should be applied to just the weight shown. The only weight limit is to obtain good performance and traction and the torque requirements.




Figure 27 - Rear Wheel Weights

OPERATION




Figure 28 - Front End Weights

CAST IRON WEIGHTS (OPTIONAL)

Cast iron weights are a factory installed option or are available by special order from your IH SHIRL/R.A. Tractor Dealer. Weights can be mounted on the front wheels or the front end of the tractor, and on the rear wheels as shown in Figure 28 through 29.

LIQUID BALLAST

It is common practice to add weight to the tractor by filling the rear tires with liquid ballast. A maximum of 100 liters water per tire is recommended due to its low density, light and greater durability (weight per gallon) than other liquids. Maximum recommended weight for the tractor because spec'd requirement is exceeded and the IH Shirl recommends that you contact your IH SHIRL/R.A. Tractor Dealer. In the three cases listed below (Figure 28-30) based on the total tractor weight the value shown is 27.6 kg/gallon (100 liters).

TIRE PRESSURE

For pressure charts, see addendum concerning weight on the tractor. The following TIRE INFLATION vs. PERMISSIBLE LOAD chart lists the tire sizes available & shows the maximum load for a given air pressure. Note that the load capacity decreases as inflation pressure decreases, and also that a pressure of 24 psi is recommended for normal operation.

TIRE INFLATION vs. PERMISSIBLE LOAD


| FRONT TIRE SIZE | INFLATION PRESSURES - kg/cm ² | | | | | | | |
|-------------------------------|--|-----|-----|-----|-----|-----|-----|-----|
| | 0.8 | 1.0 | 1.2 | 1.4 | 1.6 | 1.8 | 2.0 | 2.2 |
| MAXIMUM PERMISSIBLE LOAD - kg | | | | | | | | |
| 6.00 x 16 F-2 4PR | - | 315 | 345 | 370 | 395 | 420 | 445 | |
| 8.18 G1 4PR | 300 | 340 | 380 | 415 | 450 | 480 | - | |
| REAR TIRE SIZE | INFLATION PRESSURES - kg/cm ² | | | | | | | |
| | 0.8 | 1.0 | 1.2 | 1.4 | - | - | - | - |
| MAXIMUM PERMISSIBLE LOAD - kg | | | | | | | | |
| 12.4/11 x 28 R-1 4PR | 850 | 945 | - | - | - | - | - | - |

NOTE: Do not exceed the maximum load. Also, do not exceed tire pressure indicated.

LUBRICATION AND MAINTENANCE

LUBRICATION AND MAINTENANCE CHART—SD4300 SD5000T

TWO-WHEEL DRIVE




| LUBRICATION AND MAINTENANCE ITEMS | SERIAL NUMBER | SERVICE INTERVALS | LUBRICATION AND MAINTENANCE ITEMS | SERVICE INTERVALS |
|---|---------------|-------------------|-----------------------------------|-------------------|
| | | | | |
| 6. Engine Oil Level | 1 | 1000 Hrs. | 2. Gear Lube | Every 500 Hrs. |
| 10. Fluid Maintenance | 2 | 1000 Hrs. | 3. Water Filter | Every 500 Hrs. |
| 13. Air Cleaner Dust Filter | 3 | 1000 Hrs. | 4. Fuel Filter | Every 500 Hrs. |
| 8. Brake Oil | 4 | 1000 Hrs. | 5. Engine Oil Filter | Every 500 Hrs. |
| 10. Transmission and Rear Axle Oil | 5 | 1000 Hrs. | 6. Gear Oil | Every 500 Hrs. |
| 4. Front Differential Oil | 6 | 1000 Hrs. | 7. Prop. Shaft | Every 500 Hrs. |
| 7. Front Spur | 7 | 1000 Hrs. | 8. Inspection Points | Every 500 Hrs. |
| 12. Intermediate Gear Box and Rear Axle Oil Level | 8 | 1000 Hrs. | 9. Front Axle and Rear Axle Oil | Every 500 Hrs. |
| 11. Front Axle | 9 | 1000 Hrs. | 10. Front Gear Oil | Every 500 Hrs. |
| 1. Steering | 10 | 1000 Hrs. | 11. Front Gear Oil Change | Every 500 Hrs. |
| 5. Front | 11 | 1000 Hrs. | 12. Front Wheel Bearing | Every 500 Hrs. |
| 21. Clutch Pedal | 12 | 1000 Hrs. | 13. Front Oil Change | Every 500 Hrs. |
| 19. Braking Pedal | 13 | 1000 Hrs. | 14. Air Cleaner Change | Every 500 Hrs. |
| 20. Steering Linkage | 14 | 1000 Hrs. | 15. Front Wheel Bearing | Every 500 Hrs. |
| 2. Front Spur | 15 | 1000 Hrs. | 16. Front Oil Change | Every 500 Hrs. |
| 18. Ring Gears | 16 | 1000 Hrs. | 17. Front Wheel Bearing | Every 500 Hrs. |
| 12. Hyd. Oil Circuits | 17 | 1000 Hrs. | 18. Front Oil Change | Every 500 Hrs. |
| | 18 | 1000 Hrs. | 19. Air Cleaner Change | Every 500 Hrs. |

LUBRICATION AND MAINTENANCE

LUBRICATION AND MAINTENANCE CHART-SD4340 SD5040T

FOUR-WHEEL DRIVE



| MAINTENANCE ITEM | CURE | SERVICE INTERVALS | |
|--|-----------|-------------------|------------|
| | | 1000 HRS. | 1000 MILES |
| 1. Engine Oil Level | 1000 hrs. | 1000 hrs. | 1000 miles |
| 2. Radiator Coolant | 1000 hrs. | 1000 hrs. | 1000 miles |
| 3. Air Filter Element | 1000 hrs. | 1000 hrs. | 1000 miles |
| 4. Transmission Oil Level | 1000 hrs. | 1000 hrs. | 1000 miles |
| 5. Differential Oil Level | 1000 hrs. | 1000 hrs. | 1000 miles |
| 6. Front Axle Oil Level | 1000 hrs. | 1000 hrs. | 1000 miles |
| 7. Rear Axle Oil Level | 1000 hrs. | 1000 hrs. | 1000 miles |
| 8. Hydro Clutch Oil | 1000 hrs. | 1000 hrs. | 1000 miles |
| 9. Fan Belt | 1000 hrs. | 1000 hrs. | 1000 miles |
| 10. Gearshift Lever and Shift Axle Oil Level | 1000 hrs. | 1000 hrs. | 1000 miles |
| 11. Fuel Filter | 1000 hrs. | 1000 hrs. | 1000 miles |
| 12. Power Steering Oil Filter | 1000 hrs. | 1000 hrs. | 1000 miles |
| 13. Battery | 1000 hrs. | 1000 hrs. | 1000 miles |
| 14. Tires | 1000 hrs. | 1000 hrs. | 1000 miles |
| 15. Clutch Vane, Lubricant & Fitting | 1000 hrs. | 1000 hrs. | 1000 miles |
| 16. Universal Joints | 1000 hrs. | 1000 hrs. | 1000 miles |
| 17. Drive Axles | 1000 hrs. | 1000 hrs. | 1000 miles |
| 18. King Pins | 1000 hrs. | 1000 hrs. | 1000 miles |
| 19. U-Joint Pitman Arms | 1000 hrs. | 1000 hrs. | 1000 miles |
| 20. Differential Carrier | 1000 hrs. | 1000 hrs. | 1000 miles |
| 21. Air Cleaner - Intake | 1000 hrs. | 1000 hrs. | 1000 miles |

LUBRICATION AND MAINTENANCE

FUEL AND LUBRICANTS DIESEL FUEL

Level of fuel 12.0%

When ambient air temperature drops to -6°C (21°F), the diesel fuel is 30% / 2 (See 2.1) or 0.6 mm sediment content resulting in 45.4% sediment (fuel) at -10°C (14°F) and 0.6% / 2 (-20°C (-4°F)). Use Diesel fuel 20 No. 1 (ISO 11159) with minimum sediment content of 0.6%.

The representation is a major portion of your fuel tank exceeding double pressure in the injection system, it is 17°C (63° F). Do not let the pressure drop below the minimum value. Use the tank oil 50% in the filter housing or from your service station. Please note that there are no pressure gauges in the system.

NOTE: Use only fuel designed for diesel engines. When heating fuel tanks in harmful chemical areas, always use secondary fuel storage efficiency in particular areas. Refer to also "Figure 33 - Fuel contamination" on page 72 for additional fuel information.


FUEL STORAGE

Extremely small clearance exists between the individual nozzle elements of the fuel injection system and the fuel delivery elements of the injectors. Therefore, it is extremely important that precautions be taken to make sure that fuel in both lines of the system stays clean. See Figure 33.

Fuel used should be stored in tanks or containers so that the fuel does not come into contact with metal parts, such as the fuel filter bowl. Insert with the fuel filter filter paper, allowing the filter paper to come into contact with the probe, bottom of the fuel injection pump and a piston.

The most common cause of clogging is a lack of oxygen in the fuel which causes the fuel to stagnate. Figure 34 shows gravity feed circulation. Inject fuel through the fuel filter bowl. The fuel filter bowl is held 100% above the tank. The tank should slope upward after the tank to allow sediment to settle away from the take-off point. When ever the tank is refilled, allow the take-off point to be 10% above the tank. After filling, a drain valve must be drained out at the lowest point in the tank. Any sediment and sludge can be drained out of the tank.

After the engine has started, turn the fuel pump switch off and open the fuel tank. If you notice any noise, stop the engine immediately and repair the fuel line.



But...

Dirt or immediately filtered fuel makes it necessary to have a fuel pressure as low as 50% less than that in the injector lines.

This causes loss of fuel efficiency and engine power. Diesel fuel combustion and the possibility of water and sediment accumulation start to pollute fuel and damage the pump. This can also cause rough engine operation.





Figure 33 - Dirt vs. Injectors

LUBRICATION AND MAINTENANCE



Initially, a storage container above the ground and built into the side of a hillside is best for the fuel storage tank. A tank provides a relatively flat site at the lowest point of the hillside so that cleaning and maintenance can be done most easily. It is also desirable to have all the discharge outlets of the tank at one level.



On the hillside, each tank contains a pump for circulation purposes. They are situated on their stands. The fuel system should be cleaned and checked every 100 hours of use.

Figure 34 - Diesel Fuel Storage

2. Fuel quality: Diesel should be used, as shown in Figure 34. Use the latest type benzene and kerosene fuel as indicated in specification.

If bulk storage is not possible and the tank is stored outdoors, keep them in a clean, dry place. The fuel storage tank should be fitted with a fuel filter to remove water and dirt and should be transported in vehicles that have a 1.7 m pump length away from the tank.

After unloading the tank at the top of the bank, and again when the value of any fuel has been used, Diesel fuel will take care of any dust and dirt.

REFUELING THE TRACTOR

It should be noted that the order of the storage tank, filter, the fuel pump and filter is incorrect to filter water when filling the tractor's fuel tank. Keep the tractor tank as low as possible to avoid water contamination.

NOTE: It is a good practice to fill the tractor fuel tank with fuel at the end of each day, as this will reduce overnight condensation. After any fuel which may have been spilled should be removed.

LUBRICANTS

Type of Lubricant: SAE

Synthetic Oil

Service Grade CD

SAE 10W-30 or 10W-40 for your application

SAE 10W-30 in severe cold unless SAE 10W-30

SAE 20W-50 in winter use 0°C and 20°F

SAE 30W-40 in summer use above 35°C (95°F)

NOTE: When using Diesel fuel with available ambient below 10°C, do not mix oil with an API 10W-30 or less oil. SAE 10W-30 or used engine oil or CD oil, but the oil change interval must be reduced to 50 hours and the filter must be changed every 100 hours. When the total operating time is greater than 1000 hours, then a 3% oil dilution must be used except for temperatures below -7°C. An unused service oil change interval must be reduced to 50 hours, and the filter must be changed every 300 hours. To make up for the extra oil, a sufficient amount of fuel must be added to the tank to make up for the fuel lost due to oil dilution.

Filter: Diesel

Fuel Filter

Hydraulic System: SAE 10W-30 or 10W-40, API CD

Power Steering Oil: SAE 10W-30 or 10W-40, API CD

Clutch/Brake Fluid: DOT 3

and ABS Fluid: DOT 3

LUBRICATION AND MAINTENANCE

LUBRICANT STORAGE

SUZUKI TRAILER IS EQUIPPED WITH LUBRICANT TANKS IN POSITION #1 AND #2. THE CARTRIDGE USED BY THE TRAILER MAY NOT BE USED FOR THE SUZUKI COUNTRYMAN. PRECAUTIONS MUST, HOWEVER, BE TAKEN BY YOU TO PREVENT LUBRICANT CONTAMINATION OR LEAKAGE DURING STORING. THESE CARRIERS IN THE TRAILER ARE BASED ON THE ASSUMPTION THAT ONLY ONE TYPE OF OIL IS USED.

BOTTLES OF LUBRICANT SHOULD BE KEPT UNDER COVER, PREFERABLY IN A CLEAN, DRY PLACE, AND SHOULD NOT BE EXPOSED TO SUNLIGHT OR HEAT WHICH MAY DAMAGE THEM.

WHEN A CARTRIDGE IS LEFT IN AN EXPOSED POSITION, IT SHOULD BE REFERRED TO AS A "STANDBY" AND SHOULD NOT BE REMOVED FROM THE TRAILER UNTIL AN ALTERNATIVE IS MADE WHEN CONSIDERING THE USE OF A PART IN THE EQUIPMENT, AND MORE THAN A DAY OR TWO, WHEN THIS HAS BEEN REMOVED, IS ADVISED OF APPROXIMATELY.

1. THE SUZUKI HOLLOW TUBE FILTER IS TO BE FILLED WITH OIL. POUR OIL THROUGH THE FILTER LINE TO 5MM FROM THE TOP EDGE BETWEEN THE LOWER AND UPPER SECTION OF THE FILTER.

2. SEAL THE FILTER LINE.

CHANGING OIL AND FILTER. CHANGE THE ENGINE OIL EVERY 100 HOURS AND THE FILTER AFTER EVERY 200 HOURS.

NOTE: NEVER REUSE ENGINE OIL AND FILTER CHANGER AND FILTER CHANGER. IF THE TRAILER IS OPERATED IN EXTENDED PERIODS OF TIME IN THE SUMMER, TURN DOWN SPEED UNLESS WITH CAREFUL DRIVING. IN WINTER, OPERATE IN EXTENDED OPERATING CONDITIONS. THE ENGINE OIL SHOULD BE CHANGED 1) EACH MOTION AND THE FILTER AT 150 HOURS MAXIMUM.

1. WARM THE ENGINE TO 80°, BUT AT NORMAL OPERATING TEMPERATURE. DRAIN THE ENGINE OIL BY FOLLOWING THE PROCEDURE IN FIGURE 36. REACTIVATE THE FILTER AFTER THE OIL HAS BEEN DRAINED, AS INDICATED IN

FUEL AND LUBRICANT SERVICE PROCEDURES ENGINE

Checking Oil Level: Check the engine oil level during every 100 hours.

1. WITH THE TRAILER STANDING LEVEL, AND OVER THE GROUND AS SHOWN IN FIGURE 35, CHECK THE OIL LEVEL WITH THE DIPSTICK. FIGURE 36




Figure 35 - Engine Oil Level Dipstick and Filler Cap




Figure 36 - Engine Oil Drain Plug

2. REMOVE THE OIL FILTER (FIGURE 37), DRAINING THE USED OIL. HOLD THE CARTRIDGE PLUG IN OVER THE FILTER. DISPOSE OF FILTER.
3. COAT THE GASKET ON THE NEW FILTER WITH A LAYER OF OIL. SCREW THE FILTER JACKET ON PROPERLY SO THE GASKET CONTACTS THE FILTER SURFACE; THIS COATS THE FILTER APPROXIMATELY 3/4 OF A TURN clockwise. DO NOT OVER-TIGHTEN.
4. ADD NEW OIL AT THE SPECIFIED RATE (SEE FIGURE 24). TURN THE ENGINE AND CHECK THE FILTER FOR LEAKS AFTER 30 MINUTES. THE FILTER MUST NOT LEAK AT THIS POINT.

LUBRICATION AND MAINTENANCE




Figure 37 - Engine Oil Filter

THE FUEL INJECTION PUMP

Check the fuel pump assembly every 200 hours or every 100 miles. (Figure 38)

To make the following test add new engine oil as specified on page 24.




Figure 38 - Fuel Injection Pump

FUEL FILTER

Draining the Filter: Drain the diesel fuel filter when condensation is suspected.

Cleaning the Fuel Filter: Clean the fuel filter every 100 hours or 500 miles of clean diesel fuel.

1. Drain the filter assembly. Use a screwdriver and pliers to remove the filter housing. (Figure 39)




Figure 39 - Fuel Filter

2. Clean the filter element and replace it if new fuel has been pumped through it.

3. Install the fuel filter element and screw the bowl and filter assembly back into the fuel system. (See *Replacing the Fuel System* on the next page.)

Changing the Fuel Filter: Change the filter for filters with different sizes as follows:

1. Disconnect the fuel lines. (Figure 39)
2. Loosen the fuel filter and take it apart.
3. Carefully tighten the saddle and gasket.
4. Install the fuel filter assembly following the outlines in the following procedure.

LUBRICATION AND MAINTENANCE

BLEEDING THE FUEL SYSTEM

Bleed the fuel system if:

- the fuel filter has been replaced.
- a new filter element has been installed.
- the fuel filter has been cleaned.
- the filter housing or line from the filter have been disconnected.
- the injection pump has been removed and reinstalled.

Bleed the fuel system as follows:

1. Obtain three 1/4" pipe fittings and three nuts.
2. Attach the feed filter air vent screw, Figure 39, on top of the filter. Bleed the filter by attaching one piping point to piping, Figure 39, and another fitting from the filter, then attach the same to pipe.
3. Connect the air vent pipe to the air vent screw, Figure 38, at least one-half inch away from the screw. Then tighten the screws.
4. Put the hand throttle to the high speed position. Turn the engine over until a few pockets of air bleed through the fuel line.

AIR CLEANER ELEMENT AND DUST PAN

Remove the dust pan and clean the body of the air cleaner. Cut green, the evergreen type, off the element. Blow the air from the inside of the element. If it will not blow, remove the element and soak it in the water for several minutes. If the element has turned remarkably, turn it in neutral rotation (rotation about 180 degrees). Shake it gently, rinse in clean water, dry and dry in the sun to expand the fibers.

Check the element every 100 hours and replace every year of service, depending on usage.




Figure 40 - Air Cleaner

IMPORTANT Install the filter with the "O" ring directed upward. Improper installation causes wind resistance to attach to the base directly without sealing along the outer rim, reducing the service life of the element considerably.

LUBRICATION AND MAINTENANCE

TRANSMISSION, REAR AXLE AND HYDRAULIC SYSTEM

Checking Oil Level: Check the oil level every 20 hours.

1. With the tractor standing level and the engine off, check the oil level with the dipstick. Figure 41.
2. The oil level should not be below the lower mark or the upper level above the upper mark. If low add new oil of the type specified on page 24 and recheck the oil level.
3. Operate the rear axle for 10 minutes.
4. Check oil level again.
5. Turn the idle lever clockwise.




Figure 41 Transmission, Rear Axle and Hydraulic System Oil Level Dipstick and Fill Plug

Changing Oil: Change the oil every 300 hours.

1. Warm the engine up for approximately 10 minutes by operating the transmission and rear axle selections. Figure 42. As you heat it, proceed down inside the machine. Detach the plug after the oil has drained. Discard the oil.
2. Insert the filter plug. Figure 42, and add oil through the type listed on page 24.
3. The oil temperature is that of the correct flow when the oil is held between the top and the lower end of the dipstick. Detach the dipstick mark on the stick, as the transmission will be overfilled.
4. Turn the idle lever clockwise.

IMPORTANT: Service this tractor with 10W-30 oil for the transmission, rear axle and hydraulic system. Special oil may be required to maintain a car oil.




Figure 42 Transmission, Rear Axle Oil Drain Plugs and Filter

HYDRAULIC SYSTEM FILTER

Check operation of the filter after 90 hours. Clean or replace filter if necessary. Clean the filter every 100 hours and change it every 300 hours of service. The filter is located by the pump on the front left side of the engine.

1. Turn the idle lever clockwise. Figure 43.




Figure 43 - Hydraulic System Filter

LUBRICATION AND MAINTENANCE

2. Replace filter by in front of the engine.
 3. Remove oil pressure filter element from retaining and mounting sleeve.
 4. Push filter part 1 into and retighten sleeve back to original position.
- IMPORTANT:** Check filter connection and washer seat for damage, warp and/or leakage.
5. Position housing and spark plug engine side of 110 degree cooling fins with rear body. Retain all four.
 6. Connect oil and open oil drain screw from engine oil tank.

STEERING GEAR HOUSING (TWO-WHEEL DRIVE SD4300, SD5000T)

Checking Oil Level: Check the oil level of the steering gear housing every 600 hours.

1. Remove the two nuts.
2. Manually operate until level of the housing by turning the steering wheel (figure 44).
3. The oil should be level with the bottom of the housing hole, or 0.25 in. (6 mm) below the top of the type selected (see page 32).
4. Install the filter plug and the fastener.




Figure 44 — Steering Gear Housing Filler Plug

LUBRICATION FITTINGS

The following points refer to the lubrication chart, page 21 or 22. Service lubrication every 50 hours or continue early condition; lubrication cycle can be made more often. Refer to page 24 for the year or model that should be used.

- Steering oil cap
- Front wheel bearings
- Clutch cable
- Prop shaft
- Front end driveshaft bearing supports
- Power shaft

1. Wipe away all old grease and oil from the lubrication fittings and bearing supports before adding the new grease or oil.

2. Use a high pressure grease gun to force in the new grease and clean excess grease from the assembly being filled.

3. Reassemble and torque nuts.

FOUR-WHEEL DRIVE (SD4340, SD5040T)

Upper King Pins

Service the upper king pins at least 45° after every 50 hours of operation, under normal conditions. Lubricate early condition. Lubrication cycle can be made more often. Use a grease quality recommended. Lubricant grade




Figure 45 — King Pins Lubrication Points and Front Axle Differential Fill and Level Check Port

LUBRICATION AND MAINTENANCE

FINAL REDUCTION GEAR CASES

Checking Oil Level: Check the oil level in each final reduction gear case every 50 hours. Do this after turning on the oil flow switch (Figure 46) to both the cases. The oil should be level with the bottom of the sight window.

Changing Oil: Drain oil with the reduction gear case at least every 200 hours of operation by removing the drain plug (Figure 46). Use multi-grade oil, mineral or a high quality, extreme pressure gear lubricant over 50 and shear stability. Refer to the following chart for recommended viscosity grades.

| TEMPERATURE | VISCOSE INDEX @ 20°C |
|-------------|----------------------|
| Initial | SAE 60 |
| Drain | SAE 90 or 100 |

The transmission and rear differential should be checked every 200 hours. See your IH Service Manual for more details.




Figure 46 - Final Reduction Gear Case Fill and Drain Plugs

FRONT AXLE DIFFERENTIAL CASE

Checking Oil Level: Check the oil level in the front axle differential case every 50 hours. Do this after turning on the oil flow switch (Figure 46) to both the cases. The oil level should be level with the bottom of the sight window.

Changing Oil: Drain oil from the differential case every 300 hours by removing the drain plug (Figure 47), thoroughly wash a high quality, extreme pressure gear lubricant with mineral base additive. Refer to the following chart for recommended viscosity grades.

| TEMPERATURE | VISCOSITY GRADE |
|-------------|-----------------|
| Initial | SAE 50 |
| Drain | SAE 80 or 100 |




Figure 47 - Front Axle Differential Drain Plug

LUBRICATION AND MAINTENANCE

POWER STEERING RESERVOIR LUBRICATION AND MAINTENANCE (FOUR-WHEEL DRIVE SD4340, SD5040T)

Checking Oil Level: The oil level in the power steering reservoir should be checked every 50 hours. The reservoir is located at the under side of the front fender. The fluid plug is located at the front of reservoir. The check valve is located below the reservoir.

1. When the car is standing still, turn the wheel to the extreme toward position. Check the oil level. (Figure 48)
2. The oil level should be up to the top of the low side neck of the tank. If not add oil, pour the oil until it reaches the top of the neck.
3. Stop the engine and turn the steering wheel from side to side several times to allow the oil to circulate throughout the system.
4. Start the engine and reduce the oil pressure as required and repeat Step 3.




Figure 48 - Power Steering Reservoir and Oil Level

Changing Oil Filter: Change the oil filter every 500 hours. The filter is located at the front of the reservoir. (Figure 49)

1. Drain the oil from the reservoir.
2. Remove the filter cap by loosening the lock nut.
3. Remove the filter body and screw the filter to the reservoir.
4. Replace the cap and tighten securely.
5. Add oil to the reservoir according to the recommended specification.

IMPORTANT: The front fender should be coated with liquid paint when repainting.

6. Turn the reservoir with clockwise direction.
7. Turn the oil filter clockwise. (See Figure 49)
8. Start the engine and turn the steering wheel from side to side several times to allow the oil to circulate throughout the system.
9. Stop the engine and turn the oil filter clockwise again and repeat Step 7.




Figure 49 - Power Steering Oil Filter

LUBRICATION AND MAINTENANCE

GENERAL MAINTENANCE TURBO-CHARGER SYSTEM (SD5000T, SD5040T)

The SD5000T and SD5040T Turbo-Charger System. The system consists of the turbo-charger and a drive belt for cooling. It can fail from overheat.




Figure 5C - Turbo-Charger

If the engine load changes rapidly, heat will quickly generate more oil shear time and this will occur seconds. This is the problem because the engine is driven with the existing oil to compensate the slight increasing the load rate.

This transient load is applied to the engine after the torque converter shifts, the clutch should not be applied when the clutch is engaged. To prevent this, decrease the load when the engine speed 2200 rpm or more, since the turbocharger has been used to increase the load, switch the engine speed.




Figure 5I - Turbo Charger System

PRECAUTIONS FOR OPERATION OR TRACTOR

1. Never fail to warm up the engine for 5 to 10 minutes. In cold dust, warm up the engine for a longer time to warm the oil for smooth fuel delivery before starting the work.
2. Do not drive continuously for longer than 20 minutes at a time. Therefore, if the engine is stopped for 10 minutes, the rotation of the fan should be 20 minutes off so that it may not heat the bearings or other parts, reducing their life, or causing serious accidents.

Stop the engine after long operation for about 5 minutes.

3. The lubrication oil of the engine must be maintained with the engine because to keep the engine at a proper level. Replace the oil and oil filter according to the Oil Lubrication Chart on page 21 or 22.

LUBRICATION AND MAINTENANCE

COOLING SYSTEM

The engine water system CHRYSLER Engine Coolant with ten-year life additive.

To obtain optimum efficiency and performance from the engine, it must operate at the correct temperature. This is dependent on the cooling system. The system should be kept filled with a 50/50 mixture of coolant (the filterless and biodegradable) for your engine's service.

Checking Coolant Level: Check the coolant level after driving 10 hours.

- Check the coolant level. It must not be less than 1/2 and 1/2 of the coolant reserve tank.
- If the coolant level is below 1/2 the low and over 1/2 the high level, add antifreeze/glycol mixture until the cooling system is ready to run. Remove the top cap of the coolant reservoir tank and add a 50/50 mixture of coolant (the filterless and biodegradable) to the radiator and engine block drain valve. Do not overfill. To reduce the chance of leakage, do not overfill the coolant to a point above the low level line. However, to change the coolant or check the radiator, do not open the coolant drain valve. The radiator drain valve is located on the bottom of the radiator, just above the cap on the radiator.

CAUTION: Do not try to remove the top cap of the coolant reservoir tank while the engine is hot. The tank may burst if you attempt to do so. If the tank bursts, the liquid will spray out and cause severe burns. If you are exposed to the liquid, wash the skin immediately with water. If you are exposed to the liquid by breathing it in, get fresh air immediately. If you are exposed to the liquid by swallowing it, do not induce vomiting. Get medical attention immediately.

IMPORTANT: Alcohol-type antifreeze is not recommended. Do not use alcohol-type antifreeze and coolant mixtures.

- Keep the radiator free of debris or dirt to insure free air flow.

Draining and Flushing the Cooling System: Drain and flush the radiator and engine block every 12 months. If the owner wants to store or store of less than 1/2 year, do not drain and flush water.

Draining the System

- Park the vehicle and set the transmission between Neutral and the reverse block. The radiator drain valve is located on the bottom left side of the radiator. (Figure 52). The engine block drain valve is located on the left side of the engine. See Figure 52.
- After the coolant has drained, plug radiator drain in the radiator drain neck and connect through the system with an empty bottle. Make sure water is cold. Turn on the drain valve and begin draining. When the water begins to turn clear, close the drain valve. Turn off. Allow all water to drain from the system before opening valves.
- Close the radiator drain valve. Open the system with a 50/50 mixture of coolant and antifreeze and clean system.

Repeat steps 1 until the coolant level in the reserve tank reaches between the 1/2 and 1/2 marks.




Figure 52 Radiator Drain Valve and Engine Block Drain Valve

- Open the radiator drain valve. Turn the tap.
- Open the engine block drain valve. Turn the tap.
- Turn the engine on to heat up the cooling system. Do not overheat the engine. If the engine overheats, turn off the engine. Once the engine has cooled down, turn the engine back on and repeat the procedure until the engine is cool.
- Reopen the radiator and engine block drain valves.

LUBRICATION AND MAINTENANCE

IMPORTANT: Never run the engine when the cooling system is empty, and do not add cold water or cold antifreeze solution if the engine is hot.




Figure 53 - Radiator Screen

Thermostat: The thermostat is located in the coolant outlet cylinder in the front of the cylinder head. It opens at:




Figure 54 - Thermostat Housing

When the engine is cold, the thermostat is closed to prevent coolant from getting through to the radiator, thus allowing the engine to quickly warm up. As the engine begins to heat up, the coolant begins to circulate within the engine, warming the thermostat until it opens to the radiator.

IMPORTANT: Do not increase the thermostat's temperature to 105°C during cold weather because the engine will not cool down to normal operating temperatures, resulting in extensive engine wear.

It is overly recommended to install a new thermostat, since it may get stuck in the closed position, causing the heat exchanger to overheat. If the heat exchanger overheats, it will damage the cylinder head.

Fan Belt: A belt drives the fan to cool the engine down via the fins of the radiator to cool the coolant in the radiator. While many factors affect the efficiency of the fan assembly, the engine running temperature of the belt is the most important factor in the fan's performance. The fan assembly turns at 3000 rpm at 1715 rpm/min when 9 to 11 kN (20 to 25 pounds of pressure) is applied to either pulley. Check the condition of the belt in the fan assembly every 20 hours. If the belt is over-tight, packing or greasing may be required.

Replacing Fan Belt:

1. Turn off the alternator, disconnecting battery, as shown in Figure 55.



CAUTION: Make sure the alternator is disconnected from the engine before attempting to remove the mounting bolts.

2. Pry the alternator away from the engine and tighten the mounting bolts.

Checking Tension:




Figure 55 - Alternator Mounting Bolts

LUBRICATION AND MAINTENANCE

FUEL INJECTOR REMOVAL AND INSTALLATION

The injectors should be cleaned, tested, and reinstalled using special tools. Do not use any one of the following methods to remove fuel from the injector orifice and base: hammering, heat, HCl, HNO₃, H₂SO₄, H₃PO₄, NaOH, Trichloro-Diesel.

Procedures for the injection:

1. Clean the lower deck front around the injectors and tank. Disconnect the leak-off pipe from the injector. Figure 56.
2. Unconnect the injector pressure line at the pump and injector. Take care not to kink the lines. If the injector is not being reinstalled immediately, prevent the entry of air.
3. Remove the disc and spring retainer to withdraw the fuel injector from the cylinder head. If a special set of injectors is not available, use the Lyco system to clean the orifice.

After the injectors have been cleaned, install them as follows:

1. Place each cleaned injector assembly in the cylinder head.
 2. Insert a new upper seal (seal ring) in each injector. Thread the base of the injector and tighten the retaining nut to 37 kgm (38 N·m).
- IMPORTANT:** Do not overtighten the retaining nut. Over-tightening may distort the injector.
3. Install the injector lines. Turn clockwise the 1/4 turn at the injector until either end of the fuel system is seated. Turn the fuel line on the injector pump to 2.5 kgm (24.3 N·m).




Figure 56 – Fuel Injector Leak-off Lines

4. Tighten leak-off line. Figure 57. Turn clockwise the leak-off line approximately 30-39 N·m.
5. Clean and lubricate the lever used under "Base Throttle" Figure 57, page 27.

ENGINE SPEED ADJUSTMENT

To adjust engine for maximum forward speed, set the idle speed according to the following procedure:

1. Loosen the lock nuts. Figure 57.
 2. Keep the foot throttle pedal at the same level as the intake air temperature plate.
 3. Set the maximum idle speed to 2620-2670 rpm, using the tachometer.
 4. Shut off the fuel pump.
- IMPORTANT:** Do not start the fuel pump while it is removed from the foot or intake air level of the foot throttle plate.
5. Move the idle idle lever. Check for smooth resistance in both directions of the position.
 6. Tighten the lock nuts the resistance control.
 7. Set the idle speed to 700-800 rpm. Go through the next




Figure 57 – Throttle Adjustment

LUBRICATION AND MAINTENANCE

VALVE CLEARANCE (LASH)

Correct valve clearance is one of the most important items of engine maintenance. Correct clearance will ensure the engine will operate经济地 and efficiently, clear insufficient clearance will result in the engine overheating. If this is extremely important, the gap can be easily set or adjusted.

Checking and Adjusting Valve Clearance: Check and adjust the valves every 500 hours. To decrease gaps and increase stroke, make the valve cold.

1. Remove the valve cover and crankcase.
2. With the engine idling, check the clearance of each valve with a vernier caliper gauge (Figure 59).

The setting is as follows:

Intake = .012 in.

Exhaust = .012 in.

3. If the clearance is incorrect on any valve, turn the plug screw at the back of each of the valves to increase or decrease it until the gap is the correct setting for normal clearance with the specified gauge.
4. After the adjustment has been made, if the valve is damaged, try to have it fully repaired.




Figure 59 Checking Valve Clearance

BATTERY

Keep the battery terminals tight and free of corrosion. An annual cleaning with water and vinegar is good for safety; the acidic solution will remove the battery sulfation. Wash the battery with clean water. Apply a small amount of petroleum jelly to the terminals to protect them from corrosion.

In freezing temperatures, the battery must be maintained at a peak state of charge. When a battery is discharged, the electrolyte is weak and may freeze, causing damage to the case. If it becomes necessary to add water, do not add water to the top of the case; add water to the bottom of the case, the water will then move up to the top of the case to prevent the water from freezing.

Checking Electrolyte Level: Check the electrolyte level in the battery every 50 hours.

CAUTION: Acid is very dangerous to the eyes and skin. If acid gets on your skin, wash it off immediately with large amounts of water. If acid gets in your eyes, flush them with water for 15 minutes and seek medical attention immediately.

1. Clean the top of the battery, then remove the top cap.
2. If the electrolyte level is low, add distilled water. The acid is concentrated in the top by 6.0% in most batteries.
3. Be careful when adding water, this will cause the water to boil and burst. At lower freezing temperature, be sure to pour the water from a period of time after adding water, so the battery will dry up and prevent the water from freezing.

ALTERNATOR

The alternator (Figure 60) is not driven from the engine instead it is driven by a component that will always keep the output voltage the charging rate can be altered. Details of belt adjustment are given on page 54.

Other than belt adjustment, the only function required on the alternator is to periodically inspect it to make sure it is clean and tight, and that all belts are tight as stated on page 54.




Figure 59 - Alternator




Figure 60 - Voltage Regulator

When working on or checking the alternator, comply with the following precautions to prevent alternator damage:

- DO NOT connect any circuit breaker, short the F1-LD terminal, or the alternator to ground.
- DO NOT use over the voltage regulator while the alternator is operating.
- DO NOT disconnect the alternator without disconnecting the battery cables before the alternator is operating.
- DO NOT remove the alternator from the engine without first disconnecting the negative (-) battery cable of the battery to be removed, due to the heat generated by the heat sink.
- If battery is to be installed, MAKE CERTAIN that the positive (+) cable is connected first and that the negative terminal is connected to ground. Reverse polarity will destroy the rectifier diodes in the alternator.

VOLTAGE REGULATOR

The voltage regulator, Figure 60, automatically controls the alternator output voltage. No attempt should be made to adjust the setting of the regulator.

If the Charge Indicator light illuminates and the alternator is not charging the battery, check the battery and the wiring connections. If these are normal, turn on the headlights. If they continue to indicate no charge, contact your IHESI/SHSMU/A Teacher/Instructor.

FUSE BOX

The fuse box is shown in Figure 61. Remove the fuse box cover by removing screws, and the plastic heat cover is easily removed by prying it off. Figure 26, AMM and I-Value Plus, are shown to easier identify appropriate fuses with the specified I-amp.




Figure 61 - Fuse Box

LUBRICATION AND MAINTENANCE

HEADLAMPS

Should a headlight fail, cover the damaged one replaced. To remove the bulb:

1. Remove the hood.
2. Remove the headlight wiring assembly from the top and disconnect wiring assembly from cavity.
3. Bend rubber boot back on the lamp socket. Figure 62
4. Pull on the glass retainer with the hand to release the bulb from its base.
5. Open the cavity. If necessary, make certain that an angle will properly seat the bulb. Failure to do so may lead to early failure. Remove bulb until it can be easily grasped. To prevent damage, avoid compressing spring retaining.




Figure 62 - Headlamp Assembly

WARNING LIGHTS

When changing lights, follow the steps in the following procedure:

1. Unclip the bulb retainer from the bulb and the intermediate plate.
2. Remove the intermediate plate at the back of the light.
3. Pull the lead wire off the bulb holding the root, and then the bulb is taken out.
4. Remove the bulb's plastic sleeve through retaining clip and turn the lamp counter clockwise to remove it.




Figure 63 - Changing Bulb of Warning Light

TURN SIGNAL LAMPS, BRAKE LAMPS and LICENSE LAMP

To replace the bulb:

1. Remove the retainer and take the bulb.
2. Hold a new bulb and insert the end of the lead wire assembly.

LUBRICATION AND MAINTENANCE

TIRES

Check tire pressure every 50 hours, or daily. Below the 17 psi inflation. My Tire Valley Load Reduction may be required. See the manual for use.

NOTE: If the rear body is equipped with liquid fuel, a second tire change should be made because the column might leak and water will run across the floor of the vehicle. See page 9.

After tire pressure is set, inspect the tire for damage and wear. Apply immediately. Replaced damaged tires to satisfy the factory.



CAUTION: Do not attempt to remove the tire from the wheel. Do not attempt to replace the tire on the wheel. Do not attempt to replace the tire on the wheel.

- Use a lip seal or O-ring when replacing front and rear wheels above 100° or 100° to withstand oil leakage.
- Do not inflate tire to a pressure over 2.4 bar (34 psi).
- Do not drive a tire unless the rim is mounted on the truck or trucked so that it is not loose. The tire must be securely fastened.
- Check the hub, bearing and wheel assembly for bullet holes and the tire has been impacted by more than 40% of its pressure.
- Do not use ozone, rubber cement, or use a de-solder gun.

FRONT WHEEL BEARINGS (TWO-WHEEL DRIVE SD4300, SD5000T)

The two-wheel drive uses the same spindles by inner and outer tapered roller bearings. An oil seal is used at the inner end of the spindle, see a diagram of the spindle, to retain the lubricant and to prevent dirt and other foreign materials.

Front wheel bearings should be replaced every 300 hours of service.

1. Apply the marking wax to both the spindle journals.
2. Remove front of the front wheel and spindle. Use Figure 65, the center part of the rear of Figure 65. Record the space for bearing and type the complete wheel assembly.

3. Remove the clip, the spacer, the oil seal from the center of the axle and the inner bearing from the wheel.

4. Thoroughly clean a portion of a suitable solvent and allow to dry naturally. Do not use compressed air. Paint the bearing cage and on the assembly. To measure the clearance, putting a weight of one kilogram firmly, check the bearing gaps.




Figure 65. Spacing Front Wheel Bearing Two-Wheel Drive (SD4300 and SD5000T).

5. Encase the axle and oil seal assembly in the clean paint. Do not use paint thinner. Pack approximately 0.25 oz (7 g) of grease in the space between the base of the axle in the hole, but do not pack the hub completely. Apply a thin layer of the seal to the top of the spindle.
6. Reapply the inner bearing, the oil seal and the oil seal in the rear of the axle.
7. Place the wheel assembly on the spindle and note the wheel bearing, front washer, and cage bearing. Tighten the nut at the 20% torque rating the wheel with a slight diagonal tension. Back off the nut until the bearing seat is the same distance with the base of the spindle. Apply a new outer paint seal washer, then the wheel cap.

LUBRICATION AND MAINTENANCE

STEERING WHEEL FREE PLAY ADJUSTMENT

Steering wheel play or the distance of rotation between the steering wheel hub and the column assembly, is shown in Figure 6C. If the play exceeds the indicated limit, adjustment is necessary.

1. Make certain all lock bolts are tightened properly. If necessary, see Adjustment and Tools section.




Figure 6B - Steering Wheel Free Play

2. Loosen the adjustment nut on the center hub of the steering gear box and turn the adjuster screw, see Figure 6D, counter clockwise to increase the free play until one of the adjustment markings is visible. Increase the steering wheel free play. Once the adjustment is made, tighten the adjuster lock nut securely.




Figure 6F - Steering Wheel Free Play Adjustment

FRONT WHEEL TOE-IN

Front wheel toe-in represents the wheel alignment error at the factory. Normally, the wheels are run straight; however, an adjustment should be made.

Checking Toe-In

1. Determine the straight-ahead position by turning the steering wheel fully clockwise and then反 clockwise. After turning the tractor forward with the straight-ahead position mark the front of the wheels from the front (wheel) fairing. Figure 6G.
2. Measure and record the distance between the front left wheel at the marks, then push the tractor forward with moderate speed, any further up the rear of the front.
3. Measure and record the distance between the front right wheel at the marks.
4. The difference between the distances recorded at Step 2 and 3 should be 0.16 to 1.024 in. (mean). The difference between the wheels should be 0.3 cm (0.12 to 0.394 in.) greater when the marks are on the exterior of the front.
5. If the measurement is not correct, adjust as outlined in the following procedure.

LUBRICATION AND MAINTENANCE

Adjusting Toe-in.

1. Loosen the lock nut.
2. Adjust the toe rod to provide a toe-in of approximately 13.01 ± 1.5 mm.
3. Note the correct toe-in is obtained; tighten the lock nut.
4. Re-tighten the toe rod and securely retighten the lock nut.

BRAKE ADJUSTMENT

Whenever the brake pedal travel exceeds 6 centimeters, or if the travel of one side is unequal to that of the other, adjustment must be made as follows in the following manner:

1. Check the master cylinder fluid level; add fluid if required and securely tighten.
2. Loosen the lock nut (Figure 63), and rotate the cable until the clearance between the two is $\pm 20-30$ mm ($0.79-1.18$ in.) of pedal free play.
3. Tighten the lock nut so that it will hold during the rest of the adjustment.




Figure 58—Checking Toe-in




Figure 69—Brake Pedal Adjustment

1. Turn on the master cylinder fluid breaking action, so that the wheel is equal. Repeat as necessary.

LUBRICATION AND MAINTENANCE

CLUTCH PEDAL ADJUSTMENT

To obtain optimum clutch feel, it is essential that the clutch pedal free travel distance (over 50 mm) is 60 mm to provide free travel at 50% load. If load > 70%,

1. Release the steering lock and drive SDA.
2. Turn the screw to increase or decrease free travel as required.




Figure 70 – Clutch Pedal Free Travel Adjustment

TRACTOR STORAGE

Tractors that are to be stored for an extended period should be prepared as follows. The following is a suggested list of operations to be performed:

1. Thoroughly clean the tractor. Use methylated spirit where necessary to prevent frost.
2. Unscrew the master cylinder on the front panel, empty reservoir and bleed.
3. Raise the front left hydraulic cylinder to the fully raised position. Place the left tractor wheel in the extended position. This places the cylinder from below, refer to the cylinder callouts on front panel diagram.

4. Lubricate the frame. Use end of motions 1, 5, 12, hydraulic system and rear axle with gear oil. Drain the engine oil and add with new lubricating oil. Lubricate the oil filter.

5. If the tractor is stored for extended times (over 6 months), an extended period, fuel oil and water should be taken. In addition, the fuel injection pump and the fuel filter valves should be checked and cleaned during the storage period.

- Before starting the fuel system, switch the fuel tank with a torch or a quantity of sand/wellingtons in the system when it is empty, when these for storage.
- Start the engine. Let it run until it is warm. Stop the engine, wait 10 minutes to ensure complete distribution of the sand/wellingtons. Turn the fuel pump lever clockwise 1/4 turn. Turn the fuel pump lever clockwise 1/4 turn. Turn the fuel pump lever clockwise 1/4 turn.
- Drain the fuel tank and wash the filter of the new filter with fuel, adding a little oil to the fuel tank.
- Run the engine for 10 minutes to ensure complete distribution of the sand/wellingtons. Turn the fuel pump lever clockwise. The engine need to run more than 10 minutes.
- Let the fuel tank well filled with fuel.

IMPORTANT: On step number 2, please note the engine storage time of 10 minutes, do not start the engine again until after 10 minutes.

6. Drain the oil and empty engine block. Wash the system, clean the diesel filter, and fit a new filter element and filter cap.
7. Charge the battery and clean it thoroughly. Be sure that the bulk charge goes that the terminals are in the groove and Place it in storage in a cool dry place above freezing temperature. The battery should be charged periodically during storage.
8. Remove parking brake, the parking brake is recommended during the time.
9. Close the hydraulic fluid opening.
10. Set the lock plane after depressing the clutch pedal, continue to operate the clutch pedal from the flywheel. (Figure 71).

LUBRICATION AND MAINTENANCE




Figure 71 Setting the Lock Plate of Clutch Pedal

Note that fuel with glazed in storage should be completely replaced in the following manner before using:

1. Dilute the fuel to the recommended orientation and remove the blocking.
2. Check the fuel lines in the tanks and transitions for losses. If any repairs are made, see Chapter 3, Installation, Clutch Assembly and Removal, for the latest information.
3. Install a fully charged battery and connect the electrical system. If the engine is not running, start it.
4. Check the cooling system. The system should be filled with a 50/50 mixture of ethylene glycol and distilled water.
5. Drainage of the tank plate or clutch pedal by disconnecting the master cylinder line, Figure 71.
6. Remove the engine and follow the procedure outlined below. Be sure the engine is operating at normal load and that both engines are turned off completely.
7. Clean the fuel line without fuel and check for leakage. If a repair is indicated, do it.

LUBRICATION AND MAINTENANCE

GENERAL TORQUE SPECIFICATION TABLE

USE THE FOLLOWING TORQUES WHEN SPECIAL TORQUES ARE NOT GIVEN

| Bolt Size | Diameter in inches | Torque in inch-lbs. | Grade instead | | Pre-tension | Final tension kg-cm | Torque kg-cm |
|-----------|-----------------------|------------------------|---------------|-----------|-------------|------------------------|-----------------|
| | | | To grip | kg-cm | | | |
| M 6 | 7/16 | 10 | 90-130 | 90-130 | - | - | - |
| | 5/8 | 10 | 100-140 | 100-140 | - | - | - |
| | 3/4 | 10 | 140-180 | 140-180 | - | - | 160-200 |
| M 8 | 7/16 | 1.25 | 210-300 | 210-300 | - | - | 260-320 |
| | 5/8 | 1.25 | 290-340 | 290-340 | - | - | 310-350 |
| | 3/4 | 1.25 | 370-410 | 370-410 | - | - | 400-420 |
| M 10 | 7/16 | 1.5 | 470-550 | 470-550 | - | - | 510-600 |
| | 5/8 | 1.5 | 590-650 | 590-650 | - | - | 630-720 |
| | 3/4 | 1.5 | 740-820 | 740-820 | - | - | 820-900 |
| M 12 | 7/16 | 1.75 | 710-870 | 710-870 | - | - | 770-900 |
| | 5/8 | 1.75 | 850-970 | 850-970 | - | - | 980-1080 |
| | 3/4 | 1.75 | 1060-1190 | 1060-1190 | - | - | 1190-1280 |
| M 14 | 7/16 | 2.0 | 1120-1320 | 1120-1320 | - | - | 1240-1450 |
| | 5/8 | 2.0 | 1390-1570 | 1390-1570 | - | - | 1570-1750 |
| M 16 | 7/16 | 2.0 | 1620-1890 | 1620-1890 | - | - | 1890-2100 |
| | 5/8 | 2.0 | 1780-2010 | 1780-2010 | - | - | 1910-2120 |
| | 3/4 | 2.0 | 1920-2180 | 1920-2180 | - | - | 2050-2210 |
| M 18 | 7/16 | 2.5 | 2180-2370 | 2180-2370 | - | - | 2370-2550 |
| | 5/8 | 2.5 | 2420-2770 | 2420-2770 | - | - | 2770-3000 |
| | 3/4 | 2.5 | - | - | - | - | - |

SPECIFICATIONS

The specifications on the following pages are provided for your information. For additional information, review the **SH-BAJRA** Device.



Properly Maintained Equipment is Safe Equipment

"FISHINGUSA's policy is one of continuous improvement; therefore, the right to make changes in design and model designs at any time - without notice and without obligation - is reserved exclusively to FISHINGUSA."

SPECIFICATIONS

| | <u>Model</u> | <u>42430</u> | <u>42431</u> | <u>57500ST</u> | <u>57500T</u> |
|----|------------------------------------|--------------------------|--|-------------------------|------------------------|
| | <u>Drive</u> | <u>2WD (Front Drive)</u> | <u>4 Wheel Drive</u> | <u>4 Wheel Drive</u> | <u>4 Wheel Drive</u> |
| 1 | Overall Length (mm) | | | 3370 | |
| 2 | Overall Width (mm) | 1700 | | 1920 | |
| 3 | Overall Height (mm) | 1955 | 1970 | 1975 | 1970 |
| 4 | Wheel Base (mm) | 1810 | 1870 | 1810 | 1870 |
| 5 | Front - rear track | 1210-1490 (6 st) | 1190 | 1215-1490 (6 st) | 1160 |
| 6 | Front wheelbase | | 1200-1500 (6 st) | | |
| 7 | Max Ground Clearance (mm) | 390 | 390 | 395 | 385 |
| 8 | Min. Turn (m) (90% Grade Form) | 2900 | 2940 | 2900 | 3000 |
| 9 | Bottom - Approach Chord | 2700 | 2860 | 2700 | 2940 |
| 10 | Mixed | 17-18A (PAW - FWD/FAW) | 18-19A (PAW - FWD/FAW) | 18-19A (PAW - FWD/FAW) | 18-19A (PAW - FWD/FAW) |
| 11 | Tire | | 4 Cylinders (Optional) (Front - Rear - Left - Right) | | |
| 12 | Number of Cylinders (Front - Rear) | | 4x185x900 | | |
| 13 | Compression Ratio | | | 12.1 | |
| 14 | Front Displacement (cc) | | | 2123 | |
| 15 | Output (hp) | 45.1250 | | 46.1240 | |
| 16 | Max. Horsepower (hp) | | 45 | | 50 |
| 17 | Cooling | | Dr. S. 6.8 - 7.0 | | |
| 18 | Transmission Stage | | Self-timing Gear System | | |
| 19 | Parking System | | Internal Combustion Engine Type | | |
| 20 | Hydrodynamic Lock | | Stainless | | |
| 21 | Front | 0.00 16.172 41.0 | 0.00 21.421 | 0.00 16.172 41.0 | 0.00 21.421 |
| 22 | Rear | | 12.5 1.622 31.428 | | |
| 23 | Steering | 1.475 | 1.630 | 1.625 | 1.580 |
| 24 | Front Axle | | 1-3/8 in. 1020 (11.6) Earth Splines | | |
| 25 | Front Axle Resistance | | Capacity | | |
| 26 | Speed (top & engine rpm) | 916.76 | 1062.1500 12500 | 950.714.1146.1243.12400 | |
| 27 | Front Clutch RPM | | CV Tensioner Pulley (Front and Rear) C.R. 700 | | |
| 28 | Max. Clutch Capacity (kg) | | 1970 | | |
| 29 | Front Disc | | Steel Plate | | |
| 30 | Front Brake | | 32.0 | | |
| 31 | Front Disc (F.D.) | | 0.1 | | |
| 32 | Front Disc (F.D.) | | 0.0 | | |
| 33 | Front Steering Resistance (kg) | | 1.3 (differential pressure 0.5) | | |
| 34 | Alternator (W. A.H.) | | 12V, 20A | | |
| 35 | Battery (V. A.H.) | | 12V, 100AH | | |
| 36 | Starting Voltage (V.A.H.) | | Starting Current 1 | | |
| 37 | Front Lamp (Watt) | | 1st: 12V, 1.62-2.72 | | |
| 38 | Front Lamp (Watt) | | 2nd: 12V, 1.62-2.72 | | |
| 39 | Front Lamp (Watt) | | Side Lamp | | |
| 40 | Front Lamp (Watt) | | 1st: 12V, 0.19-3.18 | | |
| 41 | Front Lamp (Watt) | | 1st: 6V, 0.22-2.33 | | |

* O-I-SH-D-A. PAW vehicle policy is one of continuous improvement, however the right to make changes in design and specification of any item without notice and without obligation is hereby granted by IHI Corp. previously built."

SPECIFICATIONS


SHIBAURA GROUND SPEEDS

From 1000 to 2400 RPM Engine Speed

With 12.4/11.2B Rear Tires

| POSITION | K-LOM 11 RS PCT 205/100 R16 Standard Tire | | | | | | | | | | | km/h |
|----------|---|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| | 4 | 6 | 8 | 10 | 12 | 14 | 16 | 18 | 20 | 22 | 24 | |
| 1st | 3.85 | 4.42 | | | | | | | | | | |
| 2nd | 4.98 | 5.53 | | | | | | | | | | |
| 3rd | 5.04 | 5.72 | | | | | | | | | | |
| 4th | 5.33 | 6.03 | 6.20 | | | | | | | | | |
| 5th | 5.75 | 6.47 | 6.77 | 7.07 | | | | | | | | |
| 6th | 7.12 | 7.81 | 8.11 | 8.41 | | | | | | | | |
| 7th | 7.92 | 8.62 | 8.92 | 9.22 | | | | | | | | |
| 8th | 8.77 | 9.47 | 9.77 | 10.07 | 10.37 | 10.67 | 10.97 | 11.27 | | | | |
| 9th | | 10.62 | 11.12 | 11.62 | 12.12 | 12.62 | 13.12 | 13.62 | | | | |
| 10th | | | 11.29 | 11.79 | 12.29 | 12.79 | 13.29 | 13.79 | | | | |
| 11th | | | | 12.56 | 13.06 | 13.56 | 14.06 | 14.56 | 15.06 | 15.56 | 16.06 | |
| 12th | | | | | | | | 15.85 | 16.35 | 16.85 | 17.35 | 22.73 |
| 13th | | 14.77 | 15.27 | | | | | | | | | |
| 14th | | 15.88 | 16.38 | 16.88 | | | | | | | | |
| 15th | | 15.53 | 16.03 | 16.53 | 17.03 | 17.53 | 18.03 | 18.53 | | | | |
| 16th | | 17.27 | 17.77 | 18.27 | 18.77 | 19.27 | 19.77 | 20.27 | 20.77 | 21.27 | 21.77 | |
| 17th | 18.11 | 18.61 | 19.11 | 19.61 | 20.11 | 20.61 | 21.11 | 21.61 | 22.11 | 22.61 | 23.11 | km/h |
| | km/h | km/h | km/h | km/h | km/h | km/h | km/h | km/h | km/h | km/h | km/h | km/h |

WIRING DIAGRAM



SAFETY AND INSTRUCTION DECALS

In the event that decals become damaged or illegible, they should be replaced with new decals at their original position.



CAUTION

- Know all operating procedures and safety precautions in the operator's manual before operating the tractor.
- Start engine only from the operator's seat with the PTO disengaged.
- Slow down on turns, rough ground and slopes to avoid roll over.
- Do not permit passengers under any circumstances.
- Stop engine and apply parking brake before dismounting from tractor.
- On public roads use warning lights and S.M.V. emblem to avoid accidents.

CAUTION - Know all operating procedures.
PART NO. - 390191240.
LOCATION - Center of L.H fender



WARNING

- KEEP HANDS FEET AND CLOTHING AWAY FROM PTO AND OTHER MOVING PARTS.
- DISENGAGE PTO AND SHUT OFF ENGINE BEFORE SERVICING TRACTOR OR IMPLEMENTS AND ATTACHING OR DETACHING IMPLEMENTS. KEEP SAFETY SHIELD IN PLACE.
- PULL ONLY FROM DRAWBAR PULLING FROM ANY OTHER POINT MAY CAUSE TIPPING

WARNING - keep hands, feet and clothing away from PTO and other moving parts.
PART NO. - 390191260
LOCATION - Rear of floor



Diff Lock Pedal
PART NO. 390191800
LOCATION Right side of floor



Glow Plug Indicator
PART NO. 390191650
LOCATION Right side of instrument panel

IMPORTANT

- For normal operation on firm soil, hard surfaces and roadways the unit front wheel drive should be disengaged to maximize tire and driveline life and fuel economy.
- Only use front wheel drive when additional traction is required while operating in loose soil, wet, slippery conditions or on slopes.

IMPORTANT - Front Wheel Drive
PART NO. 390192420
LOCATION - Center of R.H Fender



Four-Wheel Drive Control Lever
PART NO. 390170830
LOCATION - On the change lever
face right side



Creeper Range Lever
PART NO. - 390170780.
LOCATION - On the creeper
change lever face left side

SAFETY AND INSTRUCTION DECALS

ENGINE STARTING / STOPPING

• STARTING

1. Pull the throttle lever fully.
2. Depress the clutch pedal fully and move the gear and P.T.O. Shift lever to the neutral position while keeping the hydraulic positioning lever at the lowering position.
3. Turn the key to the "HEAT" position. The glow signal lamp lights and goes out about 3 seconds later.
4. Then turn the key to the "START" position to start the engine. (Turn the key directly to the "START" position when the engine is still warm.)
5. Push the throttle lever forward. Never fail to warm up the engine for 5 to 10 minutes at the idling speed. (Be sure the key is kept at "ON" position.)

• STOPPING

1. Keep the engine at the idling speed for about 5 minutes.
2. Push the throttle lever fully forward.
3. Turn the key to the "OFF" position.

SD5000T SD5040T
ENGINE - STARTING/STOPPING
PART NO. 390182400
LOCATION - Center of L. H. Fender



SD5000T, SD5040T
Hand Throttle Control Lever
PART NO. 390430150.
LOCATION - Hand throttle lever
right side of instrument panel



Starter Switch
PART NO. 390180930
LOCATION - Starter Switch, right
side of instrument panel



SD4300 SD4340
Hand Throttle Control Lever
PART NO. 390430140
LOCATION - Hand throttle lever
right side of instrument panel

SAFETY AND INSTRUCTION DECALS

PTO

PTO Gearshift Lever
PART NO. - 390170250.

3 **1**

PTD Gearshift Position (3-1)
PART NO. 390170180

4 **2**

PTD Gearshift Position (4-2)
PART NO. 390170190

MAIN TRANSMISSION

Main Shift Change Lever
PART NO. - 390170200



RANGE TRANSMISSION

Range Select Change Lever
PART NO. - 390170260

Flow Control Valve
PART NO. 390370360
LOCATION - Top of flow
Control Knob





IMPORTANT

For safe operation
when operating the
lever, remove the plate to
allow work.

IMPORTANT - Open the flood
PART NO. 390152470




Hydraulic Control Levers
PART NO. - 390370640




Turn Signal Switch
PART NO. - 390152190

Hydraulic Lift Control
PART NO. 390370650.
LOCATION - Center of R.H. Fender


SAFETY AND INSTRUCTION DECALS




Four-Wheel Drive
LUBRICATION AND MAINTENANCE
PART NO. 380210880
LOCATION - Ins. of front



Two-Wheel Drive
LUBRICATION AND MAINTENANCE
PART NO. 390210890.
LOCATION - Inside of fender



SD500031 SD50407
GROUNING SETTOS
PART NO - 390171150
LOCATION - Center of L.H Fender



SU4300 SU4340
GROUND SPFFDS
PART NO. - 390171180
LOCATION - Center of L ... Tandem

**PRE-DELIVERY SERVICE
CHECK AND ADJUST AS REQUIRED**

INOPERATIVE SERVICE CHECKS:

1. Tire pressure
2. Axle lock
3. Front end greasing
4. Hydraulic cylinder level
5. Battery electrolyte level
operating & storage levels
6. Engine oil level
7. Transmission and gearcase
oil level
8. Front Axle and Front Diff
oil level [4WD]
9. Starter safety switch
operation
10. Hydraulic fluid level
adjustment

OPERATIVE SERVICE CHECKS:

11. Upper link and hitch
12. Brake system and pedal
condition
13. Operation of
steering system
14. Rear wheel disc and rods
bolts torque levels
15. Front wheel disc and rods
bolts torque levels [2WD]
16. Rear wheel disc and rods
bolts torque levels [4WD]
17. Front wheel toe-in
18. Bushings
19. S. A. M. L. and bolt
condition
20. Check front end for
proper operation
21. Drain diesel fuel filter

All operating checks are to be performed
with the tractor at normal operating temperature.

1. Lights and instruments for
proper operation
2. Fluid and oil levels
3. Maximum no load speed and
idle speed adjustments and
fuel control
4. Starting and starter
safety switch
5. P. T. O. engagement and
disengagement
• Clutch pedal and
P. T. O. lever
6. Hydrostatic System
• Safety switches for position and
drift control operation
7. Flywheel clutch operation
8. Control lever free operation
9. Low speed transmission lever

TRACTOR MODEL NO. _____

INSPECTION PERFORMED
WARRANTY EXPLAINED

TRACTOR SERIAL NO. _____

OWNER'S SIGNATURE _____

DATE _____

DEALER'S SIGNATURE _____

DATE _____

**50-HOUR SERVICE
CHECK AND ADJUST AS REQUIRED**

INOPERATIVE SERVICE CHECKS:

1. Tire pressure
2. Check air cleaner air
operating
3. Improve clutch bushing
4. Transmission including clutch
lever adjustment
5. Battery electrolyte level
6. Fan belt tension
7. Battery electrolyte and water
operating, electrolyte level
and charge
8. External cables terminals
and wires
9. Drain and refill engine oil
10. Replace engine oil filter
11. Transmission and gearcase
oil level
12. Front axle bearing and front
diff oil level [4WD]
13. Inspection pump fittings
14. Cylinder head adjustment
15. Check hydraulic System
Oil level

OPERATIVE SERVICE CHECKS:

1. Lights and instruments for
proper operation
2. Fuel and oil levels
3. Maximum no load speed and
idle speed adjustments and
fuel control
4. Starting and starter safety switch
5. P. T. O.
6. Hydraulic System
• Safety switch for position and
drift control operation
7. Flywheel clutch operation
8. Control lever free operation
9. Low speed transmission lever

PERFORMANCE SPECIFIC CHECKS:

1. Engine operation in full
throttle and governor
operation
2. Transmission including clutch
3. Steering control
4. Differential lock - operating
and adjustment
5. Brake action
6. All optional equipment and
attachments

TRACTOR MODEL NO. _____

INSPECTION PERFORMED


TRACTOR SERIAL NO. _____

OWNER'S SIGNATURE _____

DATE _____

DEALER'S SIGNATURE _____

DATE _____



PRE-DELIVERY SERVICE
CHECK AND ADJUST AS REQUIRED

INOPERATIVE SERVICE CHECKS:

1. Tire pressure
2. Air cleaner and filter connections
3. Radiator coolant level
4. Fan belt tension
5. Battery clean & vent opening, electrolyte level and charge
6. Engine oil level
7. Transmission gear selector lever
8. Front Axle and Front Differential (4WD)
9. Steering safety switch operation
10. Hydraulic lift control adjustment

OPERATIVE SERVICE CHECKS

11. Upper link, and bush
12. Brake adjustment and pedal equalization
13. Operation of
brake pedal lock
14. Rear wheel disc and hub
bolts torque
15. Rear wheel disc and hub
runout of tightness (2WD)
16. Front wheel disc and hub
bolts torque (4WD)
17. Front wheel torque
18. Front bush
19. Sheet metal and paint
condition
20. Check lift rod for
proper operation
21. Drain diesel fuel filter

OPERATIVE SERVICE CHECKS

1. All operating checks are to be performed
with the tractor at normal operating temperature.
2. Lighted oil indicators for
proper operation
3. Fluid and oil levels
4. Maximum engine speed and
idle speed adjustments, and
load control
5. Starting and starter solenoid switch
6. Valve set
7. Hydraulic System
• Selection lever for position and
draft control operation
8. Engine oil level operation
9. Low-tower (steering) lever

TRACTOR MODEL NO.

INSPECTION PERFORMED
WARRANTY EXPIRED

TRACTOR SERIAL NO.

OWNER'S SIGNATURE

DATE

DEALER'S SIGNATURE

DATE

50-HOUR SERVICE
CHECK AND ADJUST AS REQUIRED

INOPERATIVE SERVICE CHECKS:

1. Tire pressure
2. Check air cleaner hose
connection
3. Radiator coolant filter(s)
4. Tachometer probe or servo
valve holders
5. Radiator coolant level
6. Fan belt tension
7. Battery clean & vent
opening, electrolyte level
and charge
8. All electrical cables, terminals
and wires
9. Gear and belt lubricant oil
10. Adjust engine oil filter
11. Transmission gear selector
lever
12. Front differential and front
axle oil level (4WD)
13. Pump oil pump filter
14. Cylinder head bolt torque
15. Clean Hydraulic System
oil filter

OPERATIVE SERVICE CHECKS:

1. Lighted oil indicators for
proper operation
2. Fluid and oil levels
3. Maximum engine speed and
idle speed adjustments, and
load control
4. Starting and starter solenoid switch
5. Valve set
6. Hydraulic System
• Selection lever for position and
draft control operation
7. Engine oil level operation

PERFORMANCE SERVICE CHECKS:

1. Engine oil filter location
identified and given out
operation
2. Transm. Lever including clutch
3. Sheet metal and paint
condition
4. Differential lock engagement
and disengagement
5. Brake action
6. All optional equipment and
accessories

TRACTOR MODEL NO.

INSPECTION PERFORMED

TRACTOR SERIAL NO.

OWNER'S SIGNATURE

DATE

DEALER'S SIGNATURE

DATE